


BTS400 Instruction Manual



SPECIFICATIONS





- | | |
|------------------------|---|
| 1. Power: | 5 Watts |
| 2. Frequency response: | 95Hz-18KHz |
| 3. Battery: | 10000±20mAh |
| 4. Playing Time: | Fully charged battery lasts about 4-6 hours |
| 5. Bluetooth™ Range: | 8-10 Meters in an open area |
| 6. Wireless Version: | V2.1 + EDR |

OPERATION


Power Button:  Turn the speaker on by pressing the power button for 2 seconds. The speaker says “hello” and then “start pairing”. To turn off, press the power button for 2 seconds and that speaker will say “goodbye”. The ring on the top lights up while power is on.

Pause/Play: Press and release power button to pause\play. (Or control from the music player)

Line-In/AUX function: Connect the 3.5mm line into the headphone jack of your computer and Micro USB plug into the speaker.

Next/Previous and Volume Up/Down: Use the “ ” “ ” keys to control theses function in Bluetooth paired mode , or use the functions on you smart phone or music player to control these functions when connected to pc/Laptop.

CHARGING

Plug the micro USB end of the charging cable into the charging port of the speaker and then connect the USB end of the charging cable to the USB port of your PC or other USB power source. The red LED will light up while charging (the small hole on the left corner of the micro USB ). The red LED will turn off automatically when charging is complete. It is strongly recommended that the speaker be fully charged before first use and after long periods of inactivity. Do not overcharge the battery.

WIRELESS PAIRING

1. Please check to make sure the device to which you are pairing has Bluetooth™ capabilities. This information should be included in your phone or music player's instructions or packaging.
2. Make sure that the speaker is turned off, then place the speaker and the smart phone or music player in proximity so that both devices are in view.
3. Turn the speaker on using the power button. While waiting for the Bluetooth™ connection, red and blue lights flash (1.0 seconds per flash).
4. Check your smartphone or music player for the speaker under the Bluetooth™ pairing options and select. Bluetooth code is "BTS400 " , Once connected ,the blue LED will light up and flash at 1.0 second intervals when playing audio . No password is needed for pairing. Should a password be requested, type "0000" in as the password.

Note: Some mobile phones or other devices may pair automatically when re-started.

PRECAUTIONS

- Please only use the computer USB or the DC 5V power adaptor matching the Micro USB interface to charge. Only use quality cords and adaptors.
- Please keep and use in normal environments. Exposure to extreme elements such as extreme heat and cold, fire, excessive moisture, dust, or other extreme elements may damage the unit. Do not touch with wet hands.
- Keep debris or other items from blocking the speakers or from entering any of the ports.
- Do not attempt to open, repair, or take apart the speaker. The speaker may be damaged during that process.
- If the speaker quality seems lessened, or a slight popping noise is heard, it may be due to low battery. Please recharge the speaker.
- This item is not meant for children.

TROUBLESHOOTING

No Sound

- Make sure that the music player is working and that the speaker is charged.
- Make sure the Bluetooth™ is paired to the device you are attempting to play. (It could automatically pair with another familiar device within pairing distance.)
- Make sure the BTS400 is in the proper mode.

Not charging

Check to make sure that you are using the correct cable and that it is fully plugged into both the device and the USB port that you are charging from. Also check to make sure the PC or other USB charger is turned on.

Operating temperature: -5°C to 40°C.

Storage temperature: -40°C to 85°C.

Humidity: Operating Humidity 10% to 95%

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. (5mm)

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.