

802.11n/b/g Wireless Outdoor High Power Access Point System

version 1.0

User Manual

Apply to:



ALCON ACP24



ALCON AMU24

FCC Notices

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

RF exposure warning:


The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment. The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

Revision History

Version	Date	Notes
0.2.4	August , 2013	Initial Version
0.2.8	January , 2014	Add some features
0.3.2	April , 2014	Released version

AP Configuration Using Locator

While entering the Locator utility, the Locator will automatically search the AP available on the same network. Locator will show the Device Name, Device Type, IP Address, Ethernet MAC Address and Firmware Version in first page. Before start using Locator, make sure you disable personal firewall installed in you PC. (Ex. Windows XP personal firewall)



If you have 2 Fast Ethernet Adapter or more, you can choose enable one Fast Ethernet Adapter for enter with Locator utility.

AP Configuration Using Web User Interface

Before Setup...

❖ Verify the IP address setting


You need to configure your PC's network settings to obtain an IP address. Computers use IP addresses to communicate with each other across a network, such as the Internet.

1. Click **Start**, select **Control Panel**. Double-click the **Network Connections**.
2. Right click the **Local Area Connection** and click **Properties**; select **Internet Protocol (TCP/IP)** for the applicable Ethernet adapter. Then click **Properties**.
3. Select **USE the following IP address**, enter **192.168.254.254** (but, **192.168.x.x** for the device use) in the **IP Address** field and **255.255.0.0** in the **Subnet Mask** field, then click **OK**.

Start Setup by Browser...

1. After getting the correct connection, start the web browser (make sure you disable the proxy) and enter [192.168.x.x \(x is outdoor unit](http://192.168.x.x)

[IP Address](http://192.168.x.x)) in the **Address** field. Press **Enter**.



2. Enter the factory default **User name** and **Password** as:

User Name: **Admin**


Password: **(leave blank)**

then click **OK**.

3. You will enter the Utility homepage.

Start Setup by Locator...

1. You just need to click on the **Web** icon in Locator main page. The Locator will launch a default browser for you and lead you into web UI directly.



Wireless Configuration - AP Mode

System Information –

The default operation mode is AP mode. And the first page appears in main page will show **System Status -> System Summary** automatically, you can find detail system configuration in this page.

300Mbps Wireless Broadband Access Point

Access Point

- Status
 - System Summary
 - Wireless Station List
 - Throughput
 - Event Log
- System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless MAC Filter
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset

System Summary

System Information

Device Name	MIMO AP
Ethernet MAC Address	00:23:28:24:04:46
Wireless MAC Address	00:23:28:24:04:47
Country	N/A
Current Time	Thu Jan 1 00:43:34 UTC 1970
Firmware Version	0.3.2
Spanning Tree Protocol	Disabled

IP Settings

IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
DHCP Client	Disabled

Current Wireless Settings

Operation Mode	Access Point
Wireless Mode	IEEE 802.11g/n HT20
Frequency/Channel	2.412 GHz (Channel 1)
Profile Isolation	No
Profile Settings (SSID/Security/VID)	1 Generic/Open System/No Encryption/1
	2 N/A
	3 N/A
	4 N/A
Distance	1 Km

Client List –

Automatically, this page can help user to identify current devices who already associated to the AP

300Mbps Wireless Broadband Access Point

- Access Point
 - Status
 - System Summary
 - Wireless Station List
 - Throughput
 - Event Log
 - System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
 - Wireless
 - Wireless Network
 - Wireless MAC Filter
 - Wireless Advanced Settings
 - Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset

Client List

#	MAC Address	RSSI(dBm)
1	00:23:28:24:04:41	-37

Throughput –

This page shows the throughput for both LAN and WLAN. It refreshes every 5 seconds.

300Mbps Wireless Broadband Access Point

- Access Point
 - Status
 - System Summary
 - Wireless Station List
 - Throughput
 - Event Log
 - System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
 - Wireless
 - Wireless Network
 - Wireless MAC Filter
 - Wireless Advanced Settings
 - Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset


Throughput

LAN

WLAN

System Log –

Click **Event Log**, the device automatically logs (records) events of possible interest in its internal memory. If there is not enough internal memory for all events, logs of older events are deleted, but logs of the latest events are retained.





You can start to configure the system. In **System Settings** page, you can configure:

- **Device Name** – You may assign any name to the Access Point. Using memorable and unique names are helpful, especially if you are employing multiple access points in the same network. The device name needs to be less than 32 characters. After verify the name you input, click **Apply** to save the change.
- **Country/Region** – Here you can set the AP to follow different country and region regulation.
- **Operation Mode** - The default operation mode is **Access Point**, this connects your wireless PCs and devices to a wired network. In most cases, no change is necessary. You can switch operation mode to **Wireless Client**, **Pt(M)P Bridge** or **Repeater** mode depends on your application. Wireless Client mode allows this device to act as a client within its range. Your Ethernet devices behind the unit can connect to remote AP. Repeater mode is able to talk with one remote access point within its range and retransmit its signal. Choose repeater mode if you

want to extend the range of your original AP. Pt(M)P Bridge mode allows Bridge point to point or point to multi-point network architecture, In order to establish the wireless link between bridge radios, the MAC address of remotes bridge(s) need to be registered in the address table. Enter the MAC address with format xx:xx:xx:xx:xx:xx (x is the hexadecimal digit). A Master Bridge Radio may accommodate up to **8** remote MAC addresses.

Make sure you click **Apply** to save the changes before move to next page.



IP Settings –

IP Setting page can configure system IP address. Default IP address is 192.168.1.1 and Subnet Mask is 255.255.255.0. You can manually enter the IP address setting or get an IP from a DHCP server.

- **IP Network Setting** – Here you can choose to get IP from a DHCP server or specify IP address manually. Choose to obtain an IP address from DHCP server if your environment or ISP provides DHCP server.

Otherwise, you can manually setup IP address.

- **IP Address** – The IP address need to be unique to your network. We would like to recommend you stay with default IP address 192.168.x.x. This is private address and should work well with your original environment.
- **IP Subnet Mask** – The Subnet Mask must be the same as that set on your Ethernet network.
- **Default Gateway** – If you have assigned a static IP address to the Access Point, then enter the IP address of your network's Gateway, such as a router, in the Gateway field. If your network does not have a Gateway, then leave this field blank.

The screenshot shows the configuration interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left is a navigation menu with categories: Access Point, Status, System, Wireless, and Management. The "IP Settings" section is active, showing a table of network parameters. The "IP Network Setting" is set to "Specify an IP address". The IP Address is 192.168.1.1, the Subnet Mask is 255.255.255.0, and the Default Gateway is 0.0.0.0. There are also fields for Primary and Secondary DNS, both set to 0.0.0.0. "Apply" and "Cancel" buttons are at the bottom.

IP Network Setting	Obtain an IP address automatically (DHCP)	Specify an IP address
IP Address		192 . 168 . 1 . 1
IP Subnet Mask		255 . 255 . 255 . 0
Default Gateway		0 . 0 . 0 . 0
Primary DNS		0 . 0 . 0 . 0
Secondary DNS		0 . 0 . 0 . 0


The screenshot shows a Microsoft Internet Explorer window titled "Processing - Microsoft Internet Explorer". A dialog box is displayed with the text "Processing now! Please wait..." and a progress bar that is 50% full.

Spanning Tree Settings –

Click **Spanning Tree Settings** under **System Configuration** menu, Spanning-Tree Protocol is a link management protocol that provides path redundancy while preventing undesirable loops in the network.

- **Spanning Tree Status:** Choose to enable or disable the spanning tree feature.
- **Bridge Hello Time:** Specify the number of seconds for the hello time.
- **Bridge Max Age:** Specify the number of seconds for the max age.
- **Bridge Forward Delay:** Specify the number of seconds for the bridge forward delay.
- **Priority:** Specify the number of seconds for the priority.

Click **Apply** to save the changes before leaving this page.



300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- **Spanning Tree Settings**

Wireless


- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Spanning Tree Settings

Spanning Tree Status	<input checked="" type="radio"/> On <input type="radio"/> Off
Bridge Hello Time	2 seconds (1-10)
Bridge Max Age	20 seconds (6-40)
Bridge Forward Delay	15 seconds (4-30)
Priority	82768 (0-65535)



In **Wireless** page, each option is described below

Wireless Network -

Wireless Network page allows you to configure the **Wireless Mode, Channel / Frequency, SSID** and **Security** etc.

- **Wireless Mode** – Default setting is **802.11g/n HT20**. This will support all 802.11g clients connect to the AP. You can choose **802.11g** in wireless mode column if your environment only has 802.11g clients.
- **Channel / Frequency** –The channels available are based on the country's regulation and select the appropriate channel from the list provided to correspond with your network settings.
- **Current Profiles** – You may configure up to four different wireless profiles. Click **Edit** to modify the profile and check the **Enable** box to activate the profile.
- **Profile (SSID) Isolation** – Stations connected to different profiles cannot access each other. Choose **No Isolation** (Full access), or **Isolate all profiles (SSIDs) from each other using VLAN (802.1Q) standard**.
- **SSID Profile** – The SSID is the unique name shared among all points in a wireless network. The SSID must be identical for all points in the wireless network. It is case-sensitive and must not exceed 32 alphanumeric characters, which may be any keyboard character. Make sure this setting is the same for all points in your wireless network. For added security, you should change the SSID from the default name **Generic**, to a unique name.
- **VLAN ID** – If you have enabled VLAN tagging on your network, specify the VLAN tag ID 1 to 4095. You can assign an SSID to a VLAN. Client devices using the SSID are grouped in that VLAN.
- **Suppressed SSID** – This option can hide the SSID not available from site survey tool. Enable this function only if you do not want the Access Point to be found by others.
- **Stations Separation** – Default setting is **Disable**. This option can disallow the client devices connected to this AP to access each other.
- **Security Mode**: By default, the security is **Disabled**. Refer to the next section to configure the security features such as **WEP, WPA-PSK, WPA2-PSK, WPA-PSK Mixed, WPA, WPA2** and **WPA-Mixed**.

Click **Apply** to save the changes.

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Mode	802.11g			
Channel / Frequency	802.11g HT20 <input type="checkbox"/> Auto			
	802.11g/n HT20			
	802.11g/n HT40(+)			
	802.11g/n HT40(-)			

SSID	Security	VID	Enable	Edit
Generic	Open System/No Encryption	1	<input checked="" type="checkbox"/>	<input type="button" value="Edit"/>
Generic2	Open System/No Encryption	2	<input type="checkbox"/>	<input type="button" value="Edit"/>
Generic3	Open System/No Encryption	3	<input type="checkbox"/>	<input type="button" value="Edit"/>
Generic4	Open System/No Encryption	4	<input type="checkbox"/>	<input type="button" value="Edit"/>

Profile (SSID) Isolation

No Isolation

Isolate all Profiles (SSIDs) from each other using VLAN (802.1Q) standard

SSID Profile


Wireless Setting

SSID	Generic (1 to 32 characters)
Max. Stations	32 (1~32)
VLAN ID	1 (1~4095)
Suppressed SSID	<input type="checkbox"/>
Station Separation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

Wireless Security

Security Mode	Disabled
---------------	----------

- Disabled
- WEP
- WPA-PSK
- WPA2-PSK
- WPA-PSK Mixed
- WPA
- WPA2
- WPA Mixed



Wireless Security -

The wireless security settings configure the security type of your wireless network. There are different wireless security mode options supported by the Access Point.

In Wireless Security page, you can configure the AP to work with **Disabled** (means no security), **WEP**, **WPA-PSK**, **WPA2-PSK**, **WPA-PSK Mixed**, **WPA**, **WPA2** and **WPA-Mixed** mode. Once you setup the AP to work in security mode, all wireless stations will also need to have corresponding settings. System default setting is **Disabled**.

WEP is a basic encryption method, which is not as secure as WPA. To use WEP, you will need to select a default transmit key and a level of WEP encryption.

- **Authentication Type:** Select an authentication method. Options available are **Open System** or **Shared Key**. An open system allows any client to authenticate as long as it conforms to any MAC address filter policies that may have been set. All authentication packets are transmitted without encryption. **Shared Key** sends an unencrypted challenge text string to any device attempting to communicate with the Access Point. The device requesting authentication encrypts the challenge text and sends it back to the Access Point. If the challenge text is encrypted correctly, the Access Point allows the requesting device to authenticate.
- **Input Type:** Select **Hex** or **ASCII** from the drop-down list.
- **Key Length:** Select a key format from the drop-down list. 40/64bit-hex keys require 10 characters or ASCII keys require 5 characters, where as 104/128-bit-hex keys require 26 characters or ASCII keys require 13 characters, as 128/152-bit-hex keys require 32 characters or ASCII keys require 16 characters. A hex key is defined as a number between 0 through 9 and letter between A through F.
- **Default Key:** You may use up to four different keys for four different networks. Select the current key that will be used.
- **Key table** – You can enter 4 different WEP encryption keys into the table and by choosing the radio button to decide which one is valid now. The AP supports 64, 128 and 152bit key length. The longer key we

choose usually means the encryption is stronger.

SSID Profile


Wireless Setting

SSID	Generic (1 to 32 characters)
Max. Stations	32 (1~32)
VLAN ID	1 (1~4095)
Suppressed SSID	<input type="checkbox"/>
Station Separation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

Wireless Security

Security Mode	WEP
Auth Type	Open System
Input Type	Hex
Key Length	40/64-bit (10 hex digits or 5 ASCII char)
Default Key	40/64-bit (10 hex digits or 5 ASCII char) 104/128-bit (26 hex digits or 13 ASCII char) 128/152-bit (32 hex digits or 16 ASCII char)
Key1	
Key2	
Key3	
Key4	

After all changes are made, click **Save** to make sure all changes are saved into system.



WPA-PSK stands for Wi-Fi Protected Access – Pre-Shared Key. WPA-PSK is design for home users who do not have RADIUS server in their network environment. WPA can provide better security level than WEP without difficult setting procedure.

- **Encryption** - WPA gives you three encryption methods: **Auto**, **TKIP** and **AES**, with dynamic encryption keys.
- **PassPhrase** - Enter a WPA Shared Key of 8-63 characters. The Shared Key should be also applying the clients work in the same wireless network.
- **Group Key Update Interval** - Enter a number of seconds which instructs

the Access point how often it should change the encryption keys. Usually the security level will be higher if you set the period shorter to change encryption keys more often. Default value is 3600 seconds, set 0 in Group Key Update Interval to disable key renewal.

Remember to click **Save** to make sure all changes are made before leaving this page.


SSID Profile

Wireless Setting

SSID	Generic (1 to 32 characters)
Max. Stations	32 (1~32)
VLAN ID	1 (1~4095)
Suppressed SSID	<input type="checkbox"/>
Station Separation	<input type="checkbox"/> Enable <input checked="" type="checkbox"/> Disable

Wireless Security

Security Mode	WPA-PSK
Encryption	Auto
Passphrase	1 (1~63 characters) or (64 Hexadecimal characters)
Group Key Update Interval	3600 seconds(30~3600, 0: disabled)



WPA option features WPA used in coordination with a RADIUS server (this should only be used when a RADIUS server is connected to the Access Point).

- **Encryption** – WPA gives you three encryption methods: **Auto**, **TKIP** and **AES**, with dynamic encryption keys.
- **RADIUS Server** – Enter the IP address of your RADIUS server.
- **RADIUS Port** – Port number for RADIUS service, default value is **1812**
- **RADIUS Secret** – RADIUS secret is the key shared between Access Point and RADIUS server.

- **Group Key Update Interval** – This column indicate how often should the Access Point change the encryption key. Default value is 3600 seconds, set 0 in Group Key Update Interval to disable key renewal.


SSID Profile

Wireless Setting

SSID	Generic (1 to 32 characters)
Max. Stations	32 (1~32)
VLAN ID	1 (1~4095)
Suppressed SSID	<input type="checkbox"/>
Station Separation	<input type="radio"/> Enable <input checked="" type="radio"/> Disable

Wireless Security

Security Mode	WPA
Encryption	Auto
Radius Server	0.0.0.0
Radius Port	1812
Radius Secret	secret1
Group Key Update Interval	3600 seconds(30~3600, 0: disabled)





Wireless MAC Filter –

In this page, you can filter the MAC address by allowing or blocking access the network.

- **ACL (Access Control) Mode:** You may choose to **Disabled**, **Deny MAC in the List**, or **Allow MAC in the List**. By selecting **Allow MAC in the List**, only the address listed in the table will have access to the network; all other clients will be blocked. On the other hand, selected **Deny MAC in the List** means only the listed MAC addresses will be blocked from accessing the network; all other clients will have access to the network.
- **MAC Address:** Enter the MAC address.

- This table lists the blocked or allowed MAC addresses; you may delete selected MAC address or delete all the addresses from the table by clicking **Delete**.

Remember to click **Apply** to make sure all the changes are saved to system.



Wireless Advanced Settings -

The page below can help users to configure advanced wireless setting. Before making any changes in this page, please check your wireless settings on other system as well, as these changes will alter the effectiveness of the Access Point. In most cases, these settings do not need to be changed.

- **Data Rate** – In data rate column, you can select all bit rate supported in current operation mode. Default value is **Auto** which means the system will automatically adjust the connection speed dynamically according to your current link status.

- **Transmit Power** – You can reduce RF output power by selecting adjustable transmit power by 1dBm step from 28 to 3 dBm. Changing transmit power may decrease your wireless signal coverage. This feature can be helpful in restricting the coverage area of the wireless network. You can arrange the different data rate in distance in Access Point mode. Please refer below table.
- **Aggregation** – When you enable this function, the device will combine several packets and then transmit them as one. This is to reduce the overhead when there are large packets to be transmitted.
- **WMM** – Choose to **Enable** or **Disable** wireless multimedia mode.
- **Distance (1-30km)** – Setup this parameter according to the longest link distance between the point to point, or point to multi-point in the network. The input needs to be greater than or equal to the real distance. The range can be from 1km to 30km.
- **Wireless Traffic Shaping** – Choose to enable or disable wireless traffic shaping, specify the incoming and outgoing transmission limit kbit/s.

Remember to click **Apply** to make sure all changes are made before leaving this page.


The screenshot shows the configuration interface for a 300Mbps Wireless Broadband Access Point. The page title is "300Mbps Wireless Broadband Access Point". On the left, there is a navigation menu with sections: "Access Point", "Status" (System Summary, Wireless Station List, Throughput, Event Log), "System" (System Settings, IP Settings, Spanning Tree Settings), "Wireless" (Wireless Network, Wireless MAC Filter, Wireless Advanced Settings), and "Management" (Administration, SNMP Settings, Backup/Restore Settings, Firmware Upgrade, Time Settings, Log, Diagnostics, System Reset). The "Wireless Advanced Settings" section is active, displaying the following configuration:

Wireless Advanced Settings	
Data Rate	MCS 0 - 6.5 <input checked="" type="checkbox"/> Auto
Transmit Power	28 dBm
Aggregation	<input checked="" type="checkbox"/> Enable 32 frames (1 ~ 32) 50000 bytes (2304 ~ 65535)
WMM	Enable
Distance	1 km (1 ~ 30)

Below the advanced settings is the "Wireless Traffic Shaping" section:

Wireless Traffic Shaping	
Enable Traffic Shaping	<input type="checkbox"/>
Incoming Traffic Limit	0 kbit/s
Outgoing Traffic Limit	0 kbit/s

At the bottom of the configuration area, there are "Apply" and "Cancel" buttons.



Management

Administration –

In the administration page, you can modify the **Name** and **Password** for administrator. Changing the login user name and password is as easy as entering the string you wish in the column. Then enter the password in the second column to confirm. This option allows you to create a user name and password for the device. By default, this device is configured with a user name **Admin** and password is **(leave blank)**. For security reasons, it is highly recommended that you create a new user name and password. Click **Apply** to finish the procedure. Be sure you noted the modification before apply all changes.

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings


Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Administration

Administrator

Name	<input type="text" value="Admin"/>
Password	<input type="text"/>
Confirm Password	<input type="text"/>



SNMP Settings–

Under System Configuration, click **SNMP** to display and change settings for the Simple Network Management Protocol.

To communicate with the access point, the **SNMP** agent must first be enabled and the Network Management Station must submit a valid community string for authentication. Select **SNMP** Enable and enter data into the fields as described below. Click **Apply** to save the changes.

Setting	Description
SNMP Enable/Disable	Enables or disables SNMP.
Contact Location	Sets the location string that describes the system location. Maximum length is 255 characters.
Community Name (Read Only)	Specifies a community string with read-only access. Authorized management stations are able to retrieve MIB objects. Maximum length is 32 characters. Default is public .
Community Name (Read/Write)	Specifies a community string with read-write access. Authorized management stations are able to both retrieve and modify MIB objects. Maximum length is 32 characters. Default is private .
Trap Destination IP Address	Enter the IP address of the trap manager that will receive these messages.
Trap Destination Community Name	Enter the community name of the trap manager that will receive these messages. Default is public

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless


- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- **SNMP Settings**
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

SNMP Settings

SNMP Enable/Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Contact	<input type="text"/>
Location	<input type="text"/>
Community Name (Read Only)	public
Community Name (Read/Write)	private
Trap Destination IP Address	0 . 0 . 0 . 0
Trap Destination Community Name	public



Backup/Restore and Reset to factory default Settings–

In this section, you can **Backup/Restore Setting** and **Revert to Factory Default Settings**:

- **Save A Copy of Current Settings** – Click **Backup**, the system will prompt you where to save the backup file. You can choose the directory to save your configuration file.
- **Restore Saved Settings from A File** – Here you can restore the configuration file from where you previously saved.
- **Revert To Factory Default Settings** – Be very carefully before restore system back to default since you will lose all current settings immediately. If you act the function, the IP address will restore the establishing value situation.
192.168.1.1 in the **IP Address** field and **255.255.255.0** in the **Subnet Mask** field,

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Backup/Restore Settings

Save A Copy of Current Settings

Restore Saved Settings from A File

Revert to Factory Default Settings

Firmware Upgrade –

Enter the location of the firmware upgrade file in the file path field, or click **Browse** to find the firmware upgrade file. Click **Upgrade**, and follow the instructions. The whole firmware upgrade process will take around 1 minute. Before upgrade, make sure you are using correct version. Please check with your technical support service if new firmware available.

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Firmware Upgrade

Current firmware version: 0.3.2


Locate and select the upgrade file from your hard disk:

Time Settings –

This page allows you to configure the time on the device. You may do this manually or by connecting to a NTP server.

- **Manually Set Date and Time:** Setup the date and time
- **Automatically Get Date and Time:** Select the time zone from the drop down list and then specify the IP address of the NTP server.

Click **Apply** to save the changes.



300Mbps Wireless Broadband Access Point

Access Point

- Status
 - System Summary
 - Wireless Station List
 - Throughput
 - Event Log
- System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless MAC Filter
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset

Time Settings

Time

Manually Set Date and Time


1970 / 01 / 01 05 : 00

Automatically Get Date and Time

Time Zone: UTC+00:00 England

User defined NTP Server:

Apply Cancel



Processing - Microsoft Internet Explorer

Processing now! Please wait...

50 %


Log Settings –

This page displays a list of events that are triggered on the Ethernet and Wireless interface. This log can be referred when an unknown error occurs on the system or when a report needs to be sent to the technical support department for debugging purposes.

- **Syslog:** Choose to enable or disable the system log.
- **Log Server IP Address:** Specify the IP address of the server that will receive the system log.
- **Local Log:** Choose to enable or disable the local log.

Click **Apply** to save the changes.

The screenshot shows the configuration interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left is a navigation menu with categories: "Access Point" (Status, System, Wireless, Management), "Status" (System Summary, Wireless Station List, Throughput, Event Log), "System" (System Settings, IP Settings, Spanning Tree Settings), "Wireless" (Wireless Network, Wireless MAC Filter, Wireless Advanced Settings), and "Management" (Administration, SNMP Settings, Backup/Restore Settings, Firmware Upgrade, Time Settings, Log, Diagnostics, System Reset). The "Log" section is active, showing "Syslog" settings with a "Syslog" dropdown set to "Disable" and a "Log Server IP Address" field containing "0 . 0 . 0 . 0". Below that, "Local log" settings show a "Local Log" dropdown set to "Disable". At the bottom of the settings are "Apply" and "Cancel" buttons.



Diagnostics –

300Mbps Wireless Broadband Access Point

Access Point

Status

- System Summary
- Wireless Station List
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- **Diagnostics**
- System Reset

Diagnostics

Ping Test Parameters

Target IP	<input style="width: 100%;" type="text"/>
Ping Packet Size	<input style="width: 80%;" type="text" value="64"/> Bytes
Number of Pings	<input style="width: 80%;" type="text" value="4"/>

Traceroute Test Parameters

Traceroute target	<input style="width: 100%;" type="text"/>
--------------------------	---

- **Target IP:** Specify the IP address you would like to search.
- **Ping Packet Size:** Specify the packet size of each ping.
- **Number of Pings:** Specify how many times of ping.
- **Traceroute Target:** Specify an IP address or Domain name you would like to trace.

System Reset –

There are 2 different mechanisms for the device to reboot: Auto Reboot and Schedule to Reboot.

- **Auto Reboot:** When you enable this function, you will need to specify an IP address which you want this device to ping. This IP address could be another wireless device, a server or any device with IP address. And you can decide the time period (in seconds) or the failure counts to trigger this function.
- **Schedule to Reboot:** This function is used when there are large data communicating in your network which may cause system unstable as sometimes the buffer memory on different devices such as the Access point, IP camera, switch, or computer would run out and you may find the fastest way to get the whole system back to work by unplug the power (any device) and power it up again. This is because the buffer memory will be released when you unplug the power. Thus, you may use this function to specify a time that you want this device to reboot.
- **Reboot Now:** you can choose to **Reboot the Device** or **Restore to**

Factory Default.

300Mbps Wireless Broadband Access Point

Access Point

- Status
 - System Summary
 - Wireless Station List
 - Throughput
 - Event Log
- System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless MAC Filter
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset

Reset

Auto Reboot

Enable Ping Watchdog	<input type="checkbox"/>
IP Address To Ping	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/>
Ping Interval	<input type="text"/> 300 seconds
Startup Delay	<input type="text"/> 300 seconds
Failure Count To Reboot	<input type="text"/> 3

Schedule to Reboot

Periodic Reboot	<input type="text"/> Disable
-----------------	------------------------------

Reboot Now

The System Settings section allows you to reboot the device, or restore the device to the factory default settings. Restoring the unit to the factory default settings will erase all settings, including any rules you have created.

System Commands	<input type="button" value="Reboot the Device"/>
	<input type="button" value="Restore to Factory Defaults"/>

Wireless Configuration – Pt(M)P Bridge Mode (Point to Point & Point to Multi-Point)

Pt(M)P Bridge is used for wirelessly connect several Access Points, and in doing so extend a wired infrastructure to locations where cabling is not possible or inefficient to implement (be sure you understand the purpose of bridge mode before proceed configuration).

The screenshot displays the configuration interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left, there is a navigation menu with sections: "Pt(M)P Bridge", "Status" (System Summary, WDS Link Status, Throughput, Event Log), "System" (System Settings, IP Settings, Spanning Tree Settings), "Wireless" (Wireless Network, WDS Security, Wireless Advanced Settings), and "Management" (Administration, SNMP Settings, Backup/Restore Settings, Firmware Upgrade, Time Settings, Log, Diagnostics, System Reset). The main content area is titled "System Settings" and contains the following fields:

Device Name	MIMO CLIENT (1 to 32 characters)
Country/Region	Please Select a Country Code
Operation Mode	<input type="radio"/> Access Point <input type="radio"/> Wireless Client <input checked="" type="radio"/> Pt(M)P Bridge <input type="radio"/> Repeater

At the bottom of the form, there are "Apply" and "Cancel" buttons.

Click **Wireless Network** under Wireless menu, you can configure:

Wireless Setting –

- **Wireless Mode** – Default setting is **802.11g/n HT20**. This will support all 802.11g clients connect to the AP. You can choose **802.11g** in wireless mode column if your environment only has 802.11g clients.
- **Channel / Frequency** –The channels available are based on the country's regulation and select the appropriate channel from the list provided to correspond with your network settings.

WDS Link Setting: Select Enable and enter the MAC address.

300Mbps Wireless Broadband Access Point

Pt(M)P Bridge

Status

- System Summary
- WDS Link Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- **Wireless Network**
- WDS Security
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Mode	802.11g/n HT20
Channel / Frequency	Ch1-2.412GHz

WDS Link Setting

ID	MAC Address	Mode
1	00 : 23 : 28 : 24 : 04 : 01	Enable
2	: : : : :	Disable
3	: : : : :	Disable
4	: : : : :	Disable
5	: : : : :	Disable
6	: : : : :	Disable
7	: : : : :	Disable
8	: : : : :	Disable

Apply Cancel

Considerations before installation –

- **Loop Prevention** – Be careful to plan your Wireless Bridge connections, prevent your wireless network topology to have loop. Once loop shows up, your network traffic will become unstable.
- **Performance** – The system can support up to **8** Wireless Bridge links. But all links and wireless stations that operate at the same time will all share single radio bandwidth (Ex. 11g have 54Mbps bandwidth).
- **Latency** – In the chain topology configuration, if the chain becomes very long, end-to-end latency issue may come in play. We suggest the Bridge link topology planning should not exceed 2 hops in chain configuration.

300Mbps Wireless Broadband Access Point

Pt(M)P Bridge

Status

- System Summary
- **WDS Link Status**
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- **WDS Security**
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

WDS Link Status

Station ID	MAC Address	RSSI (dBm)
1	00:23:28:24:04:41	-36

Wireless Bridge (WDS) Security –

Wireless Bridge (WDS) now only supports limit wireless security protocol. Here lists Wireless Bridge (WDS) security settings below:

- **None** – Both Point to Point and Point to Multi-Point traffic transmit without encryption.
- **AES** – Both Point to Point and Point to Multi-Point traffic are encrypted by the same AES key.

300Mbps Wireless Broadband Access Point

Pt(M)P Bridge

Status

- System Summary
- WDS Link Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- WDS Security
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset


WDS Security

Security	None
Key Passphrase	AES (8 to 32 hexadecimal characters)

After all changes are made, click **Apply** to save into system.

Wireless Configuration – Wireless Client Mode


This device can also work as a client device. In order to setup this device to work in such mode, you need to choose **Wireless Client** mode and click **Apply**.



The screenshot shows the configuration interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left, there is a navigation menu with sections: "Wireless Client", "Status", "System", "Wireless", and "Management". The "System Settings" section is active, showing a form with the following fields:

Device Name	MIMO CLIENT (1 to 32 characters)
Country/Region	Please Select a Country Code
Operation Mode	<input type="radio"/> Access Point <input checked="" type="radio"/> Wireless Client <input type="radio"/> Pt(M)P Bridge <input type="radio"/> Repeater

At the bottom of the form, there are "Apply" and "Cancel" buttons.



After the system reboot is done, you can see the page as below. Status page show the device is now working in Wireless Client mode.

Connection Status -

This column show current connection status. If this device already connects to an Access Point or station, here will show the MAC address of the associated Access Point or station. Otherwise, connection column will show **N/A** which means no connection to any Access Point or station.

- **Wireless Client Type** – Here indicates the information of this device.
- **SSID** – SSID column displays current SSID assigned to the AP.
- **BSSID** – Basic Service Set Identifier. This is the assigned MAC address of the station in the access point.
- **Connection Status** – Showa the current status **Associated** or **N/A**.
- **Wireless Mode** – Shows the Access Point current work in either 11g or 11n mode.
- **Current Channel** – This column indicates the radio channel currently in use.
- **Security** – Indicates AP security settings in client mode. Should be either **Disabled**, **WEP** or **WPA-PSK**.
- **Tx Data Rate(Mbps)** – Shows the current Tx Data rate status.
- **Current noise level** –This column shows current link quality with AP by noise level in 0 to -96 dBm scale.
- **Signal strength** – This column shows current link quality with AP by signal strength in 0 to -96 dBm scale.

300Mbps Wireless Broadband Access Point

Wireless Client

Status

- System Summary
- **Connection Status**
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Connection Status

Wireless Client Type	Universal Client
SSID	Generic
BSSID	00:23:28:24:04:47
Connection Status	Associated
Wireless Mode	802.11g/n HT20
Current Channel	2412MHz (Channel 1)
Security	Disabled
Tx Data Rate(Mbps)	144.444
Current noise level	-95 dBm
Signal strength	-36 dBm

Wireless Network -

Wireless Setting

- **Wireless Client Type** – Default setting is **Universal Client** which will send out the MAC address of this device. The WDS Client, on the other hand, will send out the MAC address which connected to the device.
- **SSID** - The SSID is the unique name shared among all points in a wireless network. The SSID must be identical for all points in the wireless network. It is case-sensitive and must not exceed 32 alphanumeric characters, which may be any keyboard character. You can also click **Site Survey** and choose any available AP; system will determine the Access Point currently available and establish connection with that Access Point. If you already understand your wireless environment well, you can enter the SSID in manually.

In Wireless Network page, you can find **Site Survey** button as shown below. You can click on it to find all wireless networks available in your current environment.

The screenshot shows the configuration interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left is a navigation menu with sections: "Wireless Client" (Status, System, Wireless, Management), "Wireless Network", "Wireless Security", and "Wireless Client". The "Wireless Network" section is active, showing the following settings:

Wireless Setting	
Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 47

Below the settings, there is a "Wireless Security" section with "Security Mode" set to "Disabled". At the bottom, there are "Apply" and "Cancel" buttons.

The Site Survey page can help you identify all the APs currently working in your environment. Just click on the **BSSID** column, the system will join you to the SSID you specify. In **Site Survey** page, you can also see the details of all SSIDs currently available.

300Mbps Wireless Broadband Access Point

Wireless Client

Status

- System Summary
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Scanning

Please wait...

300Mbps Wireless Broadband Access Point

Wireless Client

Status

- System Summary
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset


Site Survey

2GHz Site Survey

BSSID	SSID	Channel	Signal	Security
00:80:c6:e7:98:cc	28167062	6	-65 dBm	NONE
00:18:84:25:05:a0	4FALCON2	11	-52 dBm	WEP
00:23:28:24:04:4b	ACP 2F TEST	7	-90 dBm	NONE
00:22:69:90:42:42	CHTN_T07AW	1	-41 dBm	NONE
00:c0:a8:d5:d0:2a	DLINK999	9	-84 dBm	WEP
02:0a:00:79:71:98	GPLUS P7800+	1	-89 dBm	WPA2
08:3e:8e:7c:11:40	HP-Print-40-LaserJet 1102	6	-45 dBm	NONE
a4:17:31:24:a7:de	HP-Print-DE-LaserJet 1102	11	-90 dBm	NONE
24:db:ac:0a:81:9a	MobileWiFi-619a	6	-87 dBm	WPA2
00:c0:ca:76:f9:c5	SoftAP-C5	3	-77 dBm	WPA2
00:24:8c:3d:5b:20	TPE-Free Bus	11	-90 dBm	NONE
18:d1:11:37:28:2c	Yunsing 2F Rear	1	-92 dBm	WPA2
78:44:76:de:2a:48	dlink	11	-81 dBm	WPA2
c8:6c:87:16:9d:ea	stc	1	-91 dBm	WPA

Refresh

After you determine which AP (SSID) to join, you can click on the **BSSID** column your want to choose. The system will automatically join the SSID you specified after reboot.



Wireless Security –

WEP is a basic encryption method, which is not as secure as WPA. To use WEP as a client, you will need to enter a transmit key and a level of WEP encryption exactly the same as the Access Point.

- **Auth Type:** Select an authentication method. Options are **Open System** or **Shared Key**. An open system allows any client to authenticate as long as it conforms to any MAC address filter policies that may have been set. All authentication packets are transmitted without encryption. **Shared Key** sends an unencrypted challenge text string to any device attempting to communicate with the Access Point. The device requesting authentication encrypts the challenge text and sends it back to the Access Point. If the challenge text is encrypted correctly, the Access Point allows the requesting device to authenticate.
- **Input Type:** Select **Hex** or **ASCII** from the drop-down list.
- **Key Length:** Select a key format from the drop-down list. 40/64bit-hex keys require 10 characters or ASCII keys require 5 characters, where as 104/128-bit-hex keys require 26 characters or ASCII keys require 13 characters, as 128/152-bit-hex keys require 32 characters or ASCII keys require 16 characters. A hex key is defined as a number between 0 through 9 and letter between A through F.
- **Default Key:** You may use up to four different keys for four different networks. Select the current key that will be used.
- **Key table** – You can enter 4 different WEP encryption keys into the table and by choosing the radio button to decide which one is valid now. The AP supports 64, 128 and 152bit key length. The longer key we choose usually means the encryption is stronger.

Be sure to click **Apply** to save all settings.

300Mbps Wireless Broadband Access Point

Wireless Client

- Status
 - System Summary
 - Connection Status
 - Throughput
 - Event Log
- System
 - System Settings
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics
 - System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 47

Wireless Security

Security Mode	WEP
Auth Type	Open System
Input Type	Hex
Key Length	40/64-bit (10 hex digits or 5 ASCII char)
Default Key	1
Key1	<input type="text"/>
Key2	<input type="text"/>
Key3	<input type="text"/>
Key4	<input type="text"/>

WPA-PSK stands for Wi-Fi Protected Access – Pre-Shared Key. WPA-PSK is design for home users who do not have RADIUS server in their network environment. WPA can provide better security level than WEP without difficult setting procedure.

- **Encryption** – there are two encryption methods: **TKIP** and **AES**, with dynamic encryption keys.
- **Passphrase Key** - Enter a WPA Shared Key of 8-63 characters. The Shared Key should be also applying the Access Point work in the same wireless network.

Be sure to click **Apply** to save all settings.

300Mbps Wireless Broadband Access Point

Wireless Client

Status

- System Summary
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting


Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 47

Wireless Security

Security Mode	WPA-PSK
Encryption	AES
Passphrase	(8 to 63 characters) or (64 Hexadecimal characters)

Wireless Configuration – Repeater Mode

When you set the device to Repeater mode, the device is able to talk with one remote access point within its range and retransmit its signal. In order to setup the device to work in such mode, you need to choose **Repeater** and click **Apply** in System Settings page. Please reboot the device to make sure it works in repeater mode.



300Mbps Wireless Broadband Access Point

Repeater

System Settings

Device Name	MIMO CLIENT (1 to 32 characters)
Country/Region	Please Select a Country Code
Operation Mode	<input type="radio"/> Access Point <input type="radio"/> Wireless Client <input type="radio"/> Pt(M)P Bridge <input checked="" type="radio"/> Repeater

Apply Cancel

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System


- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset



After enable the repeater mode, you can click **Wireless Network** and choose **Site Survey** to pick one of the SSIDs you would like to retransmit its signal (please be awarded that while using the repeater mode, the throughput performance maybe nearly only half compare with access point mode. Because the repeater needs to communicate with original AP and also the clients associate to the repeater at the same time).

300Mbps Wireless Broadband Access Point

Repeater

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- **Wireless Network**
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 01

Wireless Security

Security Mode	Disabled
---------------	----------

Wireless Access Point

Repeater

Status

- System Status
- Wireless Station List
- Connection Status
- Event Log

System Configuration

- System Properties
- IP Settings
- Spanning Tree Settings

Wireless Setup

- **Wireless Network**
- Wireless Security
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log

Site Survey

i:Infrastructure Ad_hoc

BSSID	SSID	Channel	Signal	Type	Security	Network Mode
00:c0:ca:60:32:a2	Generic	7	-72 dBm	G	NONE	i
00:11:a3:1b:8fd8	Generic1	9	-20 dBm	G	NONE	i
1c:af:f7:e0:c5:25		3	-26 dBm	G	WPA2	i

After **Site Survey**, you can choose the Access Point you need to extend its range by clicking **BSSID** column. Then click **Apply** to make sure system working properly with new setting.

After all the changes are made, you can check the **Connect Status** page to check current SSID and link quality / signal strength.

The screenshot shows the web interface for a 300Mbps Wireless Broadband Access Point. The main title is "300Mbps Wireless Broadband Access Point". On the left, there is a navigation menu under the heading "Repeater". The menu items are categorized into "Status", "System", "Wireless", and "Management". The "Status" section includes "System Summary", "Wireless Station List", "Connection Status", "Throughput", and "Event Log". The "System" section includes "System Settings", "IP Settings", and "Spanning Tree Settings". The "Wireless" section includes "Wireless Network", "Wireless MAC Filter", and "Wireless Advanced Settings". The "Management" section includes "Administration", "SNMP Settings", "Backup/Restore Settings", "Firmware Upgrade", "Time Settings", "Log", "Diagnostics", and "System Reset".

The main content area is titled "Connection Status" and displays a table with the following information:

Wireless Client Type	Universal Client
SSID	Generic
BSSID	00:23:28:24:04:01
Connection Status	Associated
Wireless Mode	802.11g/n HT20
Current Channel	2437MHz (Channel 6)
Security	Disabled
Tx Data Rate(Mbps)	5.5
Current noise level	-95 dBm
Signal strength	-36 dBm

Below the table is a "Refresh" button.

Wireless Security –

The wireless security settings configure the security of your wireless network. There are three wireless security mode options supported by the Access Point: **WEP**, **WPA-PSK**, and **WPA2** (WPA stands for Wi-Fi Protected Access, which is a security standard stronger than WEP encryption. WEP stands for Wired Equivalent Privacy).

In Wireless Security page, you can configure the AP to work with **Disabled** (no Security), **WEP**, **WPA-PSK**, and **WPA2** security mode. Once you setup the AP to work in security mode, all wireless stations will also need to have corresponding settings. System default setting is **Disabled**.

300Mbps Wireless Broadband Access Point

Repeater

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 01

Wireless Security

Security Mode	Disabled Disabled WEP WPA-PSK WPA2-PSK
---------------	--

WEP is a basic encryption method, which is not as secure as WPA. To use WEP, you will need to select a default transmit key and a level of WEP encryption.

- **Auth Type:** Select an authentication method. Options available are **Open System** or **Shared Key**. An open system allows any client to authenticate as long as it conforms to any MAC address filter policies that may have been set. All authentication packets are transmitted without encryption. **Shared Key** sends an unencrypted challenge text string to any device attempting to communicate with the Access Point. The device requesting authentication encrypts the challenge text and sends it back to the Access Point. If the challenge text is encrypted correctly, the Access Point allows the requesting device to authenticate.
- **Input Type:** Select **Hex** or **ASCII** from the drop-down list.
- **Key Length:** Select a key format from the drop-down list. **40/64-bit (10 hex digits or 5 ASCII char)** require 10 characters or ASCII keys require 5 characters, while **104/128-bit (26 hex digits or 13 ASCII char)** requires 26 characters or ASCII keys require 13 characters, and **128/152-bit (32 hex digits or 16 ASCII char)** requires 32 characters or ASCII keys require 16 characters. A hex key is defined as a number between 0 through 9 and letter between A through F.

- **Default Key:** You may use up to four different keys for four different networks. Select the current key that will be used.
- **Key table** – You can enter 4 different WEP encryption keys into the table and by choosing the radio button to decide which one is valid now. The AP supports 64, 128 and 152bit key length. The longer key we choose usually means the encryption is stronger.

300Mbps Wireless Broadband Access Point

Repeater

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 01

Wireless Security

Security Mode	WEP
Auth Type	Open System
Input Type	Hex
Key Length	40/64-bit (10 hex digits or 5 ASCII char)
Default Key	1
Key1	<input type="text"/>
Key2	<input type="text"/>
Key3	<input type="text"/>
Key4	<input type="text"/>

Be sure to click **Apply** to save all changes.

WPA-PSK / WPA2-PSK stands for Wi-Fi Protected Access – Pre-Shared Key. WPA-PSK is design for home users who do not have RADIUS server in their network environment. WPA can provide better security level than WEP without difficult setting procedure.

- **Encryption** - WPA gives you three encryption methods: **Auto**, **TKIP** and **AES**, with dynamic encryption keys.
- **PassPhrase** - Enter a WPA Shared Key of 8-63 characters. The Shared Key should be also applying the clients work in the same wireless network.
- **Group Key Update Interval** - Enter a number of seconds which instructs the Access point how often it should change the encryption keys. Usually the security level will be higher if you set the period shorter to change

encryption keys more often. Default value is 3600 seconds, set 0 in Group Key Update Interval to disable key renewal.

Remember to click **Save** to make sure all changes are made before leaving this page.

300Mbps Wireless Broadband Access Point

Repeater

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 01

Wireless Security

Security Mode	WPA-PSK
Encryption	AES TKIP
Passphrase	(8 to 63 characters) or (64 Hexadecimal characters)

300Mbps Wireless Broadband Access Point

Repeater

Status

- System Summary
- Wireless Station List
- Connection Status
- Throughput
- Event Log

System

- System Settings
- IP Settings
- Spanning Tree Settings

Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings

Management

- Administration
- SNMP Settings
- Backup/Restore Settings
- Firmware Upgrade
- Time Settings
- Log
- Diagnostics
- System Reset

Wireless Network

Wireless Setting

Wireless Client Type	<input checked="" type="radio"/> Universal Client <input type="radio"/> WDS Client
Wireless Mode	802.11g/n HT20
SSID	Generic (1 to 32 characters) <input type="button" value="Site Survey"/>
Prefer BSSID	<input checked="" type="checkbox"/> 00 : 23 : 28 : 24 : 04 : 01

Wireless Security

Security Mode	WPA2-PSK
Encryption	AES TKIP
Passphrase	(8 to 63 characters) or (64 Hexadecimal characters)

Appendix A: Notice

Please refer to the following system grounding diagram for your installation reference.

When in doubt, refer to the NEC code to determine proper grounding techniques.

For detailed information regarding grounding the outdoor wireless system.

