


## Contents

### AR-888 Series



### FCC Statement (part15.21,15.105)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:




- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.—Consult the dealer or an experienced radio/TV technician for help.

(FCC part 15.19) : This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Installation

- Take off two Iron bars from the of bottom body **A** and and mounting plate **B**. Pull the cables from the square holes of the eva foam gasket and mounting plate.
- Use a screwdriver to screw the eva foam gasket **C** and mounting plate **B** onto the wall with Flat Head Cap Philips Tapping Screws (Excluded, the Installer should prepare before installation. **The screws shall not be screwed too tight, or it could lead to the deformation of the mounting plate.**)
- Connect the cables to the backside of body **A** and attach **A** to **B**. To fix **A** on **B** by inserting two iron bars from the bottom of **A+B**.
- Attach the Back Cover **D** to **A**. Use the Allen key and screws to assemble the Back Cover onto the body.
- **Hands-off and clear any objects around the 888 (H/K)**. Turn on the power and LED will light-up and beep will sound. Wait the Touch IC start for 10 sec. to operate.



## Basic Commands

Enter program mode

\* 123456 #

Change program code

Input 6-digit PWD twice

09 \* 654321654321 #

Add Card User

(Please list down each User Address and its Card ID)

User Range: 00000~03000

M4/M8 Mode

19 \* 00001 \* 00001 #

M6 Mode (Must set up 17'0000#)

22 \* 1 #

Ex.: 00001 start user address at 00001 and scanned 50 pcs of card one by one; next time, input 19\*00051\*00001#

Attach/Present Card One by One

Add PIN User

PIN=0000 (Disable)

M4/M8 Mode (4/8 beeps while entering program mode)

12 \* 00001 \* 1234 #

M6 Mode (6 beeps)

15 \* 1234 #

Add Card+PIN User

PIN=0000 (Disable)

M4/M8 Mode

13 \* 00001 \* 4321 #

M6 Mode

17 \* 4321 #

Set up Door Relay Time

TTT: 001~600=1~600 sec.  
601~609=0.1~0.9sec.  
000=On/ Off (Latch)

02 \* 007 #

Set up Door Close Time

TTT: 001~600=1~600 sec.


18 \* 015 #

Exit program mode

\* #

## Wiring Diagrams

### • Alarm Output 3-Lift Control Wiring



Ex. Assign user address 1 to access to 1, 3, 5, 7 floor

21\*00001\*0\*01010101#

Enable Life Control

24 \* 002 # (Enable)  
24 \* 000 # (Disable)

Assign Users (Single Floor)

27 \* UUUUU \* FF #

UUUUU=User Address=00000~03000

FF=Floor number=1~32

Assign Floor User (Multi-Floor)

21 \* UUUUU \* S \* FFFFFFFF #


S=Set=0~3

FFFFFF=0 (Disable) / 1 (Enable)


Occupied Alarm Output to support

28 \* 064 # (Enable)  
28 \* 128 # (Disable)

### • Alarm Output 2- WG Dual Door Control Wiring



### • Alarm Output 1- Alarm Wiring




Enable Door Open Too Long Alarm

Enable Arming while exit program mode \* \* #

Stop Alarm by Push Button

24 \* 064 # (Enable)  
24 \* 000 # (Disable)


### • Exit Button Wiring



### • Door Sensor Wiring



### • Door Lock Wiring



### • WG Reader Wiring



### • Networking Connection Wiring



### Set up Node ID

Ex. Node 32 connected to PC

00 \* 032 \* 032 \* 032 #

Ex. Node 9 connected to 716E

00 \* 009 #

032=Node ID of Access Controller

032=Virtual 716E Node ID

032=Door number

(All Range:001~254)

009=Node ID of Access Controller

Range: 001~254