



7" TABLET

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device.

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MODEL: PHP_V710R USER MANUAL

Preface

Thank you for buying the MID. We wish you enjoy using it.

Please read and retain all the operating instructions before operating the unit, we do not assume any liability arising out of improper operation or incidental damages.

For better services, the content of this operation manual may be changed.

If the actual setup and usage of the unit are different from this operation manual, please view the website of our company to inquire about the latest product information.


Do not allow water or foreign objects to enter the unit.

I. Note:

- Avoid the unit being dropped. Avoid the display been shake seriously, or the display will be damaged or unusual.
- 2. Do not use metal object to touch the device to prevent it from short circuit.
- Please backup your data in case your important data is lost, especially before you upgrade the firmware. The company will not take charge in any loss that caused by lost of data.
- Do not disassemble. Do not wipe the surface of the unit by alcohol, thinner or benzene.
- Do not disconnect the unit while it is formatting or uploading/downloading, or the procedures may lead to errors
- We do not take responsibility to the flash damage caused by product broken, repair or other reasons. Please operate strictly as per the user guide.
- 7. Avoid water or foreign objects enter the unit.

- 8. Do not use the unit in places that are extremely hot, cold, dusty, or humid.
- Avoid the unit being dropped. Avoid the display been shake seriously, or the display will be damaged or unusual.
- 10. Specifications are subject to change and improvement without notice

II. Introduction of cover:



Power on/off

- 2. Volume+, Volume -
- Earphone Jack
- Reset
- 5. IR
- Micro USB interface
- Back Camera
- 8. TF-CARD interface
- Loudspeaker
- 10. Front Camera

III. Operation Instruction

1. Basic Operation

1.1. Power on/Power off

Power on:

Press and hold the power switch for 5 seconds; the unit displays the start-up logo and enters the working mode.

Power off:

Press and hold the power switch for 3 seconds to turn the unit off.

Sleep:

While the device is at working status, press the power switch, it enters the sleeping mode, and the screen will be off then. Press the power switch again, it shift to the normal mode. You may use this function when you don't' use the device temporary to save power.

1.2. Charging

When the device prompts low battery, please charge it by provided charger.

Note:

To improve the longevity of the battery, you may charge for another 15 minutes after it prompts the battery is full.

1.3. Main menu

Click the icon in the main interface, the main menu is appeared. It including the system setting, music playback, video playback, web browser and other applications you installed in the main menu.

2. Settings



Settings "in the main interface to enter the setting interface. Click the

Corresponding setting items to operate.



2.1. Date and Time Setting

Click "Date & Time" in the setting interface to set the date and time. You may set The date, time zone, time, time format and date format etc. in the menu.



2.2. Brightness

Select "Display" in the setting interface. Click "Brightness" to enter, and slide the

bar to adjust the brightness.



3. Wi-Fi connection

Click "Settings" in the main interface and click "Wireless & network" to enter the wireless and network setting interface. Click Wi-Fi to turn on the WIFI. Click Wi-Fi setting to set and manage wireless access.

3.2 Bluetooth


Turn on the Bluetooth, Click Bluetooth setting to set and manage Blutooth Devices access. Click "SEARCH FOR DEVICES", it lists the open devices. Click the name of the devices; it pops up the setting window. choose the device, pairing it, then you can transfer pictures, movies, music etc with it.

3.3 Ethernet configuration

The Unit support USB-Net-Card

3.4

Click "Network Notification", it lists the open network it searched. Click the name of the network; it pops up the setting window. You may connect it to WIFI according to the prompts. You need to input the user name and password if networks are encrypted.



4. Explorer to install App

4.1 Install

There are many ways to install applications under Android, such as via USB, by third party program. We introduce installation by Apps Installer here.

Click the "File Manager" in the main interface .

Select the APK file you want and enter the application installation interface. Click "Install" to install the application automatically. After installation, it prompts "Open" and "Finish". Click "Open" to open the application. Click "Finish" to exit.

4.2 Uninstall

You may use the corresponding third party software management tool or the installed application management software of the device to install applications.

Select "Setting/Applications/Manage applications" to select the installed applications and check the attribute of it or uninstall it.

5. Connect to internet

- **5.1.** After connecting with WIFI, open the browser and input the web address, you can browse the web then.
- **5.2.** Click the icon to enter the bookmark to view the browse history. Click the web page you want to open it.


To save the web page into bookmark, you may click to enter and click "add"

to save it.

6. Audio and video playback

6.1. Audio playback

Click the "Music" in the main menu to enter the audio playback interface. It lists the audio files in the device, and you may click the file name to play it. In the audio playing interface, click the icons to play/pause/ increase volume/ decrease volume/ FF/ REW....



6.2. Video Playback

Click the "UHD Player" in the main menu to enter the video playback interface. It lists the video files in the device, and you may click the file name to play it. In the video

playing interface, touch the screen to pop-up the operation icons and click the icons to

play/pause/ skip to next file/skip to previous file....



7. Picture viewing

Click "UHD Player" in the main menu to enter the picture folder list. Select and click the folder you want to enter; it displays then clicks the thumbnail of the picture to view it.

Touch the screen to pop-up the operation icons while viewing the picture, you may zoom in/zoom out/ skip to next picture/skip to previous picture/ rotate/ delete the picture...





8. 3G DONGLE


Select "Access Point names", after your 3G dongle Activates, then your 3G Dongle will be selected automatically or you can view list of network name.



Note: $\overline{3G}$ dongle is not in the package of tablet

9. Camera

Click "Camera" in the main interface.



9.1 Camera

If the cursor is at position, the device is at Camera mode.

Click to take picture.



Click to set the scene mode, Picture size, Picture quality, and color



Click to select back or front camera

9.2 DV



If the cursor is at position, the device is at DV mode.

Click to take picture.

Click to set the color effect or restore to default settings.

10. Connect with external device

10.1. Connect with PC

Connect the device with the PC via the USB cable. The PC appears two new disk


symbols after connected successfully. One is the TF card, and the other is the built-in flash.





10.2. Use of OTG and USB host

It supports the movable device with FAT32 format, such as U disk and MP3. Connect the movable device to the MID. (Note: only OTG could support USB mouse and keyboard, USB HOST only support USB2.0 High speed device)



10.3. Applications

For convenient usage, we installed some third party software in the MID. For detailed operation methods, please check the corresponding instruction. Some of the software may be able to be used in some area because of network service.

10.4. HDMI

The devices support connect to HDMI displayer via HDMI cable(Plug and Play) IV. Troubleshooting

1. What if the device is abnormal during operation?

Answer: 1). Reboot the device to see if it works OK.

- Charge the device by the charger to activate the battery. Make sure it has power before you operate it.
 - 3). It is suggested to upgrade the OS of the device by professional.

2. Why the standby time is so short sometimes?

Answer: the use time of the battery is all depend on the temperature and use instance. If the temperature is too high or too low, the use time of the battery might be effected. It is suggest using the device in normal temperature.

The using time is also affected by increased volume and frequently operation.

VI. Specifications

11. Specifications	
Item	SC-4207

Dimension	190X108X10.5MM
Display	7" 800X480 TFT touch panel
OS	Android 4.4
Input method	Soft keypad
Capacity	4GB
External Capacity	(SD) (TF) card, up to 32GB
Audio	MP3,WMA,FLAC,APP,OGG(support all audio formats)
Video	mpeg4-sp,asp,divx,WMV,RMVB,H.264/1080P (support all video formats)
E-book	Support
Bluetooth	Support BT
HDMI	Support HDMI
Wireless network	Support WIFI
Language	Multi-language
USB	USB2.0 high speed
OTG	Support
Temperature	-20°C to 60°C
Power supply	AC 100~240V 50/60Hz; DC 5V/2A
Battery	3000mAh poly-lithium battery

Note: The pictures list in the manual are for reference only!

The design and the specification of the unit are subject to change without notice.