


3. Diagram



Loop Speaker



Operation Manual

Model:BT LOOP

Contents:

1. Instructions

1.1 Charging the speaker

1.2 Bluetooth Connectivity

1.3 LED light codes

2. Specifications

3. Diagram

1. Instructions

1.1 Charging the speaker

Connect the included USB cable to a computer USB port or USB charger, and to the speaker mini-USB port.

When charging, the LED will illuminate in Red. When battery is fully powered, the LED will turn off.

1. 2 Setting up Bluetooth Connectivity

(before setting up, make sure the speaker is turned on, fully charged, and not already connected to another device)

TO PAIR TO AN ANDROID PHONE

1. Open **Settings**
2. Open **Wireless and Network**
3. Open **Bluetooth Settings**
4. Turn **Bluetooth** on (if it is off)
5. Select **Search for Devices**
6. Select **TOUCHPOINT**
7. Touch **Connect**

TO PAIR TO AN IPHONE OR IPAD

1. Open **Settings**
2. Turn **Bluetooth** on (if it is off)
3. Select **TOUCHPOINT** found under **My Devices**
4. Once paired: it will say **Connected** next to the device name

TO PAIR TO A MAC OS COMPUTER

1. Open **System Preferences**
2. Open **Bluetooth**
3. Click the + button to add a Bluetooth device
4. Select **TOUCHPOINT**
5. Click **Continue** - the computer will pair with the device. If asked, input the passcode **0000**

TO PAIR TO A WINDOWS OS COMPUTER

1. Open **Devices and printers**
2. Click **Add a device**
3. Select **UGO or Bluetooth headset**
4. Click **Next**
5. Input Pass code **0000** if necessary

1.3 LED Light :

Off / Discharged	No light
On / in pairing mode	Blinking blue light
On / connected to device	Blue light (no blinking)

2. Specifications

Output	: 2.2W
Bluetooth version	: v2.1+EDR
Frequency	: 100Hz - 20KHz
Max sound level (dB)	: >85db or $\geq 90 \pm 2$ db
Charging time	: 1.5hrs
Play time at full volume	: continuously approx. 2hrs
THD (Distortion level)	: < 0.5%
DC input	: DC5V
Battery	: Li-Ion

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.