

C313 Series Indoor Monitor User Manual

Akuvox
Open A Smart World



About this manual

Thank you for choosing Akuvox's C313 Series indoor monitor. This manual is intended for end users, who need to use and configure the indoor monitor.

It provides an overview of the most essential functions and features of the product, whose firmware version is 113.0.1.118.rom.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator &you body.

Contact us

For more information about the product, please visit us at www.akuvox.com or feel free to contact us by

Sales email: sales@akuvox.com

Technical support email: techsupport@akuvox.com

Telephone: +86-592-2133061 ext.7694/8162

We highly appreciate your feedback about our products.

Version 1.0, Oct.201

1. Product overview

1.1 Product Description

C313S is a Linux-based IP indoor monitor with a touch screen. It incorporates audio communications, access control sensor arming and obtain video stream from door phone or IPC.

Its finely-tuned Linux OS allows for better suit the habit of usage of local people. Powered by it, C313S's multiple ports, such as IO and Bell ports, can be used to easily integrate external Arming systems, such as bell controller and fire alarm detector, helping to create a holistic control of home safety and access control and giving occupants a great sense of security.

It is applicable to multi-storey residential buildings or villas.




1.2 Power connection

The door phone is powered by simply connecting the two wires of the power adapter to the wiring interface on the back of the indoor monitor.

① Plug the wire printed with white bars to ② the first pin and slightly press it so that it gets locked inside.

③ Plug the wire printed with letters to ④ the second pin and slightly press it so that it gets locked inside.



2. Daily use

2.1 Making a call

There are two ways to make a call from the indoor monitor to other units, which can be another indoor monitor or an intercom app.

2.1.1 Calling from digital keypad

- ① Tap the icon to enter the call interface.
- ② Enter the number to call on the digital keypad, for example number 1001, and ③ tap the dial key, you can choose to m




2.1.2 Calling from phonebook

- ④ Tap the icon to enter the phonebook, or ⑤ tap this icon to enter the phonebook.

- ⑥ Choose a group.


To find a specific occupant, ⑦ scroll up or down the pre-imported contact list, or ⑧ search the list by number or alphabet. C313S supports fuzzy matching query

- ⑨ Choose either a room number, an occupant's name, or the combination of both,
- ⑩ Tap the dial key next to the contact found.



2.1.3 Callingresident

- ①Press the icon to enter the call resident interface.
- ②Enter the room number you want to call, for example, if you want to call the community1,Building 1, Unit 1, Floor 1, Room1;enter 001001010101, and then ③press dial key. You can choose the audio call or video call.



2.1.4 Calling from callog


- ①Press the icon to enter the call log interface.
- ②You can choose missed call log or all of the call log
- ③Choose a log to check, or ④you can also choose audio or video call to call out.
- ⑤Press the icon to delete the selected call log.
- ⑥Press the icon to delete all of the call log.
- ⑦Press the icon to add selected caller into phonebook.

2.1.5 Callingdoorphone

①Press to make a call out, if you want to call doorphone unit.

2.1.6 Callingcenter

②Press to make a call out., if you want to call management center (SDMC system).



2.2 Receiving a call

2.2.1 Receive a incomingcall

①There will be a video preview in this window, when you receive a incoming call;


②Press this icon to answer the incoming call;

③Press this icon to ignore this incoming call; it will go back to the desktop.

④Press this icon to capture the video preview, the screen shot will saved into Album.


⑤Press this icon to open the door.

⑥Press "+"/"" to adjust the ringtone volume.



2.2.2 during the session


- ①Press the icon to hang up this session.
- ②Choose capture to get a screenshot and save it into Album.
- ③Press this icon to open the door for caller.
- ④Press "+"/"" to adjust the speaker volum.



2.3 Contact

2.3.1 LocalPhonebook



- ①Press the icon to delete the selected group.
- ②Press the icon to delete all groups.
- ③Press the icon to add a group.
- ④Press the icon to modify the selected group.



2.3.1.1 Add agroup

Enter the phone book interface, you can ①press the icon to add a group.


- ②Type in the goup name.
- ③Choose a ring tone for this group.
- ④Press this icon to save the group.
- ⑤Press the icon to exit adding a group.



2.3.1.2 Managecontacts




Enter the contacts interface, you can ①press the icon to make a audio/video call to the selected contact.

- ②Press the icon to delete the selected contact.
- ③Press the icon to delete all fo the contacts under this group.
- ④Press this icon to add a contact
- ⑤Press this icon to modify the selected contact.



2.3.1.3 Add a contact

- ① Select a group, to check the contacts in this group.
- ② Press the icon to add a contact.
- ③ Type in the contact name.
- ④ Type in the number 1, it must be a room number.
- ⑤ Type in the number 2, it can be a SIP number or IP number.
- ⑥ Select a special ring tone for this contact.
- ⑦ Select a group for this contact
- ⑧ Press this icon to save the contact.
- ⑨ Press this icon to exit adding contact.




2.3.2 Communityphonebook

Once C313s connected to the SDMC system, it will get the community phonebook automatically.

①Choose a contact to check his office number or mobile number.

②Choose a number and ③press dial key to dial the corresponding contact, you can choose audio call or video call.

Note: The community phonebook is managed by the property worker, so you cannot manage it by yourself.




2.4 Status

2.4.1 Basic Status

To check C313S's status by ①pressing this icon.


After entering the status interface, it shows the basic status as default. You can check the IP address, MAC address, firmware version and device number here.



2.4.2 NetworkStatus

①Press the icon to check the network status.

You can check the LAN type, LAN IP, subnet mask, gateway and DNS here.




30-11-2017 08:43:52 AM

Status

Network

LAN Type	DHCP
LAN IP	192.168.35.19
LAN Mask	255.255.255.0
Gateway	192.168.35.1
DNS1	192.168.35.1
DNS2	

①




30-11-2017 08:44:18 AM

Status

Phone

Model	C313
Hardware	113.0.0.0.0.0.0
Firmware	113.0.1.118

②



5-12-2017 11:14:39 AM

Status

Account

10011	Registered
(Empty)	Disable

③

2.4.3 PhoneStatus

①Press the icon to check the phone status.

You can check model, hardware and firmware information here.


2.4.5 Account Status

①Press the icon to check the phone status.

You can check model, hardware and firmware information here.

2.5 Monitor


①Press the icon to receive the video from indoor IPC or community IPC any time.



2.5.1 DoorPhone

②By entering the monitor interface, it is door phone list by default.

You can receive video from predefined doorphone station which you set under the path "Setting-Advance- Door Station"




2.5.2 WebCamera

③Press the icon to enter the web camera list.

④Press this icon to delete all of the web cameras.


⑤Press this icon to add a web camera, you need to set the device name and rtsp URL of the web camera.



2.5.3 WebCamera(Detect)


① Press the icon to enter the web camera(detect) list. C313S will detect available web camera via ONVIF protocol automatically.


② Choose a URL to get the corresponding video. You need to enter the username and password for access.



2.6 Message(s)

③ Press the icon to enter the message(s) interface. There will be a label notification at top right corner when there is a new message.





2.6.1 Notices

By entering the message(s) interface, it is notices list. You can check the message(s) you received from management center or other residents.


①Press this icon to delete all messages.

②Select a message to check, or you can delete the selected message by long press.

③By pressing a message, you can check the corresponding received time and ④context.

⑤Press this icon to reply corresponding message.

⑥Press this icon to back to notices list.



2.6.2 Sent

①Press this icon to enter the sent list. You can check the sent log here.

②Press this icon to delete all sent log.

③Select a message to check, or you can delete the selected message by long press.



④Press this icon to create a new message.

⑤This option is to set the destination. If you want to call community 1, building 1, unit 1, floor1, room 1, you need to enter 1.1.1.1.1.

⑥This option is to modify your message context.

⑦Press the icon to send the message to the predefined destination.


⑧Press the icon to cancel and back to sent list.



2.6.3 Maintenance

①Press this icon to enter the maintenance list. The maintenance message will be sent to the property management center so that you can ask for help.

②Select which problem you are facing . And press confirm when you see the prompt. For example, if the light doesn't work, you can click Light column, then click confirm label to ask for help.



2.6.4 CaptureLog


③Press this icon to enter capture log list.


④Press this icon to delete all capture log.

⑤Choose a log to check the capture.

⑥Press left/right key to check the previous/next capture.

⑦Press this icon to back to capture log list.





2.7 Arming

①Press the icon to enter the Arming interface.

②C313S supports 4 mode, they are indoor mode, sleeping mode, outdoor mode and disarm mode.

2.7.1 ArmingMode

③Press this icon to enter the arming mode settings interface.

④You can see all of the 8 zones and corresponding types (slide down to check more information) in this interface.

⑤Press this icon to set the defend delay time. It means when you change to the arming mode from other modes, there will be 30 seconds delay time.

⑥Press this icon to set the alarm delay. It means when the sensor triggered, there will be 90 seconds delay time to announce the notification.

⑦Tick/untick to enable/disable the corresponding zone under the selected mode.


⑧Press save icon to save the modification.

The Arming Settings interface consists of two main screens. The top screen, titled 'Arming Settings' (timestamp: 8-12-2017 10:45:26 AM), displays four modes: Indoor (grey), Sleeping (grey), Outdoor (grey), and Disarm (red). Each mode has a shield icon. Below these are four buttons: 'Arming Mode' (grey), 'Disarm Code' (grey), 'Alarm Log' (grey), and 'Zone Status' (grey). The bottom screen, titled 'Arming Mode' (timestamp: 12-12-2017 05:34:25 AM), shows the configuration for the 'Indoor' mode. It lists four zones: Zone 1 (Bedroom, Smoke, checked), Zone 2 (Bedroom, Urgency, checked), Zone 3 (Bedroom, Gas, checked), and Zone 4 (Bedroom, Infrared, checked). Each zone row has a 'Defence delay' and 'Alarm delay' field. A red box highlights the 'Zone 1' row, and a red number '4' is to its left. A red arrow points to the 'Save' icon in the top right of the bottom screen.



2.7.2 DisarmCode

- ① Press this icon to enter the disarm code settings interface. You can modify the disarm code here.
- ② Enter the old disarm code first, it is 0000 as default.
- ③ Enter the new disarm code
- ④ Enter the new disarm code again for confirming.
- ⑤ Press save icon to save the modification



2.7.3 AlarmLog

①Press this icon to enter the alarm log interface. You can see the alarm log here including location, zone, zone type and alarm time.

②Press this icon to delete the selected alarm log.

③Press this icon to delete all alarm log.



8-12-2017 11:50:40 AM

Alarm Log 1/17

No.	Location	Zone	Zone Type	Time
1	Bedroom	Local Zone 3	Gas	2017-12-07 12:49:16
2	Bedroom	Local Zone 3	Gas	2017-12-07 12:49:05
3	Bedroom	Local Zone 3	Infrared	2017-12-07 12:48:49
4	Bedroom	Local Zone 3	Infrared	2017-12-07 12:47:51
5	Bedroom	Local Zone 3	Infrared	2017-12-07 12:47:47
6	Bedroom	Local Zone 3	Infrared	2017-12-07 12:47:43
7	Bedroom	Local Zone 3	Infrared	2017-12-07 12:47:39
8	Bedroom	Local Zone 3	Infrared	2017-12-07 12:47:36

2.7.4 ZoneStatus

④Press the icon to enter the zone status interface.

You can check the status of every zone, including location, zone type, trigger mode and status.

About zone settings , please refer to "Settings---> Advance Settings--->Zone Settings"

12-12-2017 04:18:44 AM


Zone Status

Zone	Location	Zone Type	Trigger Mode	Status
Zone 1	Bedroom	Smoke	NC	Enabled
Zone 2	Bedroom	Urgency	NO	24H
Zone 3	Bedroom	Drmagnet	NC	Enabled
Zone 4	Bedroom	Infrared	NC	Disabled
Zone 5	Bedroom	Infrared	NC	Disabled
Zone 6	Bedroom	Infrared	NC	Disabled
Zone 7	Bedroom	Infrared	NC	Disabled
Zone 8	Bedroom	Infrared	NC	Disabled

3. Settings

3.1 Basic Settings

① Press the icon to enter the basic settings interface.



3.1.1 Display settings

By entering the settings interface, it is display settings interface as default.


You can set the brightness for screen, you can adjust it from 1 to 10, it is 5 as default, the bigger value means the lighter screen.

You can also set the sleep delay time and whether to enable the screen saver. The sleep delay time is 30 seconds as default .

3.1.2 Sound settings

② Press this icon to enter the sound settings interface.

You can set Ring Tones for incoming call, even to set a special Ring Tone for door unit, or set the Ring Volume, Talk Volume and MIC Volume. You can also choose whether to enable the Touch Sounds here.




3.1.3 Timesettings

①By pressing this icon to enter the time settings interface.

Setup the date and time in the corresponding area.

Enable NTP (Network Time Protocol), the phone will get the Date and Time automatically. And users can also setup NTP server. Setup a suitable Time Zone , Time format and Date Format.

If user don't use NTP function, you need to configure date and time manually.



3.1.4 DND(Do Not Disturb)settings


②By pressing this icon to enter the DND settings interface.

This function is used to prevent the phone from disturbing. Go to Setting-DND. if open DND, external phone call is unable to call in, turned off by default.

③Enable/Disable DND function.

④Enable/Disable the IVR(Interactive Voice Response).

⑤Select valid time of DND. Use Whole day by default.Users can also setup the accurate Start and End time.



3.1.5 Album


By pressing "Album" to enter the Album interface.

To check all local pictures in album. Users can also play the photos as a digital photo frame.

①Press these 2 icon to check previous/next picture.

②Press this icon to play the photos.

③Back to settings interface by pressing this icon.



3.1.6 System Settings

④Press the icon to enter the System interface.

⑤You can choose Reboot icon to reboot the C313S, click Confirm when you see the prompt. The phone will reboot.

⑥Press the icon to clean the C313's screen, it will keep you from misusing.

⑦Choose a suitable Language for C313S, it is English as default.

