



8" WiFi Digital Photo Frame with Touchscreen LCD Display

Instructional Manual



Table of Contents

Frame Features	04
Frame Control Close-up	06
Package Contents	07
Getting Started	07
Operating Instructions	
Connecting to a wireless network.....	08
Link your frame to your Facebook, Twitter or Photo Partner App.....	09
<i>Facebook</i>	09
<i>Twitter</i>	13
<i>Photo Partner</i>	16
Main Menu Function	
Main Menu	21
Album Function	
Album Settings	22
System Function	
System Settings	24
Alarm Function	
How To Set Alarm	26

Table of Contents


Technical Support	27
Radio and TV Interference Statement	28
Warranty	29

Frame Features







- | | | |
|----------------------|----------------------|-----------------|
| ❶ 8" LCD Touchscreen | ❹ Mini USB Port | ❺ Security Lock |
| ❷ Black Frame | ❺ Power Button | ❻ Wall Mount |
| ❸ SD/SDHC Card Slot | ❻ Directional Keypad | |
| ❹ USB 2.0 Ports | ❼ Menu Button | |
| ❺ Power Adapter | ❽ Frame Stand | |


A Connect a USB hard drive, USB flash drive or SD/SDHC card to easily access and share your favorite pictures, music, or videos.

B Transfer and store files quickly and easily from your personal computer to the frame's 8GB built-in memory with hi-speed USB 2.0.



Frame Control Close-Up

- 1 -  Power On / Off
- 2 - Menu
 - (a) Press to return to previous screen
 - (b) Press & hold to return to Main Menu
- 3 -  Play / Pause
 - (a) Press to select option on Main Menu
 - (b) Press to pause slideshow, music or video
- 4 -  Up Arrow
 - (a) Press to navigate UP when selecting options
 - (b) Press to select Previous file (Photo & Music mode)
 - (c) Press & hold to Fast Forward
- 5 -  Down Arrow
 - (a) Press to navigate DOWN when selecting options
 - (b) Press to select Next file (Photo & Music mode)
 - (c) Press & hold to Scan Backward
- 6 -  Left Arrow
 - (a) Press to navigate LEFT when selecting options
 - (b) Press & hold to lower volume
- 7 -  Right Arrow
 - (a) Press to navigate RIGHT when selection options
 - (b) Press & hold to increase volume



Package Contents

Your order has been carefully packaged and inspected. The following accessories should be included in your package. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact us immediately for assistance.

- Power Adapter
- Frame Stand
- Registration Card
- Quick Start Guide

Getting Started

- Screw in the frame stand
- Plug in the power adapter

Operating Instructions

Step 1: Connecting to a wireless network

AWDMPF208F scans for available Wi-Fi networks and displays the names of those it finds when it is powered on when it is powered on. Secured networks are indicated with a Lock icon. If AWDMPF208F finds a network that you connected to previously, it connects to it automatically. If not:

1. Touch the Network you want to connect to
2. Use the keyboard to enter the Password
3. Touch Connect
4. Touch > to continue to next step


Operating Instructions

Step 2: Link your frame to your Facebook, Twitter or Photo Partner App

Facebook

How to link the frame to you Facebook account so that pictures from your Facebook page will show automatically on the frame after you post it.

1. You can either scan the QR Code on the frame using your smart phone or type <https://m.facebook.com/AWcloudalbum/> on a browser or mobile device using any device.
2. Click on "USE APP".




Operating Instructions

Please login to your Facebook account so that the Wifi Frame can be linked. All pictures after the binding process will be pushed directly to the Wifi Frame after it is posted on your Facebook account.

3. Click on “Authorization and logging”.



4. Please login to your Facebook account. If you are already logged in on this computer, you will not need to login again and you will be directed to the next step directly.




Operating Instructions


5. Go to Settings>Device Info from the frame's main menu.

For RM Name, create a nickname for your frame to easily identify which frame is which in case you have more than one wifi frame. After you have filled out both fields, please click "TO Bind".

6. You will see below message after the request is sent.



The screenshot shows a web page titled "Binding Equipment". It contains the following text: "This page is for users to bind their digital photo frame to their Facebook account. Please fill in the UN Code (the unique ID of the photo frame can be found under Device Info menu in Settings) and click [To bind] button." Below this, it says: "If the UN Code is valid, a confirmation message will be sent to your photo frame." and "If the UN Code is not valid, an error message will be shown. Please double check the UN Code entered." There are two input fields: "UN Code" and "RM Name". Below the "RM Name" field, it says "The nickname name of the photo frame". At the bottom, there is a blue button labeled "TO bind" and a link "To the Settings".



For users to bind their digital photo frame to their Facebook account. Please fill in the UN Code (the unique ID of the photo frame can be found under Device Info menu in Settings) and click [To bind] button.


If the UN Code is valid, a confirmation message will be sent to your photo frame.

If the UN Code is not valid, an error message will be shown. Please double check the UN Code entered.

Operating Instructions

7. You will then see the below confirmation message. You will also receive a message on the frame showing that your facebook account is linked to the frame.

8. Congratulations! Your Facebook account is now linked to the frame. From now on, every picture that you post to your Facebook will be pushed to the WiFi Frame directly without any extra steps.



Operating Instructions

Twitter

How to link the frame to your Twitter account so that you can post picture directly from your Twitter account to the frame.

1. You can either scan the QR Code on the frame or type:

<https://twitter.com/CloudAlbum/>
in your browser

2. Click on "Follow".



Operating Instructions

3. Please login to your Twitter account. If you are already logged in on this computer, you will not need to login again and you will be directed to the next step directly.

Join Twitter today.


Sign up

4. Click “Message” to send a private message to link the frame.




Operating Instructions

5. Type 'bd+device serial no' to bind. For example, if the device serial number is 1234567890, please type bd1234567890 in the message. Once the binding is successful, you will see a reply from the Cloud Frame for the confirmation.



6. Congratulations! Your Twitter account is now linked to the frame. To post a picture to your frame, you can just send a private message to the frame like below.




Operating Instructions

Photo Partner

How to link the frame to Photo Partner app so that you can send picture/video directly from your tablet or smart phone.


1. You can either scan the QR Code on the frame or search for “Photo Partner” in either Google Play or iTunes store.
2. Once it is downloaded, please start the app by tapping “Photo Partner”.
3. Tap on “Bind Device”.



Operating Instructions


4. Please input the UN serial number. You can find the 10 digit UN serial number under **Settings>Device Info** in the main menu of the frame.

5. Tap on Bind. Once the process is complete, you can verify it under when you tap on "Device Manager" A popup message will also be shown on the frame.



Operating Instructions

6. Congratulations! Photo Partner app is now linked to the frame.



Operating Instructions

To post picture from the Photo Partner to the frame, please follow below steps.


A. Tap on “Gallery”.

B. Select the picture or video that you want to send to the frame.




Operating Instructions

- C.** Tap on “Confirm” on the bottom of the screen to confirm the picture selection.
- D.** Select the Photo quality of either SD or HD.
- E.** You can also add text to the picture by tapping on the photo and type in the text.
- F.** Tap on “Send” to send the picture/pictures to the frame. You will see a status bar on the main menu to see the progress. You may also check by tapping “Message”.



Main Menu Function


Main Menu



Album Function

Album Settings

1. From the main menu, tap on “Settings”.
2. Tap on “Album Settings”.



Album Function

Slideshow: if enabled, the slideshow will start automatically. The slideshow will display pictures from the cloud media folder unless you are in the thumbnail page of the Internal memory or USB/SD Card folder then the slideshow will show pictures in those folders only.

Set music path: Set to play music files from the internal memory or USB/SD card slot.

Background Music Mode: Set background music playlist.

Slideshow mode: Slideshow transition effect.

Slideshow interval: Slideshow time interval.

Slideshow photo limit: Set the number of pictures in the slideshow.

Auto sleep and wakeup: Enable the auto on/off feature.

Set sleep time: Set the time for the frame to auto power off.

Set wakeup time: Set the time for the frame to auto power on.


Remove all photos: Delete all photos from the cloud media and internal memory folders

Reset all setting: Reset all settings and disconnect all linked accounts without removing pictures in the cloud media and internal memory folders.

System Function

System Settings

1. From the main menu, tap on “Settings”.
2. Tap on “System Settings”.



System Function

Sound: To adjust the media volume and notification volume, enable the touch sounds.

Display: To adjust the brightness of the display.

Date and time: To set the date and time for the frame.


Language: To select the display language.

Factory data reset: Rest all data from the device's internal memory and the inserted SD card.

Alarm Function

How To Set Alarm

1. From the main menu, tap on “Alarm”.
2. To edit an existing alarm, tap on “Edit alarm” or tap “Add alarm” to create a new alarm.
3. Once you have set the days, time and ringtone of the alarm, tap OK to set the alarm.



Technical Support

We are committed to providing the best customer service support. If you need assistance with your Aluratek product, please contact the Aluratek Technical Support department prior to returning this device. Reach out to us in any of the following ways:

E-mail: **support@aluratek.com**

Web: **aluratek.com/helpdesk**

Local (Irvine, CA): **714-586-8730**

Toll free: **1-866-580-1978**

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 Year** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or “warranty void” sticker has been removed or altered on the product.

This warranty does not cover:

- A) Cosmetic damage or damage due to acts of God
- B) Accident, misuse, abuse, negligence or modification of any part of the product.
- C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
- D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement: The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

