






# Smart Vent Installation Guide

## What's in the Box?



A. Smart Vent

B. 2 Mounting Screws

C. 2x C-Cell Batteries

D. Bottom Battery Holder

E. Top Battery Holder

F. Battery Holder Screws


---

## Smart Vent Assembly and Installation

For full instructions, visit [flair.co/welcome](http://flair.co/welcome)


### 1. Attach Bottom Battery Holder

Insert the Bottom Battery Holder into the back of the Smart Vent. Screw in the two Battery Holder Screws. Ensure the screws are fully inserted and snug but **do not over tighten**, as you might strip the plastic.



### 2. Insert Batteries

Unscrew the two front screws and remove the faceplate (if attached). Insert the two C-cell batteries, taking care to note the correct orientation.




### 3. Attach Top Battery Holder

Align the arrow on the Top Battery Holder with the arrow on the Smart Vent body.

Push the Top Battery Holder down over the batteries and screw in both screws (note: screws are pre-inserted into the Top Battery Holder).

If you've installed the Top Battery Holder correctly, you should see the Smart Vent's lights turn on and the louvers move. If you do not see these actions, remove the Top Battery Holder, wait five minutes, and install again.



### 4. Mount or Insert the Smart Vent

#### Floor installation

Place the Smart Vent into the duct opening on the floor.


#### Wall and Ceiling

Insert the Smart Vent into the wall or ceiling. Insert the mounting screws into the mounting slot on the two ends of the vent. Align the screws in the mounting slot with the existing mounting holes in the wall or ceiling.

#### **If the mounting holes in your wall or ceiling are stripped or loose:**

Use drywall anchors (not included) and/or use the alternate mounting holes. If you use the alternate mounting holes, we recommend using drywall anchors and 4 mounting screws (not included).

Take care to ensure that the Smart Vent is securely fixed to the wall or ceiling. If you're unsure how to proceed with installation, contact a local handyman or contracting service. Flair is not liable or responsible for damage or injury resulting from incorrectly installed Smart Vents.




### 5. Attach Faceplate

Attach the faceplate with the two screws. Install any other Smart Vents.

### 6. Digital Installation

When you're finished installing your Smart Vents, you can start digital setup in the Flair App ([flair.co/ios](https://flair.co/ios) or [flair.co/android](https://flair.co/android)). You can also access Flair via the Web App at [my.flair.co](https://my.flair.co). For further installation instructions, please visit [flair.co/welcome](https://flair.co/welcome)



## FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ISED Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## ISED Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

## Models covered by this User Manual:

- VENT 4x10, VENT-4x12, VENT-4x14
- VENT 6x10, VENT-6x12, VENT-6x14
- VENT-8x8, VENT-8x10
- VENT-10x10
- VENT-12x12