


Section 1 - Mounting to Structure

1. Determine the mounting location of the Wireless Network Gateway and mark on the wall or ceiling.
2. Locate the Mounting Bracket and provided mounting hardware (see Fig. 1).
3. Line up the mounting holes on the back of the NDC with the mounting pegs on the mounting bracket.



Section 2 - LED Indicators

The Wireless Network Gateway has 3 LEDs that are described below

Section 2.1 - Power LED

The Power LED is solid green if there is power to the device, otherwise it is off.

Section 2.2 - Network LED

The Network LED indicates network activity as shown in the following table:


NETWORK LED BLINKING PATTERNS

YELLOW LED ACTION:	INDICATES:
OFF	No connection to the device
SOLID	No other devices communicating in the network
BLINKING	<i>Communicating on the network.</i> The blink pattern shows the total number of devices on the network. <i>A short blink = 1 device A long blink = 10 devices</i>

Section 2.2 -3 - Wireless Status LED

WIRELESS LED BLINKING PATTERNS

LED COLOR:	LED ACTION:	INDICATES:
RED & BLUE	OFF	No Network Connection
RED & BLUE	BLINKING	Pairing with Handheld Remote
PURPLE	ON	CONNECTED
RED	ON	SLEEP MODE



FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
This equipment should be installed and operated with minimum distance 20cm between the radiator & you body.