





# SMART POWER PLUG INSTRUCTION



## Product configuration



## Main Function

One key ON/OFF appliances; Remote Control; Timing ON/OFF; Set countdown tasks

## Specifications

Rated Voltage: AC 85-230V ±10% , 50/60Hz  
Rated Current:10A  
Wireless Type:2.4GHz  
Protocol:IEEE 802.11b/g/n  
Wireless Range: 45m  
Operating Temperature:0℃ ~ 40℃ (32°F ~ 104°F)  
Operating Humidity: 20% ~ 85%  
Storage Temperature:0℃ ~ 60℃ (32°F ~ 140°F)  
Storage Humidity:0% ~ 90%  
Material:PC(V0)  
Size: 55mm x 55mm x 50mm  
Plug type:US, EU, UK, AU  
Support: Amazon Alexa、Google Assistant、IFTTT




## Download App

- 1.Android phone: download "TuyaSmart" from GooglePlay.
- 2.Iphone :download "TuyaSmart" from App Store.




## Add Device

- 1.Run "TuyaSmart"from your smartphone desktop.
- 2.Register and login
- 3.Click the "Add Device"Choose the device that you want to add.




**Power Plug :**  
Plug into power, follow the step as follow:  
Select Device Type, select "Electrical outlet" in the APP



## Network Configuration

- Smart WiFi:**
- 1.Press and hold the reset button for 6s, the indicator will blink rapidly. The device is in smart Wi-Fi mode .
  - 2.Click "Confirm indicator rapidly blink"
  - 3.Configuring network based on prompt of the APP.




### AP Mode:

- 1.Press the reset button for 6s again, the LED will blink slowly. The device is in AP mode.
- 2.Click the "AP Mode"
- 3.Configuring network based on prompt of the APP.



### On/off plug :



### Reset

- 1.Press and hold the reset button for 6s, the indicator will blink rapidly. The device is in smart WiFi mode.
- 2.Press the reset button again, the indicator will blink slowly. The device is in AP mode.




### Customize Scenes

associate two devices to work to create your own scene



### Share & Push Notification

**Share:** Share your devices to others directly . (step 1)



**Push Notification:** Settings—Push Notification. (step2,3)

### LED State

Device Status	LED State
Smart Wi-Fi	Red LED will rapidly blink
AP mode	Red LED will slowly blink
on	green
off	red
reset	LED will rapidly blink(the first time reset) or slowly blink(the second time reset)



Make Your Home Smarter

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **FCC Radiation Exposure Statement:**

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.