


WIRELESS SOLAR DRIVEWAY ALARM

INSTRUCTION MANUAL

MODEL: HS006



Are you happy with the product(s)?

Please text: Hi eMACROS, I like the product(s), my order number is *** to our Email: macross.service@outlook.com

We will register your warranty and register as our VIP customer to have the opportunity to test our new products for free in the future.

Not happy?

Please contact us if you have any dissatisfactions about the product(s). We will appreciate it if you could give us a feedback. For all defective product(s), you can choose one of the following solutions:

Resend one new replacement

100% refund

If you have any questions, please contact us at:

✉ Macross.service@outlook.com,


📞 5023417705

we will assist you as quickly as possible.

🌐 www.emacros.com

Operation & Feature

1. Base Station



VOL Button

Short beep when adjusting the volume, the sound volume will be adjusted cyclically. When turned to minimum, it will be in silent mode.

POWER Button:


Long press the power button to turn on, and the No. 3 light will light up blue.

Long press the power button to turn off the device.

3


2. For detecting people

Please adjust the angle of the sensor appropriately according to the specific situation.



Installation Notes



The driveway alarm should overlook the open detection area; it should not point at trees and shrubs.



1


2. Passive Infra-Red(PIR) Motion Sensor

Mounting Plate



5

What's in the box




Note: The kit consisting of one base station and one sensor has been pre-paired prior to shipping. Simply open the sensor and power on the base station to start using it immediately.

2

Choose Installation Location

After extensive testing, we recommend the following installation heights and angles for detecting people and vehicles. These recommendations ensure optimal performance in these scenarios.

1. For detecting vehicles



6

Music Selection Button

Step1: Briefly press the “” button to enter the ringtone selection mode.

Step2: Navigate through the available ringtones and select your preferred one.

Step3: Once the desired ringtone is chosen, then activate the sensor.

PAIR Button:


Short press the Pair button to enter pairing mode and all four lights will flash red. Then choose a channel on the sensor and trigger it. Long press the pair button to clear pairing, a beep will sound, and the four lights will go out in sequence.

Zone 1 to Zone 4 LED Indicators

When motion is detected, the LED indicators in the corresponding areas of the base station will flash.

4

Make sure sunlight can reach the solar panel directly, but avoid placing the sensor eye in direct sunlight, as this can cause false alarms.



Note: When detecting movements, the sensor eye will flash red only when set on channel 1 and 2, not channel 3 or 4.

Low battery alarm

1. Base Power Low: low battery on the receiver
2. Sensor # Power Low: low battery on the sensor corresponding to this channel

Note: Please charge them as soon as possible after receiving the above alarm.

8

Receiver Status Indicator

Light No. 3 serves as a status indicator with different colors representing various statuses:

1. Blue light: Working status
2. Red light: Triggering status
3. Green light: Charging status

Note: If channel 3 is charged while powered on and receives an sensor signal, the green, blue and red lights will light up at the same time.

Troubleshooting

1. Alarm system quit working

Part 1: Check the sensor

Step 1: Check the Sensor's Battery: Charge the sensor. If the blue light flashes continuously, the battery is faulty.

Step 2: Test Sensor Function: Set the sensor to channel 1 or 2 and trigger it. A red light indicates the sensor is working; no red light suggests a fault.

Step 3: Verify Receiver's Response: If the red light is on the receiver but doesn't alarm after the sensor is triggered, ensure the receiver is not muted and re-pair it with the sensor.

Part 2: Check the receiver

Step 1 :Connect the receiver to the power supply

Step 2 :Check whether the No. 3 light is always on red. If it is always on, it means the receiver is working. If the No. 3 light is not on, there is a problem with the receiver. Please contact customer service.

9

FCC SATEMENT

Power:5V DC 1000mA

FCC ID: 2AXOF-HS006

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

13

2. Alarm system sometimes works but sometimes does not work

Step 1: Check the lens for water mist.

Step 2: Set the PIR Sensor Switch to a High sensitivity setting.

Step 3: Install the sensor about 1 ft above ground level. Keep parallel to the ground.

Step 4: Ensure the receiver and sensor are in the valid range.

14

3. The alarm system has false alarms

Step 1: Check for moving tree branches or insects in the sensor window and remove them as necessary.

Step 2: Set to Low sensitivity on the Sensor and make sure that sunlight is not shining directly onto the sensor eye.

10

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

4. If the sensor continuously goes off.

Please cover the sensor to confirm if it still goes off or gets false alarm. If so, your receiver may get the interference with other sensors. Please contact our service support, we will do our best to make it right for you.

CORE VALUES

This brand prioritizes the below core values to fulfill its mission and vision.

COMPASSION

Our most important core value, put simply is to care. For our company to do its job right, we need to empathize with our customers' fears, struggles, and hopes for the future. And in the workspace, treating each other with kindness and compassion, not only makes working together easier and more productive, but it spreads that compassion on and makes a difference in people's lives. So whether we're interacting with customers, colleagues, friends, family or strangers, the Hosmart team holds compassion at the utmost importance.

11

This radio is designed for and classified as "General population/uncontrolled Use"
DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed 2dBi by the manufacturer declared.
DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
During operation, the separation distance between user and the antenna shall be at least 20cm, this separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements.
During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so.
DO NOT operate the transmitter in areas that are sensitive to electromagnetic such as hospitals, aircraft, and blasting sites.

This product produced by:
Macross Microelectronics (HK) LIMIT
FLAT/RM KY001 UNIT 3 27/F HO KING COMM
CENTRE NO.2-16FA YEEN STREET MONGKOK
KL

12

15