


# *msi*

## Roamii BE Lite Mesh System

### QUICK START GUIDE


**Step 1 :** Connect a modem (either provided by internet service or acquired separately) to the internet port on one Roamii router with an Ethernet cable, and power up both devices.



**Step 2 :** Using a smartphone or tablet, download **MSI Roamii** from either App Store or Google Play.



**Step 3 :** Launch the **MSI Roamii** app and follow the instruction given by the app to finish setup.



#### LED status

LED	Roamii Status
White solid	Roamii is operating normally.
White pulse	Connection between satellite Roamii and main Roamii is weak.
Blue pulse	Roamii is ready for setup.
Blue solid	Roamii is starting up.
Green pulse	Roamii devices are connecting.
Orange pulse	Main Roamii: Not connected to the internet. Satellite Roamii: Not connected to the main Roamii.



Micro-Star International Co., Ltd.

<https://www.msi.com/>

## Regulatory Statements

### Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

The availability of some specific channels and / or operational frequency bands are country dependent and are firmware programmed at factory to match the intended destination. The firmware setting is not accessible by the end user.

FCC regulations restrict the operation of this device to indoor use only.

## RF Exposure Information

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 40 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance

For 2.4G WLAN, only channels 1~11 are operational. Selection of other channels is not possible..

## REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at MSI REACH website at <https://csr.msi.com/global/Product-Chemical-Management>

## IMPORTANT NOTE

For more information about your router, you can download the user manual from <https://www.msi.com/support>

## Safety Instructions

Read the safety instructions carefully and thoroughly. All cautions and warnings on the equipment or user's manual should be noted.

- Do not leave the Router in an unconditioned environment with a storage temperature above 60°C (140°F) or below 0°C (32°F), which may damage the router.
- This router should be operated under maximum ambient temperature of 40°C (104°F).
- For safety reasons, the maximum installation height of the product should be less than 2 meters.

## Power and Operating/Storage Specifications

DC Power adapter	DC Output: + 12V with Max 1.5A current	
	Temperature	Humidity
Operating	0 ~ 40°C	10 ~ 95%
Storage	-30 ~ 70°C	10 ~ 95%