



A Partner You Can Trust

CONTACTLESS READER MODULE

INSTALLATION GUIDE



MODEL:

xNFC_C150SE

1. CONTENTS IN THE BOX

- xNFC_C150SE(**Figure 1**)
- Overlay stickers (**Figure 2**) – Portrait (A) and Landscape (B)

Select the desired overlay sticker, peel the back tape and apply the overlay on the front surface of xNFC_C150SE (**Figure 3**)



A

B

Figure 1

Figure 2



Figure 3

2. CABLE INTERFACES

xNFC_C150SE comes with 3 types of cables:

- a) RS232 interface (DB9 connector) (**Figure 4**) – xNFC_C150SE is powered by power adapter.
- b) USB interface (**Figure 5**) – xNFC_C150SE is powered by host through USB.
- c) RS232 interface (**Figure 6**) – xNFC_C150SE is powered by host.



Figure 4



Figure 5



Figure 6

3. SETTING CONNECTION

- USB interface:
Plug the USB connector into any of the USB port of the host.
- RS232 interface:
Connect the RS232 connector with the COM port of the host.

4. INSTALLING THE Battery

- Keep xNFC_C150SE power-on
- Remove Battery: Pull the ejector (A). (**Figure 7**)
- Install Battery: Insert battery into battery slot with POSITIVE (+) pole face downward.
- Unplug the power



Figure 7

Caution: Keep xNFC_C150SE power on to avoid key lost when battery replacement.

5. INSTALLING THE SAM CARD

Loosen the screw and open the SAM gate (**Figure 8**), insert the SAM-1(**Figure 8-1**) & SAM-2(**Figure 8-2**) cards in the slot.




Figure 8



Figure 8-1



Figure 8-2

6. USING CONTACTLESS CARD READER

After xNFC_C150SE is powered on, xNFC_C150SE is ready for card reading when 1st LED on the bezel starts to blink.

Place contactless card close to contactless logo



to read card (Figure 9)



Figure 9

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



XAC Automation Corporation

886-3-577-2738

www.xac.com.tw

The above information is the exclusive intellectual property of XAC Automation Corporation and shall not be disclosed, distributed or reproduced without permission of XAC Automation Corporation.

XAC AUTOMATION CORP. shall not be held liable for technical and editorial omissions or errors made herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of his material.