



STEP8: Setting up Google Assistant



1



2


[MORE] → [TURN ON]^{*1} [NEXT] → [I AGREE] → Follow the onscreen instruction

*1 To not set, tap "NO THANKS".

- If Google account is not set, the setting of Google Assistant is not displayed.
- When a settings screen for Google Pay appears, follow the onscreen instructions.

STEP9: Setting an au ID

By setting au ID, you can use various services provided by au such as auスマートパス (au Smart Pass) or "au Kantan Kessai (Easy Payment)", which allows you to do things such as purchase apps from Google Play.



1




2

Confirm contents^{*1} → Checkmark "au Terms of Service" → [SIGN IN]^{*2}

Enter PIN number^{*3} → [次へ (Next)]



3



4

Enter a password → [同意して次へ (Agree, and next)]


[次へ (Next)]

- Alternatively, after the initial setting, in the Home screen, slide the screen up → [Settings] → [au Settings] → [au ID].
- Tap "au Terms of Service" and check the information.
- If you have already been registered au ID, step 2 and 3 do not appear. Proceed to step 4.
- Sign-in is not possible if connected to Wi-Fi[®]. Tap "SKIP" and proceed to "STEP 10".
- PIN number is a four digit number chosen by the customer and noted on the application form.

Making the initial settings




1



2

[au-mail] → Confirm the content → [Agree]



3



4

Confirm the content → [Agree] → Follow the onscreen instruction


Checking au-mail address^{*1} → [閉じる (Close)]

- *1 For change of model, the au-mail address which you have been used so far is displayed.


Checking your au-mail address

1 In the Home screen, slide the screen up → [au-mail] → [E-mail information]

Checking the operations of au-mail app



1




2

In the Home screen, slide the screen up → [au-mail] → [E-mail information]

[Operation guide] (Japanese)

STEP10: Setting au Apps being added




1


Mark apps to install → [Next]

- Alternatively, after the initial setting, in the Home screen, slide the screen up → [Settings] → [au Settings] → [au ID].
- Tap "au Terms of Service" and check the information.
- If you have already been registered au ID, step 2 and 3 do not appear. Proceed to step 4.
- Sign-in is not possible if connected to Wi-Fi[®]. Tap "SKIP" and proceed to "STEP 10".
- PIN number is a four digit number chosen by the customer and noted on the application form.

STEP11: Setting up additional apps



1




2


Unmark apps not to add^{*1} [OK]

- *1 Tap an item to open an app introduction.

STEP12: Setting up more things



1



2

[NO THANKS]^{*1} [FINISH]

- To make other settings, tap items you want to set, and follow the onscreen instructions.
- The screen for setting more things does not appear if you do not set the fingerprint authentication or screen lock unlock method.
- Tap "FINISH" to complete initial settings.
- Downloading of the applications selected in "STEP 10" "STEP 11" starts when the product is connected to Wi-Fi[®].

au-mail setting

- To use au-mail, subscription to LTE NET is required. If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.
- Perform the initial settings in a place with good signal condition in Japan. If you perform in a place with bad signal condition or while moving, the settings may fail. The initial setting cannot be made via Wi-Fi[®] communication.
- Depending on time zone, the initial settings may take from 30 seconds to 3 minutes. Wait for a while with "Eメールアドレスの設定中です。しばらくお待ちください。" (Setting email address. Wait for a while.) displayed on the screen.

Phone

Making a call


- Direct input calling
- From the Home screen, [📞] → [📞]
- Enter a phone number → [📞]
- To make a call to a land-line phone, enter from the city code even when you stay in the same city.
- Call → [📞]
- To adjust the in-coming volume (volume of the other party's voice), press the upper part or lower part of the volume key while calling.
- Calling from history
- From the Home screen, [📞] → Tap "Recents" tab
- [📞] of call history
- Calling from contacts
- In the Home screen, slide the screen up → [Contacts]
- Tap a contact to call
- Tap [Call]/phone number

Receiving a call


- When the screen is OFF or on the lock screen
- Incoming call screen → Swipe (flick) "📞" up
- To reject the incoming call, swipe (flick) "📞" down.
- To answer with Answering Machine, slide the status bar in the top of the screen down → Tap "Answering Machine".
- Call → [📞]
- When the screen is ON (except on the lock screen)
- In the displayed notification, [ANSWER]
- To reject an incoming call, tap "DECLINE".
- To answer with Answering Machine, slide the status bar in the top of the screen down → Tap "Answering Machine".
- Call → [📞]

Setting wireless LAN (Wi-Fi[®])

You can use a home wireless LAN (Wi-Fi[®]) or public wireless LAN to access the Internet services. Set it in a place where the signal of Wi-Fi[®] network can be received.




1



2

In the Home screen, slide the screen up

[Settings] → [Network & internet]



3



4


[Wi-Fi]^{*1}

Select a Wi-Fi[®] network → Enter a password (security key) → [CONNECT]


- *1 If Wi-Fi[®] is off, set it on.

Setting the lighting time of screen

The screen turns off automatically when the set time has elapsed while no operation is made. When you cannot operate readily because the screen turns off soon, change the lighting time.




1




2

In the Home screen, slide the screen up

[Settings] → [Display]



3



4

[Sleep]

Select the lighting time

Appendix

Peripheral devices

- TypeC Common AC Adapter 01 (0601PQA) (sold separately)
- TypeC Common AC Adapter 02 (0602PQA) (sold separately)^{*1}
- Common AC Adapter 05 (0501PWA) (sold separately)^{*1}
- Common DC Adapter 03 (0301PEA) (sold separately)^{*1}
- Micro-B Type-C Adapter (0601PHA) (sold separately)
- au Carrying Case G Black (0106FCA) (sold separately)
- *1 For use, Micro-B Type-C Adapter (sold separately) is needed.
- Information
- Accessories can be purchased from the au Online Shop. <https://onlineshop.au.com/> (Japanese)

Main specifications

Main unit		
Display	Approx. 6.0 inches Liquid crystal TRILUMINOS [®] Display for mobile, Approx. 16.77 million colors 1,080 x 2,520 dots	
Weight	Approx. 170 g	
Dimension (W x H x T)	Approx. 69 mm x 158 mm x 8.1 mm (9.7 mm where thickest)	
Internal memory	ROM: Approx. 64 GB RAM: Approx. 4 GB	
Camera pixels	Camera: Effective pixels Approx. 12 million pixels,/8 million pixels Front camera: Effective pixels Approx. 8 million pixels	
Continuous call time	In Japan	Approx. 1,700 min.
	Overseas (GSM)	Approx. 720 min.
Continuous stand-by time	In Japan	Approx. 580 hours
	Overseas (GSM)	Approx. 650 hours

Charging time	Using TypeC Common AC Adapter 01 (sold separately): Approx. 160 min. Using TypeC Common AC Adapter 02 (sold separately): Approx. 140 min.	
Continuous tethering time	Approx. 570 min.	
Wi-Fi [®] tethering maximum connection number	10	
Bluetooth [®] function	Communication type	Compliant with Bluetooth [®] standard Ver.5.0
	Output	Compliant with Bluetooth [®] standard Power Class 1
	Communication coverage distance ¹	Within 10 m with good visibility
	Supported Bluetooth [®] profile ²	HSP, HFP, PBAP ³ , A2DP, apt-X, AVRCP, SPP, OPP, HID, HOGP, MAP, GATT, PAN-NAP, PANU
Radio frequency band	2.4 GHz band (2,400 MHz - 2,483.5 MHz)	

- *1 Varies by obstruction between communication devices or radio wave reception status.
- *2 It is a specification according to purpose of use of Bluetooth[®] device and is defined by Bluetooth[®] standard.
- *3 Some contacts data may not be displayed correctly on the other party's device.
- Information
- The continuous call time, continuous stand-by time and continuous tethering time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings.

For inquiries, call: Customer Service Center

For general information (toll free)
Business hours 9:00–20:00 (7 days a week)
From au mobile phones | From non-au mobile phones/general subscriber phones

157 without area code ☎ 0077-7-111
In case above numbers are not available (toll free).
☎ 0120-977-033 (except Okinawa) ☎ 0120-977-699 (Okinawa)

For theft, loss, or malfunction (toll free)
Business hours : 24 hours live support
From au mobile phones | From non-au mobile phones/general subscriber phones

113 without area code ☎ 0077-7-113
In case above numbers are not available (toll free).
☎ 0120-925-314

Repair and Delivery Support Center
For theft, loss, or malfunction (toll free) | From au mobile phones/non-au mobile phones/general subscriber phones
Business hours 9:00–20:00 (7 days a week)
☎ 0120-925-919

Mobile phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the ♻ logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

やめましよう、歩きスマホ。
キケン! 水ぬれ充電
あぶない! 電池への衝撃

SONY[®]
Sold by: KDDI CORPORATION,
OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: Sony Mobile Communications Inc.

November 2019, 1st Edition
1300-4216.1