

Preface

Thank you for buying XXXXXXX (simply called the "product" from here on). Before using the product, read "Basic Manual" (this manual) and "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) to ensure safe use and handling.

About Operating Instructions

■ Basic Manual (this manual)

Handles only basic operations for main features. For detailed descriptions on various functions, refer to the "Instruction Manual" (Japanese) application installed on the product or "取扱説明書 (詳細版) (Full Instruction Manual) (Japanese)" available on the au homepage. <http://www.au.kddi.com/support/mobile/guide/manual/>

- Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in this manual.

■ "Instruction Manual" (Japanese) application

This product allows you to use the "Instruction Manual" (Japanese) application on the product to confirm detailed operational procedures. Certain functions can be directly activated from the application screens on which their operations are described. **From the Home screen, [⌘]▶[お客さまサポート (Customer support)]▶[Basic Manual] (Japanese)**

- When you activate for the first time, follow the onscreen instructions to download and install application.

SOL26



Basic Manual

◆Information

- Purchase a specified charger (sold separately).
- Illustrations used in this manual are just images for explanations. They may be different from actual ones.

Getting Ready

Names and functions of parts



CE mark and FCC ID

1 Open the au Micro IC Card (LTE) slot cover, and insert a fingernail into the hook at the edge of the label tray, then pull it out straight.

■ Charging with the Desktop Holder

Charging with the supplied Desktop Holder (SOL26PUA) and Common AC Adapter 05 (sold separately) is explained.

- Insert the microUSB plug of Common AC Adapter 05 (sold separately), with the engraved side (▲) facing up, straight into the microUSB connection terminal of the Desktop Holder
- Insert the power plug of Common AC Adapter 05 (sold separately) into an outlet

■ Charging with the AC Adapter

Charging with Common AC Adapter 05 (sold separately) is explained.

- Insert the microUSB plug of Common AC Adapter 05 (sold separately), with the engraved side (▲) facing up, straight into the microUSB connection terminal of the Desktop Holder
 - Insert the power plug of Common AC Adapter 05 (sold separately) into an outlet
 - Install the product to the Desktop Holder and move it left or right until it clicks
- When the product and the magnetic connector of the Desktop Holder are connected correctly, the notification LED of the product turns on.

- "The Company" as appears on the product refers to the following companies:
Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: Sony Mobile Communications Inc.

Download URL:
<http://www.au.kddi.com/support/mobile/guide/manual/>

Safety Precautions

Before you start using the product, make sure to read the "Cautions on using XXXXXXX" to ensure correct use. Before you assume that the product is malfunctioning, check for possible remedies in the following au Customer Support site of au homepage:

http://www.au.kddi.com/support/mobile/trouble/repair

Regarding notations used in this document

- In this manual, keys (key icons) are represented by simplified illustrations such as , , , , .
- Operations of tapping menu items/icons/buttons on the screen etc. are indicated as [(name of the item etc.)].
- Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted.
- In this manual, "microSD™ memory card", "microSDHC™ memory card" and "microSDXC™ memory card" are abbreviated as "microSD memory card" or "microSD".
- All of the indicated amounts exclude tax unless otherwise specified.



au Micro IC Card (LTE)

Your phone number etc. is recorded in the au Micro IC Card (LTE). The product is compatible only with au Micro IC Card (LTE). You cannot use the product with an au IC-card or micro au IC card switched from an au cell phone or au smartphone. Do not insert an au Nano IC Card (LTE) with a conversion adapter. Doing so may cause a fault.

Attaching/removing the au Micro IC Card (LTE)

Before attaching/removing the au Micro IC Card (LTE), make sure to turn off the product.

■ Attaching the au Micro IC Card (LTE)

- Open the microSD memory card/au Micro IC Card (LTE) slot cover while hooking the groove with your fingernail
- Hook the projection of the tray (1) with your fingernail to slide the tray straight out, then remove the tray from the product

■ Charging with the DC Adapter

You can charge from cigarette lighter socket in a car by using Common DC Adapter 03 (sold separately). For details, refer to instruction manual of Common DC Adapter 03 (sold separately).

■ Charging with a PC

The followings describe charging procedure by connecting the product to chargeable USB port on a PC using the microUSB cable of Sony Mobile AC adapter 05 (sold separately).

- Open the microUSB connection terminal cover of the product while hooking the groove with your fingernail, and insert the microUSB plug of the microUSB cable, with the engraved side (↔) facing up, straight into the microUSB connection terminal of the product

- "The Company" as appears on the product refers to the following companies:
Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: Sony Mobile Communications Inc.

Using au 災害対策 (au Disaster Countermeasure)

You can use 災害用伝言板 (Disaster Message Board) service, 緊急速報メール (Emergency Rapid Mail) service that distributes 緊急地震速報 (Earthquake Early Warning), 災害・避難情報 (Disaster and Evacuation Information) and 津波警報 (Tsunami Warning), and 災害用音声お届けサービス (Disaster Voice Messaging Service).

- From the Home screen, [au災害対策 (au Disaster Countermeasure)] au災害対策 (au Disaster Countermeasure) menu appears.

■ Using 災害用伝言板 (Disaster Message Board) Disaster Message Board service enables you to register information of well-being from an area of distress via LTE NET in case of large-scale disaster such as earthquake with a seismic intensity of over 6 lower.

- au災害対策 (au Disaster Countermeasure) menu▶[災害用伝言板 (Disaster Message Board)]

◆Information

- To register information of well-being, E-mail address (~ezweb.ne.jp) is required. Set up E-mail address beforehand.

■ Using 緊急速報メール (Emergency Rapid Mail) Emergency Rapid Mail is a service that distributes Earthquake Early Warning or Tsunami Warning delivered from the meteorological bureau or Disaster and Evacuation Information delivered from the government or local public organization to all au cell phones in specified areas simultaneously.

When you receive Earthquake Early Warning, when your safety and take proper action according to the situation around you. When you receive a Tsunami Warning, draw away from sea coast immediately and evacuate to safe place such as upland or well-built high building.

- au災害対策 (au Disaster Countermeasure) menu▶[緊急速報メール (Emergency Rapid Mail)]

◆Information

- Reception of Emergency Rapid Mail is notified by a special warning tone and vibration. It is not possible to change the warning tone.
- Earthquake Early Warning is notified by warning tone and voice sound ("地震です" (It is an earthquake)), and vibration.
- Earthquake Early Warning may not arrive before strong tremors in areas near the epicenter.
- Tsunami Warning is a major tidal wave/seismic sea wave notification delivered from the meteorological bureau to the area including target coast.
- Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
- The service is available only in Japan (it cannot be used overseas).
- No information fee or communication charge is required for receiving Emergency Rapid Mail.
- KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns, or other events that are outside the responsibility of KDDI.
- Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning. <http://www.jma.go.jp/>

- Hook the projection of the tray with your fingernail to slide the tray straight out, then remove the tray from the main unit

- Remove au Micro IC Card (LTE) out of the tray, insert the tray into the main unit and then press it all the way

- Close the microSD memory card/au Micro IC Card (LTE) slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

◆Information

- Note the following points, otherwise handling the au Micro IC Card (LTE) may cause malfunction or damage.

- Do not touch the IC (metal) part of the au Micro IC Card (LTE).
- Insert in the correct direction.
- Do not use force to attach or remove.
- Do not lose the au Micro IC Card (LTE) after it has been removed.

Attaching/Removing microSD memory card

■ Attaching microSD memory card

- Open the microSD memory card/au Micro IC Card (LTE) slot cover while hooking the groove with your fingernail.
- Check the orientation for inserting, and insert it until it clicks

Insert the microSD memory card with the contact side down.

■ Force-quitting

- Open the microSD memory card/au Micro IC Card (LTE) slot cover while hooking the groove with your fingernail, press the OFF button (RED) with a fine-tipped object for approximately three seconds, and release your finger after it vibrates three times

Turning on (Initial settings)

Turning the power on

- Ⓞ (over 1 sec)
The product vibrates and after a while the lock screen appears.
- Swipe (flick) the screen up or down

■ Turning the power off

- Ⓞ (over 1 sec)
- [Power off]▶[OK]

◆Information

- Press Ⓞ for over 1 second and long-touch "Power off" ▶ [OK] to restart product in safe mode.

- ◆Information
- Pressing the OFF button (RED) by a sharp object such as needle may cause malfunction.
- Alternatively, press and hold Ⓞ and upper part of the volume key at the same time for approximately three seconds, and release your finger after it vibrates three times.

Initial settings

When you turn on the product for the first time, follow the onscreen instructions to set language, functions, service, etc. For details, refer to "Setting Guide".

◆Information

- To change the language later, from the Home screen, [⌘]▶[設定 (Settings)]▶[言語と入力 (Language & input)]▶[地域／言語 (Language)]. To make settings, from the Home screen, [⌘]▶[Settings]▶[Setup guide]. To make settings

- You cannot receive Emergency Rapid Mail when your cell phone is turned off or during a call.
- Emergency Rapid Mail may not be received when your cell phone is communicating such as while sending/receiving SMS/e-mail or using the browser, or if you are in a place where signal does not reach even in the service area (e.g. in a tunnel, basement) or in a place with a poor reception.
- You cannot receive the Emergency Rapid Mail that the reception is failed.
- This delivery system is different from Earthquake Early Warning provided through TV, radio, or other communication procedures, which means that the time the Earthquake Early Warning arrives may vary.
- Information from someplace other than your current location may be received.

■ Using 災害用音声お届けサービス (Disaster Voice Messaging Service)

Disaster Voice Messaging Service is a service which allows you to record your voice and send someone you want to inform your well-being in case of a large-scale disaster.

- au災害対策 (au Disaster Countermeasure) menu▶[災害用音声お届けサービス (Disaster Voice Messaging Service)]

◆Information

- To use Wi-Fi®, initial settings via 4G (LTE/WiMAX 2+)/3G network is required.
- Voice message can be recorded for up to 30 seconds.
- Voice messages cannot be saved or played if the product does not have available memory.

■ Using 災害情報／義援金サイト (Disaster information/Donation website)

You can check history of Disaster and Evacuation Information delivered by local government, disaster information portal, donation website, etc.

- au災害対策 (au Disaster Countermeasure) menu▶[災害情報／義援金サイト (Disaster information/Donation website)]▶Follow the onscreen instructions

Do you have everything?

Before your start using the product, make sure that you have all the following packaged with the product.

- XXXXXXX¹
- Desktop Holder (SOL26PUA)¹
- Sony Mobile TV antenna cable 02 (02SOHSA)
- *1 Including warranty
- 取扱説明書 (Instruction Manual) (Japanese)
- XXXXXXXのご利用にあたっての注意事項 (Cautions on using XXXXXXX) (Japanese)
- 設定ガイド (Setting Guide) (Japanese)

The following items are not included in the package.

- microSD memory card
- AC adapter
- Earphones
- microUSB cable

- Press the microSD memory card all the way until it clicks, then pull out the microSD memory card slowly

"Removed SD card" appears on status bar to inform that the microSD memory card is removed.

- Close the microSD memory card/au Micro IC Card (LTE) slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

Charging

When you purchase your product, the internal battery is not fully charged. Charge the battery before use.

◆Information

- When the charging starts, notification LED lights according to the battery level. To check the battery level, see the status bar in the top of the Home screen. Alternatively, from the Home screen, [⌘]▶[Settings]▶[About phone]▶[Status] and see "Battery level".
- When you start charging with the product powered off, the power turns on even though operation is not available. Do not charge the battery in a place where the use is prohibited such as in airplane or hospital.
- It may take longer to complete for charging with a PC or while using the camera function.
- You cannot charge the battery by connecting the Desktop Holder to a PC.
- Be sure to attach the supplied attachment to the Desktop holder when charging. If the product is installed without the attachment attached, charging fails. Replace the attachment as required. Depending on cover you use, charging may fail.

	Return to the previous screen. Close a dialog box, menu, or the Notifications panel.
	Display the Home screen. Long-touch and drag it to to activate "Google" application or drag it to to activate "What's New" application.
	Display recently used applications on a list and activate or delete them from the list. Also, you can use and set small apps.

Using the touch panel

The display of the product is a touch panel operated by touching it with your finger.

■ Tap/Double-tap

Tap: Gently touch a screen and then immediately release your finger. Double tap: Touch the same position twice.

■ Long-touch

Keep touching an item with your finger.

■ Slide

While your finger is gently touching the screen, trace it to the desired direction to move over.

■ Flick (swipe)

Operate the screen by quickly moving (flicking) your finger up, down, right, or left.

for au service etc., from the Home screen, [⌘]▶[お客さまサポート (Customer support)]▶[au Easy Setting].

Screen Lock

When the screen lock is set, the backlight turns off to avoid the keys and touch panel from false operations. When the specified time elapses, the product's screen backlight turns off automatically and screen lock is activated.

- While the screen is displayed, Ⓞ

■ Unlocking screen

The lock screen appears when turning the power on or the backlight on by pressing Ⓞ.

- Swipe (flick) the screen up or down on the lock screen

◆Information

- On the lock screen, long-touch and drag it to to activate the camera.

Basic Operation

Key icons

The followings are the main functions of , , keys located at the bottom of the screen.



■ **Pinch**
Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.

■ **Drag**

Keep touching an item or icon, trace it to the desired direction to move.

Home screen

Home screen consists of multiple screens. Slide or flick left or right to move to the adjacent screen. Tap ☰ to return to the Home screen any time.

① Home screen position

Indicates which screen of the several Home screens you are in.

② Widgets

③ Wallpapers

④ Shortcuts (Applications)

⑤ Media folders

⑥ 基本機能フォルダ (Basic functions folder)

⑦ Application key



Adding to Home screen/Editing Home screen

You can change wallpaper or theme of the Home screen and add/delete/move shortcuts of applications, widgets, folders, etc. on the Home screen.

1 Long-touch an area of the Home screen where no icons are displayed

Alternatively, pinch-in on the Home screen.

2 Widgets		Add a widget.
Apps		Add a shortcut of an application, a setting screen, etc.
Wallpapers	Album	Select an image from albums to set as a wallpaper. <ul style="list-style-type: none">To set image range, adjust cropping area by dragging, etc.
	Live Wallpapers	Select a content from albums to set as a wallpaper.
	Photos	Select an image from photos to set as a wallpaper.
	(Xperia™'s Wallpaper)	Select an image to set as a wallpaper. <ul style="list-style-type: none">Images displayed to the right of "Photos"/"Live Wallpapers" are "Xperia™'s Wallpaper".
Themes		Set the wallpapers etc. for the Home screen or the lock screen.

■ **Adding a folder**

1 From the Home screen, long-touch an icon

2 Drag the icon onto another icon

Entering characters

Use software keyboard to enter characters.

To display the software keyboard, tap a character input box on the character entry screen for adding contacts, creating a message, etc.

■ **Switching keyboards**

With "Xperia™ Japanese keyboard" for Japanese input, you can switch input types between "Keypad" and "QWERTY".

1 Tap a character input box

2 [≡] on quick toolbar

When quick toolbar is not displayed, tap ≡ (when the character mode is "Alphabet"/"Numeric", tap ≡ 1/≡ 2/≡ 3/≡ 4) to switch to "Hiragana/Kanji" then ≡ appears.

3 [Switch to QWERTY]/[Switch to keypad]

◆**Information**

- Tap ≡ at the bottom left of the screen to hide the software keyboard.
- Word suggestions or direct conversion candidates for the entered characters appear. Tap a word to enter.
- Tap ✖ to delete the character before the cursor.
- Tap ≡ to enter symbols, facemarks etc. from the displayed list.
- For details on "Xperia™ Japanese keyboard" for Japanese input, character input box→≡ 1→≡ 2→≡ 3→≡ 4→≡ 5→≡ 6→≡ 7→≡ 8→≡ 9→≡ 10→≡ 11→≡ 12→≡ 13→≡ 14→≡ 15→≡ 16→≡ 17→≡ 18→≡ 19→≡ 20→≡ 21→≡ 22→≡ 23→≡ 24→≡ 25→≡ 26→≡ 27→≡ 28→≡ 29→≡ 30→≡ 31→≡ 32→≡ 33→≡ 34→≡ 35→≡ 36→≡ 37→≡ 38→≡ 39→≡ 40→≡ 41→≡ 42→≡ 43→≡ 44→≡ 45→≡ 46→≡ 47→≡ 48→≡ 49→≡ 50→≡ 51→≡ 52→≡ 53→≡ 54→≡ 55→≡ 56→≡ 57→≡ 58→≡ 59→≡ 60→≡ 61→≡ 62→≡ 63→≡ 64→≡ 65→≡ 66→≡ 67→≡ 68→≡ 69→≡ 70→≡ 71→≡ 72→≡ 73→≡ 74→≡ 75→≡ 76→≡ 77→≡ 78→≡ 79→≡ 80→≡ 81→≡ 82→≡ 83→≡ 84→≡ 85→≡ 86→≡ 87→≡ 88→≡ 89→≡ 90→≡ 91→≡ 92→≡ 93→≡ 94→≡ 95→≡ 96→≡ 97→≡ 98→≡ 99→≡ 100→≡ 101→≡ 102→≡ 103→≡ 104→≡ 105→≡ 106→≡ 107→≡ 108→≡ 109→≡ 110→≡ 111→≡ 112→≡ 113→≡ 114→≡ 115→≡ 116→≡ 117→≡ 118→≡ 119→≡ 120→≡ 121→≡ 122→≡ 123→≡ 124→≡ 125→≡ 126→≡ 127→≡ 128→≡ 129→≡ 130→≡ 131→≡ 132→≡ 133→≡ 134→≡ 135→≡ 136→≡ 137→≡ 138→≡ 139→≡ 140→≡ 141→≡ 142→≡ 143→≡ 144→≡ 145→≡ 146→≡ 147→≡ 148→≡ 149→≡ 150→≡ 151→≡ 152→≡ 153→≡ 154→≡ 155→≡ 156→≡ 157→≡ 158→≡ 159→≡ 160→≡ 161→≡ 162→≡ 163→≡ 164→≡ 165→≡ 166→≡ 167→≡ 168→≡ 169→≡ 170→≡ 171→≡ 172→≡ 173→≡ 174→≡ 175→≡ 176→≡ 177→≡ 178→≡ 179→≡ 180→≡ 181→≡ 182→≡ 183→≡ 184→≡ 185→≡ 186→≡ 187→≡ 188→≡ 189→≡ 190→≡ 191→≡ 192→≡ 193→≡ 194→≡ 195→≡ 196→≡ 197→≡ 198→≡ 199→≡ 200→≡ 201→≡ 202→≡ 203→≡ 204→≡ 205→≡ 206→≡ 207→≡ 208→≡ 209→≡ 210→≡ 211→≡ 212→≡ 213→≡ 214→≡ 215→≡ 216→≡ 217→≡ 218→≡ 219→≡ 220→≡ 221→≡ 222→≡ 223→≡ 224→≡ 225→≡ 226→≡ 227→≡ 228→≡ 229→≡ 230→≡ 231→≡ 232→≡ 233→≡ 234→≡ 235→≡ 236→≡ 237→≡ 238→≡ 239→≡ 240→≡ 241→≡ 242→≡ 243→≡ 244→≡ 245→≡ 246→≡ 247→≡ 248→≡ 249→≡ 250→≡ 251→≡ 252→≡ 253→≡ 254→≡ 255→≡ 256→≡ 257→≡ 258→≡ 259→≡ 260→≡ 261→≡ 262→≡ 263→≡ 264→≡ 265→≡ 266→≡ 267→≡ 268→≡ 269→≡ 270→≡ 271→≡ 272→≡ 273→≡ 274→≡ 275→≡ 276→≡ 277→≡ 278→≡ 279→≡ 280→≡ 281→≡ 282→≡ 283→≡ 284→≡ 285→≡ 286→≡ 287→≡ 288→≡ 289→≡ 290→≡ 291→≡ 292→≡ 293→≡ 294→≡ 295→≡ 296→≡ 297→≡ 298→≡ 299→≡ 300→≡ 301→≡ 302→≡ 303→≡ 304→≡ 305→≡ 306→≡ 307→≡ 308→≡ 309→≡ 310→≡ 311→≡ 312→≡ 313→≡ 314→≡ 315→≡ 316→≡ 317→≡ 318→≡ 319→≡ 320→≡ 321→≡ 322→≡ 323→≡ 324→≡ 325→≡ 326→≡ 327→≡ 328→≡ 329→≡ 330→≡ 331→≡ 332→≡ 333→≡ 334→≡ 335→≡ 336→≡ 337→≡ 338→≡ 339→≡ 340→≡ 341→≡ 342→≡ 343→≡ 344→≡ 345→≡ 346→≡ 347→≡ 348→≡ 349→≡ 350→≡ 351→≡ 352→≡ 353→≡ 354→≡ 355→≡ 356→≡ 357→≡ 358→≡ 359→≡ 360→≡ 361→≡ 362→≡ 363→≡ 364→≡ 365→≡ 366→≡ 367→≡ 368→≡ 369→≡ 370→≡ 371→≡ 372→≡ 373→≡ 374→≡ 375→≡ 376→≡ 377→≡ 378→≡ 379→≡ 380→≡ 381→≡ 382→≡ 383→≡ 384→≡ 385→≡ 386→≡ 387→≡ 388→≡ 389→≡ 390→≡ 391→≡ 392→≡ 393→≡ 394→≡ 395→≡ 396→≡ 397→≡ 398→≡ 399→≡ 400→≡ 401→≡ 402→≡ 403→≡ 404→≡ 405→≡ 406→≡ 407→≡ 408→≡ 409→≡ 410→≡ 411→≡ 412→≡ 413→≡ 414→≡ 415→≡ 416→≡ 417→≡ 418→≡ 419→≡ 420→≡ 421→≡ 422→≡ 423→≡ 424→≡ 425→≡ 426→≡ 427→≡ 428→≡ 429→≡ 430→≡ 431→≡ 432→≡ 433→≡ 434→≡ 435→≡ 436→≡ 437→≡ 438→≡ 439→≡ 440→≡ 441→≡ 442→≡ 443→≡ 444→≡ 445→≡ 446→≡ 447→≡ 448→≡ 449→≡ 450→≡ 451→≡ 452→≡ 453→≡ 454→≡ 455→≡ 456→≡ 457→≡ 458→≡ 459→≡ 460→≡ 461→≡ 462→≡ 463→≡ 464→≡ 465→≡ 466→≡ 467→≡ 468→≡ 469→≡ 470→≡ 471→≡ 472→≡ 473→≡ 474→≡ 475→≡ 476→≡ 477→≡ 478→≡ 479→≡ 480→≡ 481→≡ 482→≡ 483→≡ 484→≡ 485→≡ 486→≡ 487→≡ 488→≡ 489→≡ 490→≡ 491→≡ 492→≡ 493→≡ 494→≡ 495→≡ 496→≡ 497→≡ 498→≡ 499→≡ 500→≡ 501→≡ 502→≡ 503→≡ 504→≡ 505→≡ 506→≡ 507→≡ 508→≡ 509→≡ 510→≡ 511→≡ 512→≡ 513→≡ 514→≡ 515→≡ 516→≡ 517→≡ 518→≡ 519→≡ 520→≡ 521→≡ 522→≡ 523→≡ 524→≡ 525→≡ 526→≡ 527→≡ 528→≡ 529→≡ 530→≡ 531→≡ 532→≡ 533→≡ 534→≡ 535→≡ 536→≡ 537→≡ 538→≡ 539→≡ 540→≡ 541→≡ 542→≡ 543→≡ 544→≡ 545→≡ 546→≡ 547→≡ 548→≡ 549→≡ 550→≡ 551→≡ 552→≡ 553→≡ 554→≡ 555→≡ 556→≡ 557→≡ 558→≡ 559→≡ 560→≡ 561→≡ 562→≡ 563→≡ 564→≡ 565→≡ 566→≡ 567→≡ 568→≡ 569→≡ 570→≡ 571→≡ 572→≡ 573→≡ 574→≡ 575→≡ 576→≡ 577→≡ 578→