



# EG96-NAX

## Hardware Design

**LTE Standard Module Series**

Version: 1.0.0

Date: 2024-01-17

Status: Preliminary



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local offices. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>.

Or email us at: [support@quectel.com](mailto:support@quectel.com).

## Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an "as available" basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

## Use and Disclosure Restrictions

### License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

### Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

## Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

## Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

## Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

## Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2024. All rights reserved.**

## Safety Information

The following safety precautions must be observed during all phases of operation, such as usage, service or repair of any terminal or mobile incorporating the module. Manufacturers of the terminal should notify users and operating personnel of the following safety information by incorporating these guidelines into all manuals of the product. Otherwise, Quectel assumes no liability for customers' failure to comply with these precautions.



Full attention must be paid to driving at all times in order to reduce the risk of an accident. Using a mobile while driving (even with a handsfree kit) causes distraction and can lead to an accident. Please comply with laws and regulations restricting the use of wireless devices while driving.



Switch off the terminal or mobile before boarding an aircraft. The operation of wireless appliances in an aircraft is forbidden to prevent interference with communication systems. If there is an Airplane Mode, it should be enabled prior to boarding an aircraft. Please consult the airline staff for more restrictions on the use of wireless devices on an aircraft.



Wireless devices may cause interference on sensitive medical equipment, so please be aware of the restrictions on the use of wireless devices when in hospitals, clinics or other healthcare facilities.



Terminals or mobiles operating over radio signal and cellular network cannot be guaranteed to connect in certain conditions, such as when the mobile bill is unpaid or the (U)SIM card is invalid. When emergency help is needed in such conditions, use emergency call if the device supports it. In order to make or receive a call, the terminal or mobile must be switched on in a service area with adequate cellular signal strength. In an emergency, the device with emergency call function cannot be used as the only contact method considering network connection cannot be guaranteed under all circumstances.



The terminal or mobile contains a transceiver. When it is ON, it receives and transmits radio frequency signals. RF interference can occur if it is used close to TV sets, radios, computers or other electric equipment.



In locations with explosive or potentially explosive atmospheres, obey all posted signs and turn off wireless devices such as mobile phone or other terminals. Areas with explosive or potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust or metal powders.

# About the Document

## Revision History

| Version | Date       | Author                             | Description              |
|---------|------------|------------------------------------|--------------------------|
| -       | 2023-12-27 | Falcon Li/Woping WANG/<br>Gavin LU | Creation of the document |
| 1.0.0   | 2024-01-17 | Falcon Li/Woping WANG/<br>Gavin LU | Preliminary              |

## Contents

|   |    |
|---|----|
| <b>Safety Information</b> .....   | 3  |
| <b>About the Document</b> .....   | 4  |
| <b>Table Index</b> .....  | 8  |
| <b>Figure Index</b> .....   | 10 |
| <b>1 Introduction</b> .....   | 12 |
| <b>2 Product Overview</b> .....   | 13 |
| 2.1. Frequency Bands and Functions .....                                    | 13 |
| 2.2. Key Features .....   | 14 |
| 2.3. Pin Assignment .....   | 16 |
| 2.4. Pin Description .....  | 17 |
| 2.5. EVB Kit .....  | 22 |
| <b>3 Operating Characteristics</b> .....                                    | 23 |
| 3.1. Operating Modes .....  | 23 |
| 3.2. Sleep Mode .....   | 24 |
| 3.2.1. UART Application Scenario .....                                      | 24 |
| 3.2.2. USB Application Scenarios .....                                      | 25 |
| 3.2.2.1. USB Application with USB Remote Wakeup Function .....              | 25 |
| 3.2.2.2. USB Application with USB Suspend/Resume and MAIN_RI Function ..... | 26 |
| 3.2.2.3. USB Application without USB Suspend Function .....                 | 26 |
| 3.3. Airplane Mode .....  | 27 |
| 3.4. Power Supply .....   | 28 |
| 3.4.1. Power Supply Pins .....  | 28 |
| 3.4.2. Reference Design for Power Supply .....                              | 28 |
| 3.4.3. Voltage Stability Requirements .....                                 | 29 |
| 3.4.4. Power Supply Voltage Monitoring .....                                | 30 |
| 3.5. Turn-On .....  | 30 |
| 3.5.1. Turn-On with PWRKEY .....  | 30 |
| 3.6. Turn-Off .....   | 32 |
| 3.6.1. Turn-Off with PWRKEY .....   | 32 |
| 3.6.2. Turn-Off with AT Command .....                                       | 33 |
| 3.7. Reset .....  | 33 |
| <b>4 Application Interfaces</b> .....                                       | 36 |
| 4.1. USB Interface .....  | 36 |
| 4.2. USB_BOOT .....   | 37 |
| 4.3. USIM Interfaces .....  | 39 |
| 4.4. UARTs .....  | 41 |
| 4.5. PCM and I2C Interfaces .....   | 43 |
| 4.6. ADC Interface .....  | 46 |

|   |           |
|---|-----------|
| 4.7. SPI .....  | 46        |
| 4.8. Indication Signals .....                             | 47        |
| 4.8.1. Network Status Indication .....                    | 47        |
| 4.8.2. STATUS .....                                       | 48        |
| 4.8.3. MAIN_RI .....                                      | 49        |
| <b>5 RF Specifications .....</b>                          | <b>50</b> |
| 5.1. Cellular Network .....                               | 50        |
| 5.1.1. Antenna Interface & Frequency Bands .....          | 50        |
| 5.1.2. Antenna Tuner Control Interface .....              | 51        |
| 5.1.3. Transmitting Power .....                           | 51        |
| 5.1.4. Receiver Sensitivity .....                         | 52        |
| 5.1.5. Reference Design .....                             | 52        |
| 5.2. GNSS (Optional) .....                                | 53        |
| 5.2.1. Antenna Interface & Frequency Bands .....          | 53        |
| 5.2.2. GNSS Performance .....                             | 54        |
| 5.2.3. Reference Design .....                             | 55        |
| 5.2.3.1. GNSS Active Antenna .....                        | 55        |
| 5.2.3.2. GNSS Passive Antenna .....                       | 55        |
| 5.3. RF Routing Guidelines .....                          | 56        |
| 5.4. Requirements for Antenna Design .....                | 58        |
| 5.5. RF Connector Recommendation .....                    | 59        |
| <b>6 Electrical Characteristics and Reliability .....</b> | <b>62</b> |
| 6.1. Absolute Maximum Ratings .....                       | 62        |
| 6.2. Power Supply Ratings .....                           | 62        |
| 6.3. Power Consumption .....                              | 63        |
| 6.4. Digital I/O Characteristics .....                    | 64        |
| 6.5. ESD Protection .....                                 | 64        |
| 6.6. Operating and Storage Temperatures .....             | 65        |
| <b>7 Mechanical Information .....</b>                     | <b>66</b> |
| 7.1. Mechanical Dimensions .....                          | 66        |
| 7.2. Recommended Footprint .....                          | 68        |
| 7.3. Top and Bottom Views .....                           | 69        |
| <b>8 Storage, Manufacturing &amp; Packaging .....</b>     | <b>70</b> |
| 8.1. Storage Conditions .....                             | 70        |
| 8.2. Manufacturing and Soldering .....                    | 71        |
| 8.3. Packaging Specification .....                        | 72        |
| 8.3.1. Carrier Tape .....                                 | 73        |
| 8.3.2. Plastic Reel .....                                 | 73        |
| 8.3.3. Mounting Direction .....                           | 74        |
| 8.3.4. Packaging Process .....                            | 75        |
| <b>9 Appendix References .....</b>                        | <b>76</b> |

---

|                 |    |
|-----------------|----|
| 10 Waring ..... | 79 |
|-----------------|----|

## Table Index

|  |    |
|--|----|
| Table 1: Brief Introduction .....  | 13 |
| Table 2: Frequency Bands and Functions .....   | 13 |
| Table 3: Key Features .....  | 14 |
| Table 4: Parameter Definition .....  | 17 |
| Table 5: Pin Definition .....  | 17 |
| Table 6: Operating Modes Overview .....  | 23 |
| Table 7: VBAT and GND Pins .....   | 28 |
| Table 8: Pin Definition of PWRKEY .....  | 30 |
| Table 9: Pin Definition of RESET_N .....   | 34 |
| Table 10: Pin Definition of USB Interface .....  | 36 |
| Table 11: Pin Definition of USB_BOOT .....   | 38 |
| Table 12: Pin Definition of USIM Interfaces .....  | 39 |
| Table 13: UART Information .....   | 41 |
| Table 14: Pin Definition of Main UART .....  | 41 |
| Table 15: Pin Definition of Main UART .....  | 42 |
| Table 16: Pin Definition of PCM Interface .....  | 45 |
| Table 17: Pin Definition of I2C Interface .....  | 45 |
| Table 18: Pin Definition of ADC Interface .....  | 46 |
| Table 19: Characteristics of ADC Interface .....   | 46 |
| Table 20: Pin Definition of SPI .....  | 47 |
| Table 21: Pin Definition of Indication Signals .....                                     | 47 |
| Table 22: Network Status Indication Pin Level and Module Network Status .....            | 48 |
| Table 23: MAIN_RI Level and Module Status .....  | 49 |
| Table 24: Pin Definition of Cellular Antenna Interface .....                             | 50 |
| Table 25: Operating Frequency (Unit: MHz) .....  | 50 |
| Table 26: Pin Definition of GRFC Interface .....   | 51 |
| Table 27: Truth Table of GRFC Interfaces (Unit: MHz) .....                               | 51 |
| Table 28: RF Transmitting Power .....  | 51 |
| Table 29: Pin Definition of GNSS Antenna Interface .....                                 | 53 |
| Table 30: GNSS Frequency (Unit: MHz) .....   | 53 |
| Table 31: GNSS Performance .....   | 54 |
| Table 32: Requirements for Antenna Design .....  | 58 |
| Table 33: Absolute Maximum Ratings .....   | 62 |
| Table 34: Module's Power Supply Ratings .....  | 62 |
| Table 35: Power Consumption .....  | 63 |
| Table 36: VDD_EXT I/O Characteristics (Unit: V) .....                                    | 64 |
| Table 37: USIM Low/High-voltage I/O Characteristics (Unit: V) .....                      | 64 |
| Table 38: ESD Characteristics (Temperature: 25–30 °C, Humidity: 40 ±5 %; Unit: kV) ..... | 64 |
| Table 39: Operating and Storage Temperatures (Unit: °C) .....                            | 65 |
| Table 40: Recommended Thermal Profile Parameters .....                                   | 72 |
| Table 41: Carrier Tape Dimension Table (Unit: mm) .....                                  | 73 |

---

|   |    |
|---|----|
| Table 42: Plastic Reel Dimension Table (Unit: mm) ..... | 74 |
| Table 43: Related Documents .....                       | 76 |
| Table 44: Terms and Abbreviations .....                 | 76 |

## Figure Index

|  |           |
|--|-----------|
| Figure 1: Functional Diagram .....   | 错误！未定义书签。 |
| Figure 2: Pins Assignment (Top View) .....   | 16        |
| Figure 3: Module Power Consumption in Sleep Mode .....                                     | 24        |
| Figure 4: Block Diagram of UART Application in Sleep Mode .....                            | 24        |
| Figure 5: Block Diagram of Application with USB Remote Wakeup Function in Sleep Mode ..... | 25        |
| Figure 6: Block Diagram of Application with RI Function in Sleep Mode .....                | 26        |
| Figure 7: Block Diagram of Application without USB Suspend Function in Sleep Mode .....    | 27        |
| Figure 8: Reference Design of Power Input .....  | 29        |
| Figure 9: Reference Design of Power Supply .....   | 30        |
| Figure 10: Reference Design of Turn-On with Driving Circuit .....                          | 31        |
| Figure 11: Reference Design of Turn-On with Button .....                                   | 31        |
| Figure 12: Timing of Turn-On with PWRKEY .....   | 32        |
| Figure 13: Timing of Turn-Off with PWRKEY .....  | 33        |
| Figure 14: Reference Design of Reset with Driving Circuit .....                            | 34        |
| Figure 15: Reference Design of Reset with Button .....                                     | 34        |
| Figure 16: Timing of Reset .....   | 35        |
| Figure 17: Reference Design of USB Interface .....   | 37        |
| Figure 18: Reference Design of USB_BOOT .....  | 38        |
| Figure 19: Timing of Entering Forced Download Mode .....                                   | 38        |
| Figure 20: Reference Design of USIM Interfaces with an 8-pin USIM Card Connector .....     | 40        |
| Figure 21: Reference Design of USIM Interfaces with a 6-pin USIM Card Connector .....      | 40        |
| Figure 22: Reference Design of UART with a Level-shifting Chip (Main UART) .....           | 42        |
| Figure 23: Reference Design of UART with Transistor Circuit (Main UART) .....              | 43        |
| Figure 24: Timing of Short Frame Mode .....  | 44        |
| Figure 25: Timing of Long Frame Mode .....   | 44        |
| Figure 26: Reference Design of PCM and I2C Interfaces .....                                | 45        |
| Figure 27: Reference Design of SPI with a Level-Shifting Chip .....                        | 47        |
| Figure 28: Reference Design of Network Status Indication .....                             | 48        |
| Figure 29: Reference Design of STATUS .....  | 48        |
| Figure 30: Reference Design of Main Antenna and Diversity Antenna .....                    | 52        |
| Figure 31: Reference Design of GNSS Active Antenna .....                                   | 55        |
| Figure 32: Reference Design of GNSS Passive Antenna .....                                  | 56        |
| Figure 33: Microstrip Design on a 2-layer PCB .....  | 57        |
| Figure 34: Coplanar Waveguide Design on a 2-layer PCB .....                                | 57        |
| Figure 35: Coplanar Waveguide Design on a 4-layer PCB (Layer 3 as Reference Ground) .....  | 57        |
| Figure 36: Coplanar Waveguide Design on a 4-layer PCB (Layer 4 as Reference Ground) .....  | 58        |
| Figure 37: Dimensions of the Receptacle (Unit: mm) .....                                   | 60        |
| Figure 38: Specifications of Mated Plugs (Unit: mm) .....                                  | 60        |
| Figure 39: Space Factor of the Mated Connectors (Unit: mm) .....                           | 61        |
| Figure 40: Top and Side Dimensions .....   | 66        |
| Figure 41: Bottom Dimensions .....   | 67        |

---

|   |    |
|---|----|
| Figure 42: Recommended Footprint .....                        | 68 |
| Figure 43: Top & Bottom Views of the Module .....             | 69 |
| Figure 44: Recommended Reflow Soldering Thermal Profile ..... | 71 |
| Figure 45: Carrier Tape Dimension Drawing (Unit: mm) .....    | 73 |
| Figure 46: Plastic Reel Dimension Drawing .....               | 74 |
| Figure 47: Mounting Direction .....                           | 74 |
| Figure 48: Packaging Process .....                            | 75 |

# 1 Introduction

This document describes the EG96-NAX module features, performance, and air interfaces and hardware interfaces connected to your applications. The document provides a quick insight into interface specifications, RF performance, electrical and mechanical specifications, and other module information, as well.

## 2 Product Overview

The module is an SMD module with compact packaging.

**Table 1: Brief Introduction**

| Item           | Description  |
|----------------|--|
| Packaging type | LGA  |
| Pin counts     | 102 pins   |
| Dimensions     | (26.5 $\pm$ 0.2) mm x (22.5 $\pm$ 0.2) mm x (2.3 $\pm$ 0.2) mm |
| Weight         | 3.8 g  |

### 2.1. Frequency Bands and Functions

**Table 2: Frequency Bands and Functions**

| Technology      | EG96-NAX                         |
|-----------------|----------------------------------|
| LTE-FDD         | B2/B4/B5/B12/B13/B66/B71         |
| GNSS (Optional) | GPS, GLONASS, BDS, Galileo, QZSS |

## 2.2. Key Features

Table 3: Key Features

| Feature         | Capability   |
|-----------------|--|
| Supply Voltage  | <ul style="list-style-type: none"> <li>● 3.3–4.3 V</li> <li>● Typ.: 3.8 V</li> </ul>   |
| SMS             | <ul style="list-style-type: none"> <li>● Text and PDU mode</li> <li>● Point-to-point MO and MT</li> <li>● SMS cell broadcast</li> <li>● SMS storage: ME by default</li> </ul>  |
| USB Interface   | <ul style="list-style-type: none"> <li>● One USB interface</li> <li>● Complies with USB 2.0 specification (slave mode only)</li> <li>● Data rate: up to 480 Mbps</li> <li>● Use: AT command communication, data transmission, GNSS NMEA sentence output, software debugging, firmware upgrade and voice over USB</li> <li>● USB serial drivers under Windows 8/8.1/10/11, Linux 2.6–6.5 and Android 4.x–13.x systems</li> </ul>  |
| USIM Interfaces | <ul style="list-style-type: none"> <li>● Two USIM interfaces</li> <li>● 1.8 V and 3.0 V</li> <li>● Dual SIM Single Standby</li> </ul>  |
| UARTs           | <ul style="list-style-type: none"> <li>● Two UARTs</li> </ul> <p><b>Main UART:</b></p> <ul style="list-style-type: none"> <li>● Use: AT command communication and data transmission</li> <li>● Baud rates reach up to 921600 bps, 115200 bps by default</li> <li>● RTS and CTS hardware flow control</li> </ul> <p><b>Debug UART:</b></p> <ul style="list-style-type: none"> <li>● Use: Linux console, log output and software debugging</li> <li>● Baud rate: 115200 bps</li> </ul> |
| Audio Features  | <ul style="list-style-type: none"> <li>● LTE: AMR and AMR-WB</li> <li>● Echo cancellation and noise suppression</li> </ul>   |
| PCM Interface   | <ul style="list-style-type: none"> <li>● Use: audio data transmission between the module and the external codec</li> <li>● 16-bit linear data format</li> <li>● Long and short frame synchronization</li> <li>● Master and slave modes (but must be in master mode for long frame synchronization)</li> </ul>  |
| SPI             | <ul style="list-style-type: none"> <li>● One SPI</li> <li>● Master mode only</li> <li>● One-to-one connection, without chip selection</li> <li>● Clock rate: up to 50 MHz</li> </ul>   |

|                            |   |
|----------------------------|---|
|                            | <b>NET_STATUS:</b>  |
| Network Indication         | <ul style="list-style-type: none"> <li>● Use: network activity status indication</li> </ul>   |
| AT Commands                | <ul style="list-style-type: none"> <li>● Complies with the AT commands defined in 3GPP TS 27.007 and 3GPP TS 27.005</li> <li>● Complies with Quectel enhanced AT commands</li> </ul>  |
| Rx-diversity               | LTE Rx-diversity  |
| Antenna Interfaces         | <ul style="list-style-type: none"> <li>● One main antenna interface (ANT_MAIN)</li> <li>● One Rx-diversity antenna interface (ANT_DRX)</li> <li>● One GNSS antenna interface (ANT_GNSS)</li> <li>● 50 Ω characteristic impedance</li> </ul> |
| Transmitting Power         | <ul style="list-style-type: none"> <li>● LTE-FDD: Class 3 (23 dBm ±2 dB)</li> <li>● Complies with 3GPP Rel-8 specification</li> <li>● Max. LTE category: Cat 4</li> <li>● 1.4/3/5/10/15/20 MHz RF bandwidths</li> </ul>                     |
| LTE Features               | <ul style="list-style-type: none"> <li>● Modulations: <ul style="list-style-type: none"> <li>- DL: QPSK, 16QAM and 64QAM</li> <li>- UL: QPSK, 16QAM</li> </ul> </li> <li>● LTE-FDD max. data rates: 150 Mbps (DL)/50 Mbps (UL)</li> </ul>   |
| GNSS Features (Optional)   | <ul style="list-style-type: none"> <li>● GPS, GLONASS, BDS, Galileo and QZSS</li> <li>● Complies with NMEA 0183 protocol</li> <li>● The data update rate is 1 Hz by default and 10 Hz maximally</li> </ul>                                  |
| Internet Protocol Features | <ul style="list-style-type: none"> <li>● Complies with TCP, UDP, PPP, NTP, NITZ, FTP, HTTP, PING, QMI, CMUX, HTTPS, FTPS, SSL, FILE, MQTT, MMS, SMTP and SMTPS protocols</li> <li>● PAP and CHAP for PPP connections</li> </ul>             |
| Temperature Ranges         | <ul style="list-style-type: none"> <li>● Normal operating temperature <sup>1</sup>: -35 °C to +75 °C</li> <li>● Extended operating temperature <sup>2</sup>: -40 °C to +85 °C</li> <li>● Storage temperature: -40 °C to +90 °C</li> </ul>   |
| Firmware Upgrade           | <ul style="list-style-type: none"> <li>● USB 2.0 interface</li> <li>● DFOTA</li> </ul>  |
| RoHS                       | All hardware components are fully compliant with EU RoHS directive  |

<sup>1</sup> Within this range, the module's indicators comply with 3GPP specification requirements.

<sup>2</sup> Within this range, the module retains the ability to establish and maintain functions such as voice and SMS, without any unrecoverable malfunction. Radio spectrum and radio network remain uninfluenced, whereas the value of one or more parameters, such as  $P_{out}$ , may decrease and fall below the range of the 3GPP specified tolerances. When the temperature returns to the normal operating temperature range, the module's indicators will comply with 3GPP specification requirements again.

## 2.3. Pin Assignment




Figure 1: Pins Assignment (Top View)

### NOTE

1. Keep all RESERVED and unused pins unconnected.
2. Ensure that the pull-up power supply of the module's pins is VDD\_EXT or controlled by VDD\_EXT, and there is no current sink on the module's pins before the module turns on. For more details, contact Quectel Technical Support.

## 2.4. Pin Description

Table 4: Parameter Definition

| Parameter | Description          |
|-----------|----------------------|
| AI        | Analog Input         |
| AIO       | Analog Input/Output  |
| DI        | Digital Input        |
| DO        | Digital Output       |
| DIO       | Digital Input/Output |
| OD        | Open Drain           |
| PI        | Power Input          |
| PO        | Power Output         |

DC characteristics include power domain and rated current.

Table 5: Pin Definition

| Power Supply |         |     |                                       |  |   |  |
|--------------|---------|-----|---------------------------------------|--|---|--|
| Pin Name     | Pin No. | I/O | Description                           | DC Characteristic                            | Comment   |  |
| VBAT_BB      | 32, 33  | PI  | Power supply for the module's BB part | Vmax = 4.3 V<br>Vmin = 3.3 V<br>Vnom = 3.8 V | It must be provided with sufficient current up to 0.8 A.<br>A test point is recommended to be reserved.                         |  |
| VBAT_RF      | 52, 53  | PI  | Power supply for the module's RF part |  | It must be provided with sufficient current up to 1.8 A in a burst transmission.<br>A test point is recommended to be reserved. |  |
| VDD_EXT      | 29      | PO  | Provide 1.8 V for external circuit    | Vnom = 1.8 V<br>Iomax = 50 mA                | Power supply for external GPIO's pull-up  |  |

circuits.

A test point is recommended to be reserved.

GND 3, 31, 47, 48, 50, 54, 55, 58, 59, 61, 62, 67–74, 79–82, 89–91, 100–102

#### Turn On/Off

| Pin Name | Pin No. | I/O | Description            | DC Characteristic  | Comment   |
|----------|---------|-----|------------------------|--|---|
| PWRKEY   | 15      | DI  | Turn on/off the module |  | The output voltage is 0.8 V because of the diode drop in the baseband chipset.<br>A test point is recommended to be reserved. |
| RESET_N  | 17      | DI  | Reset the module       | $V_{nom} = 1.8 \text{ V}$<br>$V_{IHmax} = 2.1 \text{ V}$<br>$V_{IHmin} = 1.3 \text{ V}$<br>$V_{ILmax} = 0.5 \text{ V}$ | A test point is recommended to be reserved if unused.   |

#### Indication Interfaces

| Pin Name   | Pin No. | I/O | Description                                   | DC Characteristic | Comment                    |
|------------|---------|-----|---|-------------------|----------------------------|
| STATUS     | 20      | DO  | Indicate the module's operation status        | VDD_EXT           | If unused, keep them open. |
| NET_STATUS | 21      | DO  | Indicate the module's network activity status |                   |                            |

#### USB Interface

| Pin Name | Pin No. | I/O | Description                   | DC Characteristic  | Comment   |
|----------|---------|-----|-------------------------------|--|---|
| USB_VBUS | 8       | AI  | USB connection detect         | $V_{max} = 5.25 \text{ V}$<br>$V_{min} = 3.0 \text{ V}$<br>$V_{nom} = 5.0 \text{ V}$ | A test point must be reserved.                  |
| USB_DP   | 9       | AIO | USB 2.0 differential data (+) |  | Require differential impedance of $90 \Omega$ . |
| USB_DM   | 10      | AIO | USB 2.0 differential data (-) |  | Test points must be reserved.                   |

#### USIM Interfaces

| Pin Name  | Pin No. | I/O | Description      | DC Characteristic          | Comment                  |
|-----------|---------|-----|------------------|----------------------------|--------------------------|
| USIM1_VDD | 43      | PO  | USIM1 card power | $I_{omax} = 50 \text{ mA}$ | Either 1.8 V or 3.0 V is |

|            |    |     |                            |  |   |
|------------|----|-----|----------------------------|--|---|
|            |    |     | supply                     |  |   |
|            |    |     |                            | <b>Low-voltage:</b><br>Vmax = 1.9 V<br>Vnom = 1.8 V<br>Vmin = 1.7 V    | supported by the module automatically.                          |
|            |    |     |                            | <b>High-voltage:</b><br>Vmax = 3.05 V<br>Vnom = 2.85 V<br>Vmin = 2.7 V |   |
| USIM1_DATA | 45 | DIO | USIM1 card data            |  |   |
| USIM1_CLK  | 46 | DO  | USIM1 card clock           | USIM1_VDD  |   |
| USIM1_RST  | 44 | DO  | USIM1 card reset           |  |   |
| USIM1_DET  | 42 | DI  | USIM1 card hot-plug detect | VDD_EXT  | If unused, keep it open.  |
|            |    |     |                            | I <sub>max</sub> = 50 mA   |   |
| USIM2_VDD  | 87 | PO  | USIM2 card power supply    | <b>Low-voltage:</b><br>Vmax = 1.9 V<br>Vnom = 1.8 V<br>Vmin = 1.7 V    | Either 1.8 V or 3.0 V is supported by the module automatically. |
|            |    |     |                            | <b>High-voltage:</b><br>Vmax = 3.05 V<br>Vnom = 2.85 V<br>Vmin = 2.7 V |   |
| USIM2_DATA | 86 | DIO | USIM2 card data            |  |   |
| USIM2_CLK  | 84 | DO  | USIM2 card clock           | USIM2_VDD  |   |
| USIM2_RST  | 85 | DO  | USIM2 card reset           |  | If unused, keep them open.                                      |
| USIM2_DET  | 83 | DI  | USIM2 card hot-plug detect | VDD_EXT  |   |

### Main UART

| Pin Name | Pin No. | I/O | Description                          | DC Characteristic | Comment  |
|----------|---------|-----|--------------------------------------|-------------------|--|
| MAIN_CTS | 36      | DO  | Clear to send signal from the module | VDD_EXT           | If unused, keep it open. Connect to the MCU's CTS. |
| MAIN_RTS | 37      | DI  | Request to send signal to the module |                   | If unused, keep it open. Connect to the MCU's      |

|                              |         |     |                                       |                   | RTS.  |
|------------------------------|---------|-----|---------------------------------------|-------------------|---|
| MAIN_RXD                     | 34      | DI  | Main UART receive                     |                   |   |
| MAIN_DCD                     | 38      | DO  | Main UART data carrier detect         |                   | If unused, keep them open.  |
| MAIN_TXD                     | 35      | DO  | Main UART transmit                    |                   |   |
| MAIN_RI                      | 39      | DO  | Main UART ring indication             |                   |   |
| MAIN_DTR                     | 30      | DI  | Main UART data terminal ready         |                   | Pulled up by default.<br>The pin can wake up the module in the low level.<br>If unused, keep it open. |
| <b>Debug UART</b>            |         |     |                                       |                   |   |
| Pin Name                     | Pin No. | I/O | Description                           | DC Characteristic | Comment   |
| DBG_RXD                      | 22      | DI  | Debug UART receive                    | VDD_EXT           | Test points must be reserved.   |
| DBG_TXD                      | 23      | DO  | Debug UART transmit                   |                   |   |
| <b>I2C Interface</b>         |         |     |                                       |                   |   |
| Pin Name                     | Pin No. | I/O | Description                           | DC Characteristic | Comment   |
| I2C_SCL                      | 40      | OD  | I2C serial clock (for external codec) | VDD_EXT           | Externally pulled up to 1.8 V.<br>If unused, keep them open.  |
| I2C_SDA                      | 41      | OD  | I2C serial data (for external codec)  |                   |   |
| <b>PCM Interface</b>         |         |     |                                       |                   |   |
| Pin Name                     | Pin No. | I/O | Description                           | DC Characteristic | Comment   |
| PCM_SYNC                     | 5       | DIO | PCM data frame sync                   |                   | Master mode: output.<br>Slave mode: input.  |
| PCM_CLK                      | 4       | DIO | PCM clock                             | VDD_EXT           | If unused, keep them open.  |
| PCM_DIN                      | 6       | DI  | PCM data input                        |                   |   |
| PCM_DOUT                     | 7       | DO  | PCM data output                       |                   | If unused, keep them open.  |
| <b>RF Antenna Interfaces</b> |         |     |                                       |                   |   |
| Pin Name                     | Pin No. | I/O | Description                           | DC Characteristic | Comment   |
| ANT_MAIN                     | 60      | AIO | Main antenna interface                |                   | 50 Ω impedance.   |

|          |    |    |                             |   |
|----------|----|----|-----------------------------|---|
| ANT_DRX  | 56 | AI | Diversity antenna interface | 50 Ω impedance.<br>If unused, keep them open. |
| ANT_GNSS | 49 | AI | GNSS antenna interface      |   |

**Antenna Tuner Control Interfaces**

| Pin Name | Pin No. | I/O | Description           | DC Characteristic | Comment                    |
|----------|---------|-----|-----------------------|-------------------|----------------------------|
| GRFC1    | 76      | DO  | Generic RF Controller |                   |                            |
| GRFC2    | 77      | DO  | Generic RF Controller |                   | If unused, keep them open. |

**SPI**

| Pin Name | Pin No. | I/O | Description     | DC Characteristic | Comment                    |
|----------|---------|-----|-----------------|-------------------|----------------------------|
| SPI_CLK  | 26      | DO  | SPI clock       |                   |                            |
| SPI_DIN  | 28      | DI  | SPI data input  | VDD_EXT           | If unused, keep them open. |
| SPI_DOUT | 27      | DO  | SPI data output |                   |                            |

**ADC Interface**

| Pin Name | Pin No. | I/O | Description                   | DC Characteristic               | Comment                  |
|----------|---------|-----|-------------------------------|---------------------------------|--------------------------|
| ADC      | 24      | AI  | General-purpose ADC interface | Voltage range: 0.3 V to VBAT_BB | If unused, keep it open. |

**Other Interfaces**

| Pin Name   | Pin No. | I/O | Description                         | DC Characteristic | Comment   |
|------------|---------|-----|-------------------------------------|-------------------|---|
| USB_BOOT   | 75      | DI  | Force the module into download mode | VDD_EXT           | Cannot be pulled up before startup.<br>A test point is recommended to be reserve. |
| W_DISABLE# | 18      | DI  | Airplane mode control               |                   | Pulled up by default.<br>If unused, keep it open.                                 |
| AP_READY   | 19      | DI  | Application processor ready         |                   | If unused, keep it open.  |

**RESERVED Pins**

| Pin Name | Pin No.   |
|----------|---|
| RESERVED | 1, 2, 11–14, 16, 25, 51, 57, 63–66, 78, 88, 92–99 |

**NOTE**

1. Keep all RESERVED pins and unused pins unconnected.
2. BOOT\_CONFIG pins (SPI\_CLK, USB\_BOOT, PCM\_CLK, PCM\_SYNC, GRFC1) cannot be pulled up before startup.

## 2.5. EVB Kit

Quectel supplies an evaluation board (UMTS&LTE EVB) with accessories to develop and test the module. For more details, see ***document [1]***.

# 3 Operating Characteristics

## 3.1. Operating Modes

Table 6: Operating Modes Overview

| Modes                      | Descriptions  |
|----------------------------|---|
| Full Functionality Mode    | Idle<br>The module remains registered on the network but has no data interaction with the network. In this mode, the software is active.                            |
|                            | Voice/Data<br>The module is connected to the network. In this mode, the power consumption is decided by network settings and data rates.                            |
| Minimum Functionality Mode | <b>AT+CFUN=0</b> can set the module to the minimum functionality mode without removing the power supply. In this mode, both USIM card and RF function are disabled. |
| Airplane Mode              | <b>AT+CFUN=4</b> or W_DISABLE# can set the module to airplane mode. In this mode, RF function is disabled and all relevant AT commands are inaccessible.            |
| Sleep Mode                 | The module can still receive paging, SMS, voice call and TCP/UDP data from the network. In this mode, the power consumption will be reduced to an ultra-low level.  |
| Shutdown Mode              | PMU shuts down the power supply. In this mode, software is not active. However, the voltage supply (for VBAT_RF and VBAT_BB) remains connected.                     |

**NOTE**

For more details about **AT+CFUN**, see **document [2]**.

### 3.2. Sleep Mode

With DRX technology, power consumption of the module will be reduced to an ultra-low level.




Figure 2: Module Power Consumption in Sleep Mode

**NOTE**

DRX cycle values are transmitted over the wireless network.

#### 3.2.1. UART Application Scenario

If the module communicates with the MCU via main UART, both the following preconditions should be met to set the module to sleep mode:

- Execute **AT+QSCLK=1**. See **document [2]** for details.
- Ensure **MAIN\_DTR** is held high or is kept unconnected.




Figure 3: Block Diagram of UART Application in Sleep Mode

- Driving MAIN\_DTR low with the MCU will wake up the module.
- When the module has a URC to report, MAIN\_RI signal will wake up the MCU. See **Chapter 4.8.3** for details about MAIN\_RI.
- AP\_READY will detect the sleep state of the MCU (It can be configured to high or low level detection via **AT+QCFG="already"**). For details, see **document [3]**.

**NOTE**

Pay attention to the level match shown in the dotted line between the module and the MCU.

### 3.2.2. USB Application Scenarios

For the two situations ('USB application with USB remote wakeup function' and 'USB application with USB Suspend/Resume and RI function') below, three preconditions must be met to set the module to sleep mode:

- Execute **AT+QSCLK=1**.
- Ensure MAIN\_DTR is held high or is kept unconnected.
- Ensure the host's USB bus, which is connected to the module's USB interface, enters Suspend state.

Sending data to the module through USB will wake up the module.

#### 3.2.2.1. USB Application with USB Remote Wakeup Function

The host supports USB Suspend/Resume and remote wakeup function.




Figure 4: Block Diagram of Application with USB Remote Wakeup Function in Sleep Mode

When the module has a URC to report, the module will send remote wake-up signals through USB bus to wake up the host.

### 3.2.2.2. USB Application with USB Suspend/Resume and MAIN\_RI Function

If the host supports USB Suspend/Resume, but does not support remote wakeup function, the MAIN\_RI signal is needed to wake up the host.




Figure 5: Block Diagram of Application with RI Function in Sleep Mode

When the module has a URC to report, the module will wake up the host through MAIN\_RI signal.

### 3.2.2.3. USB Application without USB Suspend Function

If the host does not support USB Suspend function, the following three preconditions must be met to set the module to sleep mode:

- Execute **AT+QSCLK=1**.
- Ensure MAIN\_DTR is held high or is kept unconnected.
- Ensure USB\_VBUS is disconnected via the external control circuit.




Figure 6: Block Diagram of Application without USB Suspend Function in Sleep Mode

Restoring the power supply of USB\_VBUS will wake up the module.

**NOTE**

1. Pay attention to the level match shown in the dotted line between the module and the host.
2. For more details about the module power management application, see **document [4]**.

### 3.3. Airplane Mode

When the module enters airplane mode, the RF function does not work and all AT commands related to the RF function are inaccessible. The following ways can be used to let the module enter airplane mode.

#### Hardware:

The W\_DISABLE# pin is pulled up by default. Its control function for airplane mode is disabled by default, and **AT+QCFG="airplanecontrol",1** can be used to enable the function. Driving the pin low after its control function for airplane mode is enabled by AT command, which can make the module enter the airplane mode.

#### Software:

**AT+CFUN=<fun>** provides the choice of the functionality level through setting **<fun>** into 0, 1 or 4.

- **AT+CFUN=0:** Minimum functionality mode (disable USIM and RF functions).
- **AT+CFUN=1:** Full functionality mode (by default).
- **AT+CFUN=4:** Airplane mode (disable RF function).

**NOTE**

1. The execution of **AT+CFUN** does not affect GNSS function.
2. For details about **AT+QCFG**, see **document [3]**.

## 3.4. Power Supply

### 3.4.1. Power Supply Pins

The module has four VBAT pins dedicated to connecting with the external power supply.

**Table 7: VBAT and GND Pins**

| Pin Name | Pin No.   | Description                           | Min. | Typ. | Max. | Unit |
|----------|---|---------------------------------------|------|------|------|------|
| VBAT_BB  | 32, 33  | Power supply for the module's BB part | 3.3  | 3.8  | 4.3  | V    |
| VBAT_RF  | 52, 53  | Power supply for the module's RF part | 3.3  | 3.8  | 4.3  | V    |
| GND      | 3, 31, 47, 48, 50, 54, 55, 58, 59, 61, 62, 67–74, 79–82, 89–91, 100–102 |                                       |      |      |      |      |

### 3.4.2. Reference Design for Power Supply

The performance of the module largely depends on the power supply design. The power supply of the module should be able to provide sufficient current of 2.0 A at least. If the voltage difference between input voltage and the supply voltage is small, it is suggested to use an LDO; if the voltage difference is big, a buck converter is recommended.

The following figure shows a reference design for +5 V input power supply. The designed output of the power supply is about 3.8 V and the maximum load current is 3.0 A.




Figure 7: Reference Design of Power Input

**NOTE**

To avoid corrupting the data in the internal flash, do not cut off the power supply to turn off the module when the module works normally. Only after turning off the module with PWRKEY or AT command can you cut off the power supply.

### 3.4.3. Voltage Stability Requirements

The power supply range of the module is from 3.3 V to 4.3 V. Ensure the input voltage never drops below 3.3 V.

To decrease the voltage drop, use a bypass capacitor of about 100  $\mu$ F with low ESR ( $ESR \leq 0.7 \Omega$ ), and reserve a multi-layer ceramic chip (MLCC) capacitor array with ultra-low ESR. Use three ceramic capacitors (100 nF, 33 pF, 100 pF for VBAT\_BB and 100 nF, 33 pF, 10 pF for VBAT\_RF) for composing the MLCC array, and place these capacitors close to the VBAT pins. The main power supply from an external application should be a single voltage source and can be expanded to two sub paths routed as the star configuration. The width of VBAT\_BB trace and VBAT\_RF trace should be at least 1 mm and 2 mm respectively. As per design rules, the longer the VBAT trace is, the wider it should be.

To avoid the ripple and surge and ensure the stability of the power supply to the module, add a TVS component with  $V_{RWM} = 4.5$  V, low clamping  $V_c$  and high reverse peak pulse current  $I_{pp}$  near the power supply.




Figure 8: Reference Design of Power Supply

### 3.4.4. Power Supply Voltage Monitoring

You can use **AT+CBC** to monitor and query the VBAT\_BB voltage. For details, see [document \[2\]](#).

## 3.5. Turn-On

### 3.5.1. Turn-On with PWRKEY

Table 8: Pin Definition of PWRKEY

| Pin Name | Pin No. | I/O | Description            | Comment   |
|----------|---------|-----|------------------------|---|
| PWRKEY   | 15      | DI  | Turn on/off the module | The output voltage is 0.8 V because of the diode drop in the baseband chipset.<br>A test point is recommended to be reserved. |

When the module is in turn-off state, it can be turned on by driving PWRKEY low for at least 500 ms. It is recommended to use an open drain/collector driver to control the PWRKEY. After STATUS outputs high-level voltage, the PWRKEY can be released.




Figure 9: Reference Design of Turn-On with Driving Circuit

The module can also be turned on by pressing the PWRKEY button. A TVS component should be placed near the button for protection against ESD, since static electricity may be generated by the finger touching.




Figure 10: Reference Design of Turn-On with Button




Figure 11: Timing of Turn-On with PWRKEY

**NOTE**

1. Ensure that VBAT is stable for at least 30 ms before driving the PWRKEY low.
2. If the module needs to turn on automatically but does not need turn-off function, PWRKEY can be driven low directly to ground with a recommended 10 kΩ resistor.
3. BOOT\_CONFIG pins (SPI\_CLK, USB\_BOOT, PCM\_CLK, PCM\_SYNC, GRFC1) cannot be pulled up before startup.

### 3.6. Turn-Off

#### 3.6.1. Turn-Off with PWRKEY

Drive PWRKEY low for at least 650 ms and then release it to turn off the module.




Figure 12: Timing of Turn-Off with PWRKEY

### 3.6.2. Turn-Off with AT Command

To turn off the module, you can also execute **AT+QPOWD**, which has similar timing and effect as turning off the module through driving PWRKEY low. For details about **AT+QPOWD**, see [document \[2\]](#).

**NOTE**

1. To avoid corrupting the data in the internal flash, do not switch off the power supply to turn off the module when the module works normally. Only after turning off the module with PWRKEY or AT command can you cut off the power supply.
2. When turning off the module with the AT command, keep PWRKEY at high level after the execution of the command. Otherwise, the module will be turned on automatically again after successful turn-off.

## 3.7. Reset

Drive RESET\_N low for at least 150-460 ms and then release it to reset the module. RESET\_N signal is sensitive to interference, consequently it is recommended to route the trace as short as possible and surround it with ground.

Table 9: Pin Definition of RESET\_N

| Pin Name | Pin No. | I/O | Description      | Comment   |
|----------|---------|-----|------------------|---|
| RESET_N  | 17      | DI  | Reset the module | A test point is recommended to be reserved if unused. |

The recommended circuit for reset function is similar to the PWRKEY control circuit. You can use an open drain/collector driver or a button to control RESET\_N.




Figure 13: Reference Design of Reset with Driving Circuit




Figure 14: Reference Design of Reset with Button




Figure 15: Timing of Reset

**NOTE**

1. Use **RESET\_N** only when you fail to turn off the module with the **AT+QPOWD** and **PWRKEY**.
2. Ensure the capacitance on **PWRKEY** and **RESET\_N** is no more than 10 nF.

# 4 Application Interfaces

## 4.1. USB Interface

The module contains one integrated Universal Serial Bus (USB) interface which complies with the USB 2.0 specification and supports high-speed (480 Mbps) and full-speed (12 Mbps) modes. The USB interface can only serve as the slave device.

USB interface is used for AT command communication, data transmission, GNSS NMEA sentence output, software debugging, firmware upgrade and voice over USB.

**Table 10: Pin Definition of USB Interface**

| Pin Name | Pin No. | I/O | Description                   | Comment                                 |
|----------|---------|-----|-------------------------------|---|
| USB_VBUS | 8       | AI  | USB connection detect         | A test point must be reserved.          |
| USB_DP   | 9       | AIO | USB 2.0 differential data (+) | Require differential impedance of 90 Ω. |
| USB_DM   | 10      | AIO | USB 2.0 differential data (-) | Test points must be reserved.           |

USB 2.0 interface can be used for firmware upgrade and test points must be reserved for debugging in your designs.




Figure 16: Reference Design of USB Interface

It is recommended to add a common-mode choke L1 in series between the MCU and the module to suppress EMI. Meanwhile, it is also suggested to add R1 and R2 in series between the module and test points for debugging. These resistors are not mounted by default. To ensure the signal integrity of USB 2.0 data transmission, you should place L1, R1 and R2 close to the module, and keep these resistors close to each other. Moreover, keep extra stubs of trace as short as possible.

To ensure performance, you should follow the following principles when designing USB interface:

- Route USB signal traces as differential pairs with surrounded ground. The impedance of USB differential trace is  $90\ \Omega$ .
- Route USB differential traces at the inner-layer of the PCB, and surround the traces with ground on that layer and ground planes above and below. For signal traces, provide clearance from power supply traces, crystal-oscillators, magnetic devices, sensitive signals, such as RF signals, analog signals, and noise signals generated by clock and DC-DC.
- Pay attention to the impact caused by stray capacitance of the ESD protection component on USB data traces. Typically, the stray capacitance should be less than 2 pF for USB.
- If possible, reserve two  $0\ \Omega$  resistors on USB\_DP and USB\_DM traces respectively.

For more details about the USB specifications, visit <http://www.usb.org/home>.

## 4.2. USB\_BOOT

The module has a USB\_BOOT for forced download. Pull up USB\_BOOT to VDD\_EXT before turning on the module, and then the module will enter forced download mode. In this mode, the module supports firmware upgrade over USB interface.

Table 11: Pin Definition of USB\_BOOT

| Pin Name | Pin No. | I/O | Description                         | Comment   |
|----------|---------|-----|-------------------------------------|---|
| USB_BOOT | 75      | DI  | Force the module into download mode | Cannot be pulled up before startup.<br>A test point is recommended to be reserve. |




Figure 17: Reference Design of USB\_BOOT




Figure 18: Timing of Entering Forced Download Mode

**NOTE**

1. Ensure VBAT is stable before driving PWRKEY low. The time period between powering VBAT up and driving PWRKEY low shall be at least 30 ms.
2. Follow the above timing when using MCU control the module to enter the forced download mode. Do not pull up USB\_BOOT to 1.8 V before powering up VBAT.
3. If you need to manually force the module to enter forced download mode, directly connect the test points shown in **Figure 17**.

### 4.3. USIM Interfaces

The module has two USIM interfaces, which support Dual SIM Single Standby and meet ETSI and IMT-2000 requirements. Either 1.8 V or 3.0 V USIM card is supported. USIM1 and USIM2 cannot work at the same time. They can be switched by **AT+QDSIM**. For more details, see **document [5]**.

**Table 12: Pin Definition of USIM Interfaces**

| Pin Name   | Pin No. | I/O | Description                | Comment   |
|------------|---------|-----|----------------------------|---|
| USIM1_VDD  | 43      | PO  | USIM1 card power supply    | Either 1.8 V or 3.0 V is supported by the module automatically. |
| USIM1_DATA | 45      | DIO | USIM1 card data            |   |
| USIM1_CLK  | 46      | DO  | USIM1 card clock           |   |
| USIM1_RST  | 44      | DO  | USIM1 card reset           |   |
| USIM1_DET  | 42      | DI  | USIM1 card hot-plug detect | If unused, keep it open.  |
| USIM2_VDD  | 87      | PO  | USIM2 card power supply    | Either 1.8 V or 3.0 V is supported by the module automatically. |
| USIM2_DATA | 86      | DIO | USIM2 card data            |   |
| USIM2_CLK  | 84      | DO  | USIM2 card clock           |   |
| USIM2_RST  | 85      | DO  | USIM2 card reset           | If unused, keep them open.                                      |
| USIM2_DET  | 83      | DI  | USIM2 card hot-plug detect |   |

The module supports USIM card hot-plug via the USIM\_DET, and both high-level and low-level detections are supported. Hot-plug function is disabled by default and you can use **AT+QSIMDET** to configure this function. For more details, see **document [2]**.




Figure 19: Reference Design of USIM Interfaces with an 8-pin USIM Card Connector

If the function of USIM card hot-plug is not needed, keep USIM\_DET unconnected.




Figure 20: Reference Design of USIM Interfaces with a 6-pin USIM Card Connector

To enhance the reliability and availability of the USIM card in applications, you should follow the principles below in the USIM circuit design:

- Place the USIM card connector close to the module. Keep the trace length less than 200 mm if possible.
- Route USIM card traces at the inner-layer of the PCB, and surround the traces with ground on that layer and ground planes above and below. For signal traces, provide clearance from power supply

traces, crystal-oscillators, magnetic devices, sensitive signals, such as RF signals, analog signals, and noise signals generated by clock and DC-DC.

- Ensure the tracing between the USIM card connector and the module is short and wide. Keep the trace width of ground and USIM\_VDD at least 0.5 mm to keep the same electric potential.
- To avoid cross talk between USIM\_DATA and USIM\_CLK, keep the traces away from each other and shield them with surrounded ground.
- To offer better ESD protection, you can add a TVS array of which the parasitic capacitance should be less than 15 pF. Add 0 Ω resistors in series between the module and the USIM card connector to facilitate debugging. Additionally, add 33 pF capacitors in parallel among USIM\_DATA, USIM\_CLK and USIM\_RST signal traces to filter out RF interference.
- For USIM\_DATA, it is recommended to add a 15 kΩ pull-up resistor near the USIM card connector to improve the anti-jamming capability of the USIM card.

## 4.4. UARTs

The module has two UART: main UART and debug UART.

**Table 13: UART Information**

| UART Types | Supported Baud Rates (bps)  | Default Baud Rates (bps) | Functions   |
|------------|---|--------------------------|---|
| Main UART  | 4800, 9600, 19200,<br>38400, 57600, 115200,<br>230400, 460800, 921600 | 115200                   | <ul style="list-style-type: none"> <li>● AT command communication</li> <li>● Data transmission</li> </ul>             |
| Debug UART | 115200  | 115200                   | <ul style="list-style-type: none"> <li>● Linux console</li> <li>● Log output</li> <li>● Software debugging</li> </ul> |

**Table 14: Pin Definition of Main UART**


| Pin Name | Pin No. | I/O | Description                          | Comment   |
|----------|---------|-----|--------------------------------------|---|
| MAIN_CTS | 36      | DO  | Clear to send signal from the module | If unused, keep it open.<br>Connect to the MCU's CTS. |
| MAIN_RTS | 37      | DI  | Request to send signal to the module | If unused, keep it open.<br>Connect to the MCU's RTS. |
| MAIN_RXD | 34      | DI  | Main UART receive                    |   |
| MAIN_DCD | 38      | DO  | Main UART data carrier detect        | If unused, keep them open.                            |
| MAIN_TXD | 35      | DO  | Main UART transmit                   |   |

|          |    |    |                               |  |
|----------|----|----|-------------------------------|--|
| MAIN_RI  | 39 | DO | Main UART ring indication     |  |
| MAIN_DTR | 30 | DI | Main UART data terminal ready | Pulled up by default.<br>The pin can wake up the module in the low level<br>If unused, keep it open. |

**Table 15: Pin Definition of Main UART**

| Pin Name | Pin No. | I/O | Description         | Comment                       |
|----------|---------|-----|---------------------|-------------------------------|
| DBG_RXD  | 22      | DI  | Debug UART receive  |                               |
| DBG_TXD  | 23      | DO  | Debug UART transmit | Test points must be reserved. |

The module has 1.8 V UART. You can use a level-shifting chip between the module and MCU's UART if the MCU is equipped with a 3.3 V UART.

**Figure 21: Reference Design of UART with a Level-shifting Chip (Main UART)**

Another example of transistor circuit is shown as below. For the design of input/output circuits in dotted lines, see that shown in solid lines, but pay attention to the direction of the connection.




Figure 22: Reference Design of UART with Transistor Circuit (Main UART)

**NOTE**

1. Transistor circuit above is not suitable for applications with baud rates exceeding 460 kbps.
2. Please note that the module's CTS is connected to the MCU's CTS, and the module's RTS is connected to the MCU's RTS.
3. The level-shifting circuits (**Figure 21** and **Figure 22**) take the main UART as an example. The circuits of the debug UART are connected in the same way as the main UART.
4. To increase the stability of UART communication, it is recommended to add UART hardware flow control design.

## 4.5. PCM and I2C Interfaces

The module has one PCM interface and one I2C interface.

The PCM interface supports the following modes:

- Short frame mode: the module works as both the slave and the master device.
- Long frame mode: the module works as the master device only.

The module supports 16-bit linear encoding format. The following figures are the short frame mode timing diagram (PCM\_SYNC = 8 kHz, PCM\_CLK = 2048 kHz) and the long frame mode timing diagram (PCM\_SYNC = 8 kHz, PCM\_CLK = 256 kHz).




Figure 23: Timing of Short Frame Mode

In short frame mode, data is sampled on the falling edge of PCM\_CLK and transmitted on the rising edge. The PCM\_SYNC falling edge represents the MSB. In this mode, PCM\_CLK supports 256 kHz, 512 kHz, 1024 kHz and 2048 kHz when PCM\_SYNC operates at 8 kHz, and also supports 4096 kHz when PCM\_SYNC operates at 16 kHz.




Figure 24: Timing of Long Frame Mode

In long frame mode, data is also sampled on the falling edge of the PCM\_CLK and transmitted on the rising edge. But in this mode, the PCM\_SYNC rising edge represents the MSB. PCM\_CLK supports 256 kHz, 512 kHz, 1024 kHz and 2048 kHz when PCM\_SYNC reaches 8 kHz with a 50 % duty cycle.

The clock and mode of PCM can be configured by **AT+QDAI**, and the default configuration is short frame mode (PCM\_CLK = 2048 kHz, PCM\_SYNC = 8 kHz). For details, see **document [2]**.




Figure 25: Reference Design of PCM and I2C Interfaces

**NOTE**

1. It is recommended to reserve an RC ( $R = 22 \Omega$ ,  $C = 22 \text{ pF}$ ) circuit close to codec on the PCM traces, especially for PCM\_CLK.
2. The module works as a master device pertaining to I2C interface.

Table 16: Pin Definition of PCM Interface

| Pin Name | Pin No. | I/O | Description         | Comment                                    |
|----------|---------|-----|---------------------|--|
| PCM_SYNC | 5       | DIO | PCM data frame sync | Master mode: output.<br>Slave mode: input. |
| PCM_CLK  | 4       | DIO | PCM clock           | If unused, keep them open.                 |
| PCM_DIN  | 6       | DI  | PCM data input      | If unused, keep them open.                 |
| PCM_DOUT | 7       | DO  | PCM data output     |  |

Table 17: Pin Definition of I2C Interface

| Pin Name | Pin No. | I/O | Description                           | Comment                        |
|----------|---------|-----|---------------------------------------|--------------------------------|
| I2C_SCL  | 40      | OD  | I2C serial clock (for external codec) | Externally pulled up to 1.8 V. |
| I2C_SDA  | 41      | OD  | I2C serial data (for external codec)  | If unused, keep them open.     |

## 4.6. ADC Interface

The module has one ADC interface. To improve the accuracy of ADC, the trace of ADC interface should be surrounded by ground.

**Table 18: Pin Definition of ADC Interface**

| Pin Name | Pin No. | I/O | Description                   | Comment                  |
|----------|---------|-----|-------------------------------|--------------------------|
| ADC      | 24      | AI  | General-purpose ADC interface | If unused, keep it open. |

With **AT+QADC=0**, you can read the voltage value on ADC. For more details about the AT command, see [document \[2\]](#).

**Table 19: Characteristics of ADC Interface**

| Parameters              | Min. | Typ. | Max.    | Units |
|-------------------------|------|------|---------|-------|
| ADC input voltage range | 0.3  | -    | VBAT_BB | V     |
| ADC resolution          | -    | -    | 15      | bits  |

**NOTE**

1. The input voltage of every ADC interface should not exceed its corresponding voltage range.
2. It is prohibited to directly supply any voltage to ADC interface when the module is not powered by the VBAT.
3. It is recommended to use resistor divider circuit for ADC interface application. Resistance of the external resistor divider should be less than 50 kΩ, or the measurement accuracy of ADC would be significantly reduced.

## 4.7. SPI

The module has one SPI which only supports master mode with a maximum clock frequency up to 50 MHz.

Table 20: Pin Definition of SPI

| Pin Name | Pin No. | I/O | Description     | Comment                    |
|----------|---------|-----|-----------------|----------------------------|
| SPI_CLK  | 26      | DO  | SPI clock       |                            |
| SPI_DIN  | 28      | DI  | SPI data input  | If unused, keep them open. |
| SPI_DOUT | 27      | DO  | SPI data output |                            |

The module has a 1.8 V SPI interface. A level-shifting chip should be used between the module and the host if the application is equipped with a 3.3 V processor or device interface. The following figure shows a reference design:




Figure 26: Reference Design of SPI with a Level-Shifting Chip

## 4.8. Indication Signals

Table 21: Pin Definition of Indication Signals

| Pin Name   | Pin No. | I/O | Description                                   | Comment                    |
|------------|---------|-----|---|----------------------------|
| STATUS     | 20      | DO  | Indicate the module's operation status        | If unused, keep them open. |
| NET_STATUS | 21      | DO  | Indicate the module's network activity status |                            |

### 4.8.1. Network Status Indication

The module has one network status indication pin: NET\_STATUS, which can drive corresponding LED.

Table 22: Network Status Indication Pin Level and Module Network Status

| Pin Name   | Level Status                           | Module Network Status        |
|------------|--|------------------------------|
| NET_STATUS | Blink slowly (200 ms high/1800 ms low) | Network searching            |
|            | Blink slowly (1800 ms high/200 ms low) | Idle                         |
|            | Blink quickly (125 ms high/125 ms low) | Data transmission is ongoing |
|            | Always high                            | Voice calling                |




Figure 27: Reference Design of Network Status Indication

#### 4.8.2. STATUS

The STATUS is used for indicating module's operation status. It will output high level when the module is turned on.




Figure 28: Reference Design of STATUS

#### 4.8.3. MAIN\_RI

**AT+QCFG=** “risignaltype”, “physical” can be used to configure the indication behavior for MAIN\_RI. No matter on which port (main UART, USB AT port or USB modem port) a URC information is presented, the URC information will trigger the behavior of the MAIN\_RI. For details about the command, see [document \[3\]](#).

**NOTE**

The **AT+QURCCFG** allows you to set the main UART, USB AT port or USB modem port as the URC information output port. The USB AT port is the URC output port by default. For details, see [document \[2\]](#).

You can configure MAIN\_RI behaviors flexibly. The default behaviors of the MAIN\_RI are shown as below:

**Table 23: MAIN\_RI Level and Module Status**

| Module Status                      | MAIN_RI Level Status  |
|------------------------------------|---|
| Idle                               | High  |
| When a new URC information returns | MAIN_RI outputs at least 120 ms low level. After the module outputs the data, the level status will then become high. |

Indication behaviors for MAIN\_RI can be configured via **AT+QCFG="urc/ri/ring"**. For details, see [document \[3\]](#).

# 5 RF Specifications

Appropriate antenna type and design should be used with matched antenna parameters according to specific application. It is required to perform a comprehensive functional test for the RF design before mass production of terminal products. The entire content of this chapter is provided for illustration only. Analysis, evaluation and determination are still necessary when designing target products.

## 5.1. Cellular Network

### 5.1.1. Antenna Interface & Frequency Bands

Table 24: Pin Definition of Cellular Antenna Interface

| Pin Name | Pin No. | I/O | Description                 | Comment                                     |
|----------|---------|-----|-----------------------------|---|
| ANT_MAIN | 60      | AO  | Main antenna interface      | 50 Ω impedance.                             |
| ANT_DRX  | 56      | AI  | Diversity antenna interface | 50 Ω impedance.<br>If unused, keep it open. |

**NOTE**

Only passive antennas are supported.

Table 25: Operating Frequency (Unit: MHz)

| Operating Frequency | Transmit  | Receive   |
|---------------------|-----------|-----------|
| LTE-FDD B2          | 1850–1910 | 1930–1990 |
| LTE-FDD B4          | 1710–1755 | 2110–2155 |
| LTE-FDD B5          | 824–849   | 869–894   |
| LTE-FDD B12         | 699–716   | 729–746   |

|             |           |           |
|-------------|-----------|-----------|
| LTE-FDD B13 | 777–787   | 746–756   |
| LTE-FDD B66 | 1710–1780 | 2110–2180 |
| LTE-FDD B71 | 663–698   | 617–652   |

### 5.1.2. Antenna Tuner Control Interface

The module can use GRFC (generic RF control) interfaces to control external antenna tuner.

**Table 26: Pin Definition of GRFC Interface**

| Pin Name | Pin No. | I/O | Description           | Comment                    |
|----------|---------|-----|-----------------------|----------------------------|
| GRFC1    | 76      | DO  | Generic RF Controller |                            |
| GRFC2    | 77      | DO  | Generic RF Controller | If unused, keep them open. |

**Table 27: Truth Table of GRFC Interfaces (Unit: MHz)**

| GRFC1 Level | GRFC2 Level | Frequency Range | Bands          |
|-------------|-------------|-----------------|----------------|
| Low         | Low         | 699–787         | LTE: B12/B13   |
| Low         | High        | 824–894         | LTE: B5        |
| High        | Low         | 663–698         | LTE: B71       |
| High        | High        | 1710–2180       | LTE: B2/B4/B66 |

### 5.1.3. Transmitting Power

**Table 28: RF Transmitting Power**

| Frequency | Max. Tx Power | Min. Tx Power |
|-----------|---------------|---------------|
| LTE-FDD   | 23 dBm ±2 dB  | < -39 dBm     |

### 5.1.4. Receiver Sensitivity

Table 31: Conducted RF Receiver Sensitivity (Unit: dBm)

| Frequency   | Receiver Sensitivity (Typ.) |           |            | 3GPP Requirements (SIMO) |
|-------------|-----------------------------|-----------|------------|--------------------------|
|             | Primary                     | Diversity | SIMO       |                          |
| LTE-FDD B2  | -97.7 dBm                   | -98.7 dBm | -101.3 dBm | -94.3 dBm                |
| LTE-FDD B4  | -97.3 dBm                   | -98.5 dBm | -100.3 dBm | -96.3 dBm                |
| LTE-FDD B5  | -98.9 dBm                   | -99.5 dBm | -101.6 dBm | -94.3 dBm                |
| LTE-FDD B12 | -97.8 dBm                   | -98.1 dBm | -100.2 dBm | -93.3 dBm                |
| LTE-FDD B13 | -97.8 dBm                   | -98.2 dBm | -100.3 dBm | -93.3 dBm                |
| LTE-FDD B66 | -97.3 dBm                   | -98.7 dBm | -100.3 dBm | -95.8 dBm                |
| LTE-FDD B71 | -98.7 dBm                   | -99.3 dBm | -101.7 dBm | -93.5 dBm                |

### 5.1.5. Reference Design




Figure 29: Reference Design of Main Antenna and Diversity Antenna

**NOTE**

1. To improve receiver sensitivity, ensure that the clearance among antennas is appropriate.
2. Use a  $\pi$ -type matching circuit for all the antenna interfaces for better RF performance and for the ease of debugging.
3. Capacitors are not mounted by default.
4. Place the  $\pi$ -type matching components (R1, C1, C2 and R2, C3, C4) to antennas as close as possible.
5. Junction capacitance of ESD protection components on the antenna interface should not exceed 0.05 pF.

## 5.2. GNSS (Optional)

GNSS information of the module is as follows:

- Supports GPS, GLONASS, BDS, Galileo and QZSS positioning system.
- Supports NMEA 0183 protocol and outputs NMEA sentences via USB interface (data update rate for positioning: 1–10 Hz, 1 Hz by default).
- The module's GNSS function is OFF by default. It must be ON via **AT+QGPS**.

For more details about GNSS technology and configurations, see **document [6]**.

### 5.2.1. Antenna Interface & Frequency Bands

**Table 29: Pin Definition of GNSS Antenna Interface**

| Pin Name | Pin No. | I/O | Description            | Comment  |
|----------|---------|-----|------------------------|--|
| ANT_GNSS | 49      | AI  | GNSS antenna interface | 50 $\Omega$ impedance.<br>If unused, keep it open. |

**Table 30: GNSS Frequency (Unit: MHz)**

| Antenna Types | Frequency                  |
|---------------|----------------------------|
| GPS           | 1575.42 $\pm$ 1.023 (L1)   |
| GLONASS       | 1597.5–1605.8 (G1)         |
| BDS           | 1561.098 $\pm$ 2.046 (B1I) |

|         |                     |
|---------|---------------------|
| Galileo | 1575.42 ±2.046 (E1) |
| QZSS    | 1575.42 ±1.023 (L1) |

### 5.2.2. GNSS Performance

Table 31: GNSS Performance

| Parameter   | Mode                  | Condition             | Typ. | Unit |
|-------------|-----------------------|-----------------------|------|------|
| Sensitivity | Acquisition           |                       | -146 | dBm  |
|             | Reacquisition         | Autonomous            | -157 |      |
|             | Tracking              |                       | -157 |      |
| TTFF        | Cold start @ open sky | Autonomous            | 35   | s    |
|             |                       | XTRA start            | 12   |      |
|             | Warm start @ open sky | Autonomous            | 26   |      |
|             |                       | XTRA start            | 3.7  |      |
| Accuracy    | Hot start @ open sky  | Autonomous            | 2    | m    |
|             |                       | XTRA start            | 3.4  |      |
|             | CEP-50                | Autonomous @ open sky | 2.5  |      |

**NOTE**

1. Tracking sensitivity: the minimum GNSS signal power at which the module can maintain lock (keep positioning for at least 3 minutes continuously).
2. Reacquisition sensitivity: the minimum GNSS signal power required for the module to maintain lock within 3 minutes after loss of lock.
3. Acquisition sensitivity: the minimum GNSS signal power at which the module can fix position successfully within 3 minutes after executing cold start command.

### 5.2.3. Reference Design

#### 5.2.3.1. GNSS Active Antenna

In any case, it is recommended to use a passive antenna. However, if an active antenna is needed in your application, it is recommended to reserve a  $\pi$ -type attenuation circuit and use a high-performance LDO in the power system design.

GNSS active antenna connection reference circuit is shown in the figure below.




Figure 30: Reference Design of GNSS Active Antenna

The power supply voltage range of the external active antenna is 2.8–4.3 V, and the typical value is 3.3 V.

#### 5.2.3.2. GNSS Passive Antenna

GNSS passive antenna connection reference circuit is shown in the figure below.




Figure 31: Reference Design of GNSS Passive Antenna

It is recommended to reserve a  $\pi$ -type matching circuit in the peripheral circuit design for GNSS antenna interface for better RF performance. Components (R1, C1 and C2) of the  $\pi$ -type matching circuit shall be placed as close to the antenna as possible. C1 and C2 are not mounted by default. Only a  $0\ \Omega$  resistor is mounted on R1. Keep the characteristic impedance for RF trace as  $50\ \Omega$  when routing and keep the trace as short as possible.

**NOTE**

1. You can select an external LDO according to the active antenna types. If you design the module with a passive antenna, you will not need the VDD circuit.
2. Junction capacitance of ESD protection components on the antenna interface should not exceed  $0.05\ pF$ .
3. It is recommended to use a passive GNSS antenna when LTE B13 is supported, as the use of active antenna may generate harmonics which will affect the GNSS performance.
4. It is not recommended to add an external LNA when using a passive GNSS antenna.

### 5.3. RF Routing Guidelines

For user's PCB, the characteristic impedance of all RF traces should be controlled to  $50\ \Omega$ . The impedance of the RF traces is usually determined by the trace width (W), the materials' dielectric constant, the height from the reference ground to the signal layer (H), and the spacing between RF traces and grounds (S). Microstrip or coplanar waveguide is typically used in RF layout to control characteristic impedance. The following are reference designs of microstrip or coplanar waveguide with different PCB structures.




Figure 32: Microstrip Design on a 2-layer PCB




Figure 33: Coplanar Waveguide Design on a 2-layer PCB





Figure 34: Coplanar Waveguide Design on a 4-layer PCB (Layer 3 as Reference Ground)



**Figure 35: Coplanar Waveguide Design on a 4-layer PCB (Layer 4 as Reference Ground)**

To ensure RF performance and reliability, follow the principles below in RF layout design:

- Use an impedance simulation tool to accurately control the characteristic impedance of RF traces to  $50 \Omega$ .
- The GND pins adjacent to RF pins should not be designed as thermal relief pads, and should be fully connected to ground.
- The distance between the RF pins and the RF connector should be as short as possible and all the right-angle traces should be changed to curved ones. The recommended trace angle is  $135^\circ$ .
- There should be clearance under the signal pin of the antenna connector or solder joint.
- The reference ground of RF traces should be complete. Meanwhile, adding some ground vias around RF traces and the reference ground could help to improve RF performance. The distance between the ground vias and RF traces should be at least twice the width of RF signal traces ( $2 \times W$ ).
- Keep RF traces away from interference sources, and avoid intersection and paralleling between traces on adjacent layers.

For more details about RF layout, see [document \[7\]](#).

## 5.4. Requirements for Antenna Design

**Table 32: Requirements for Antenna Design**

| Antenna Types   | Requirements   |
|-----------------|--|
| GNSS (Optional) | Frequency range: 1559–1609 MHz<br>RHCP or linear polarization<br>VSWR: $\leq 2$ (Typ.)<br><b>For passive antenna application:</b><br>Passive antenna gain: $> 0$ dBi |

## Cellular

**For active antenna application:**

Active antenna noise coefficient: < 1.5 dB

Active antenna embedded LNA gain: < 17 dB

VSWR:  $\leq 2$

Efficiency: > 30 %

LTE Band 2 Gain:  $\leq 8.0$  dBi

LTE Band 4 Gain:  $\leq 5.0$  dBi

LTE Band 5 Gain:  $\leq 9.4$  dBi

LTE Band 12 Gain:  $\leq 8.7$  dBi

LTE Band 13 Gain:  $\leq 9.2$  dBi

LTE Band 66 Gain:  $\leq 5.0$  dBi

LTE Band 71 Gain:  $\leq 8.5$  dBi

Max input power: 50 W

Input impedance: 50  $\Omega$

Vertical polarization

**Cable insertion loss:**

- < 1 dB: LB (< 1 GHz)

- < 1.5 dB: MB (1–2.3 GHz)

**NOTE**

It is recommended to use a passive GNSS antenna when LTE B13 is supported, as the use of active antenna may generate harmonics which will affect the GNSS performance.

## 5.5. RF Connector Recommendation

If the RF connector is used for antenna connection, it is recommended to use U.FL-R-SMT receptacle provided by Hirose.




Figure 36: Dimensions of the Receptacle (Unit: mm)

U.FL-LP series mated plugs listed in the following figure can be used to match the U.FL-R-SMT.

| Part No.         | U.FL-LP-040                  | U.FL-LP-066                                     | U.FL-LP(V)-040               | U.FL-LP-062                | U.FL-LP-088                  |
|------------------|------------------------------|---|------------------------------|----------------------------|------------------------------|
|                  |                              |   |                              |                            |                              |
| Mated Height     | 2.5mm Max.<br>(2.4mm Nom.)   | 2.5mm Max.<br>(2.4mm Nom.)                      | 2.0mm Max.<br>(1.9mm Nom.)   | 2.4mm Max.<br>(2.3mm Nom.) | 2.4mm Max.<br>(2.3mm Nom.)   |
| Applicable cable | Dia. 0.81mm<br>Coaxial cable | Dia. 1.13mm and<br>Dia. 1.32mm<br>Coaxial cable | Dia. 0.81mm<br>Coaxial cable | Dia. 1mm<br>Coaxial cable  | Dia. 1.37mm<br>Coaxial cable |
| Weight (mg)      | 53.7                         | 59.1  | 34.8                         | 45.5                       | 71.7                         |
| RoHS             |                              |   | YES                          |                            |                              |

Figure 37: Specifications of Mated Plugs (Unit: mm)

The following figure describes the space factor of the mated connector.




Figure 38: Space Factor of the Mated Connectors (Unit: mm)

For more details, visit <http://www.hirose.com>.

# 6 Electrical Characteristics and Reliability

## 6.1. Absolute Maximum Ratings

Table 33: Absolute Maximum Ratings

| Parameters                   | Min. | Max.    | Units |
|------------------------------|------|---------|-------|
| Voltage at VBAT_RF & VBAT_BB | -0.3 | 4.7     | V     |
| Voltage at USB_VBUS          | -0.3 | 5.5     | V     |
| Voltage at digital pins      | -0.3 | 2.3     | V     |
| Voltage at ADC               | 0    | VBAT_BB | V     |
| Current at VBAT_BB           | -    | 0.8     | A     |
| Current at VBAT_RF           | -    | 1.8     | A     |

## 6.2. Power Supply Ratings

Table 34: Module's Power Supply Ratings

| Parameters        | Descriptions                            | Conditions   | Min. | Typ. | Max. | Units |
|-------------------|---|--|------|------|------|-------|
| VBAT              | VBAT_BB & VBAT_RF                       | The actual input voltage must be within this range | 3.3  | 3.8  | 4.3  | V     |
|                   | Voltage drops during burst transmission | At maximum power control level                     | -    | -    | 400  | mV    |
| I <sub>VBAT</sub> | Peak power consumption                  | At maximum power control level                     | -    | -    | 2.0  | A     |

|          |                          |   |     |     |      |   |
|----------|--------------------------|---|-----|-----|------|---|
| USB_VBUS | USB connection detection | - | 3.0 | 5.0 | 5.25 | V |
|----------|--------------------------|---|-----|-----|------|---|

### 6.3. Power Consumption

Table 35: Power Consumption

| Description                         | Conditions                          | Typ.  | Unit |
|-------------------------------------|-------------------------------------|-------|------|
| OFF state                           | Power down                          | 8.39  | µA   |
|                                     | <b>AT+CFUN=0</b> (USB disconnected) | 0.77  | mA   |
|                                     | <b>AT+CFUN=0</b> (USB Suspend)      | 0.99  | mA   |
|                                     | <b>AT+CFUN=4</b> (USB disconnected) | 0.83  | mA   |
|                                     | <b>AT+CFUN=4</b> (USB Suspend)      | 1.09  | mA   |
| Sleep state                         | LTE-FDD @ PF=32 (USB disconnected)  | 3.26  | mA   |
|                                     | LTE-FDD @ PF=64 (USB disconnected)  | 2.11  | mA   |
|                                     | LTE-FDD @ PF=64 (USB Suspend)       | 2.34  | mA   |
|                                     | LTE-FDD @ PF=128 (USB disconnected) | 1.48  | mA   |
|                                     | LTE-FDD @ PF=256 (USB disconnected) | 1.16  | mA   |
| Idle state                          | LTE-FDD PF = 64 (USB disconnected)  | 15.44 | mA   |
|                                     | LTE-FDD PF = 64 (USB Suspend)       | 25.14 | mA   |
| LTE data transmission<br>(GNSS off) | LTE-FDD B2 @ 23.18 dBm              | 719   | mA   |
|                                     | LTE-FDD B4 @ 23.1 dBm               | 759   | mA   |
|                                     | LTE-FDD B5 @ 23.76 dBm              | 756   | mA   |
|                                     | LTE-FDD B12 @ 23.58 dBm             | 657   | mA   |
|                                     | LTE-FDD B13 @ 23.73 dBm             | 734   | mA   |
|                                     | LTE-FDD B66 @ 23.1 dBm              | 752   | mA   |
|                                     | LTE-FDD B71 @ 23.04 dBm             | 763   | mA   |

## 6.4. Digital I/O Characteristics

Table 36: VDD\_EXT I/O Characteristics (Unit: V)

| Parameters | Descriptions              | Min.                   | Max.                   |
|------------|---------------------------|------------------------|------------------------|
| $V_{IH}$   | High-level input voltage  | $0.65 \times VDD\_EXT$ | $VDD\_EXT + 0.2$       |
| $V_{IL}$   | Low-level input voltage   | -0.3                   | $0.35 \times VDD\_EXT$ |
| $V_{OH}$   | High-level output voltage | $VDD\_EXT - 0.45$      | $VDD\_EXT$             |
| $V_{OL}$   | Low-level output voltage  | 0                      | 0.45                   |

Table 37: USIM Low/High-voltage I/O Characteristics (Unit: V)

| Parameters | Descriptions              | Min.                   | Max.                    |
|------------|---------------------------|------------------------|-------------------------|
| $V_{IH}$   | High-level input voltage  | $0.8 \times USIM\_VDD$ | $USIM\_VDD$             |
| $V_{IL}$   | Low-level input voltage   | -0.3                   | $0.12 \times USIM\_VDD$ |
| $V_{OH}$   | High-level output voltage | $0.8 \times USIM\_VDD$ | $USIM\_VDD$             |
| $V_{OL}$   | Low-level output voltage  | 0                      | 0.4                     |

## 6.5. ESD Protection

Static electricity occurs naturally and it may damage the module. Therefore, applying proper ESD countermeasures and handling methods is imperative. For example, wear anti-static gloves during the development, production, assembly and testing of the module; add ESD protection components to the ESD sensitive interfaces and points in the product design.

Table 38: ESD Characteristics (Temperature: 25–30 °C, Humidity: 40 ±5 %; Unit: kV)

| Test Points            | Contact Discharge | Air Discharge |
|------------------------|-------------------|---------------|
| VBAT & GND             | ±5                | ±10           |
| All Antenna Interfaces | ±4                | ±8            |

|                  |           |         |
|------------------|-----------|---------|
| Other Interfaces | $\pm 0.5$ | $\pm 1$ |
|------------------|-----------|---------|

## 6.6. Operating and Storage Temperatures

**Table 39: Operating and Storage Temperatures (Unit: °C)**

| Parameters                                  | Min. | Typ. | Max. |
|---|------|------|------|
| Normal Operating Temperature <sup>3</sup>   | -35  | +25  | +75  |
| Extended Operating Temperature <sup>4</sup> | -40  | -    | +85  |
| Storage Temperature                         | -40  | -    | +90  |

<sup>3</sup> Within this range, the module's indicators comply with 3GPP specification requirements.

<sup>4</sup> Within this range, the module retains the ability to establish and maintain functions such as voice and SMS, without any unrecoverable malfunction. Radio spectrum and radio network remain uninfluenced, whereas the value of one or more parameters, such as  $P_{out}$ , may decrease and fall below the range of the 3GPP specified tolerances. When the temperature returns to the normal operating temperature range, the module's indicators will comply with 3GPP specification requirements again.

# 7 Mechanical Information

This chapter describes the mechanical dimensions of the module. All dimensions are measured in millimeter (mm), and the dimensional tolerances are  $\pm 0.2$  mm unless otherwise specified.

## 7.1. Mechanical Dimensions





Figure 39: Top and Side Dimensions



**Figure 40: Bottom Dimensions**

## NOTE

The package warpage level of the module refers to the *JEITA ED-7306* standard.

## 7.2. Recommended Footprint




Figure 41: Recommended Footprint

**NOTE**

Keep at least 3 mm between the module and other components on the motherboard to improve soldering quality and maintenance convenience.

### 7.3. Top and Bottom Views




Figure 42: Top & Bottom Views of the Module

**NOTE**

Images above are for illustration purpose only and may differ from the actual module. For authentic appearance and label, please refer to the module received from Quectel.

# 8 Storage, Manufacturing & Packaging

## 8.1. Storage Conditions

The module is provided with vacuum-sealed packaging. MSL of the module is rated as 3. The storage requirements are shown below.

1. Recommended Storage Condition: the temperature should be  $23 \pm 5$  °C and the relative humidity should be 35–60 %.
2. Shelf life (in a vacuum-sealed packaging): 12 months in Recommended Storage Condition.
3. Floor life: 168 hours <sup>5</sup> in a factory where the temperature is  $23 \pm 5$  °C and relative humidity is below 60 %. After the vacuum-sealed packaging is removed, the module must be processed in reflow soldering or other high-temperature operations within 168 hours. Otherwise, the module should be stored in an environment where the relative humidity is less than 10 % (e.g., a dry cabinet).
4. The module should be pre-baked to avoid blistering, cracks and inner-layer separation in PCB under the following circumstances:
  - The module is not stored in Recommended Storage Condition;
  - Violation of the third requirement mentioned above;
  - Vacuum-sealed packaging is broken, or the packaging has been removed for over 24 hours;
  - Before module repairing.
5. If needed, the pre-baking should follow the requirements below:
  - The module should be baked for 8 hours at  $120 \pm 5$  °C;
  - The module must be soldered to PCB within 24 hours after the baking, otherwise it should be put in a dry environment such as in a dry cabinet.

<sup>5</sup> This floor life is only applicable when the environment conforms to *IPC/JEDEC J-STD-033*. It is recommended to start the solder reflow process within 24 hours after the package is removed if the temperature and moisture do not conform to, or are not sure to conform to *IPC/JEDEC J-STD-033*. And do not unpack the modules in large quantities until they are ready for soldering.

**NOTE**

1. To avoid blistering, layer separation and other soldering issues, extended exposure of the module to the air is forbidden.
2. Take out the module from the package and put it on high-temperature-resistant fixtures before baking. If shorter baking time is desired, see *IPC/JEDEC J-STD-033* for the baking procedure.
3. Pay attention to ESD protection, such as wearing anti-static gloves, when touching the modules.

## 8.2. Manufacturing and Soldering

Push the squeegee to apply the solder paste on the surface of stencil, thus making the paste fill the stencil openings and then penetrate to the PCB. Apply proper force on the squeegee to produce a clean stencil surface on a single pass. To guarantee module soldering quality, the thickness of stencil for the module is recommended to be 0.13–0.18 mm. For more details, see **document [8]**.

The recommended peak reflow temperature should be 235–246 °C, with 246 °C as the absolute maximum reflow temperature. To avoid damage to the module caused by repeated heating, it is recommended that the module should be mounted only after reflow soldering for the other side of PCB has been completed. The recommended reflow soldering thermal profile (lead-free reflow soldering) and related parameters are shown below:




Figure 43: Recommended Reflow Soldering Thermal Profile

**Table 40: Recommended Thermal Profile Parameters**

| Factor   | Recommended Value |
|--|-------------------|
| <b>Soak Zone</b>                               |                   |
| Ramp-to-soak Slope                             | 0–3 °C/s          |
| Soak Time (between A and B: 150 °C and 200 °C) | 70–120 s          |
| <b>Reflow Zone</b>                             |                   |
| Ramp-up Slope                                  | 0–3 °C/s          |
| Reflow Time (D: over 217°C)                    | 40–70 s           |
| Max Temperature                                | 235–246 °C        |
| Cool-down Slope                                | -3–0 °C/s         |
| <b>Reflow Cycle</b>                            |                   |
| Max Reflow Cycle                               | 1                 |

**NOTE**

1. The above profile parameter requirements are for the measured temperature of the solder joints. Both the hottest and coldest spots of solder joints on the PCB should meet the above requirements.
2. If a conformal coating is necessary for the module, do not use any coating material that may chemically react with the PCB or shielding cover, and prevent the coating material from flowing into the module.
3. Avoid using ultrasonic technology for module cleaning since it can damage crystals inside the module.
4. Avoid using materials that contain mercury (Hg), such as adhesives, for module processing, even if the materials are RoHS compliant and their mercury content is below 1000 ppm (0.1 %).
5. Due to the complexity of the SMT process, contact Quectel Technical Support in advance for any situation that you are not sure about, or any process (e.g. selective wave soldering, ultrasonic soldering) that is not mentioned in **document [8]**.

### 8.3. Packaging Specification

This chapter outlines the key packaging parameters and processes. All figures below are for reference purposes only, as the actual appearance and structure of packaging materials may vary in delivery.

The modules are packed in a tape and reel packaging as specified in the sub-chapters below.

### 8.3.1. Carrier Tape

Carrier tape dimensions are illustrated in the following figure and table:




Figure 44: Carrier Tape Dimension Drawing (Unit: mm)

Table 41: Carrier Tape Dimension Table (Unit: mm)

| W  | P  | T    | A0   | B0   | K0  | K1  | F    | E    |
|----|----|------|------|------|-----|-----|------|------|
| 44 | 32 | 0.35 | 25.5 | 29.5 | 3.2 | 5.8 | 20.2 | 1.75 |

### 8.3.2. Plastic Reel

Plastic reel dimensions are illustrated in the following figure and table:




Figure 45: Plastic Reel Dimension Drawing

Table 42: Plastic Reel Dimension Table (Unit: mm)

| ØD1 | ØD2 | W    |
|-----|-----|------|
| 330 | 100 | 44.5 |

### 8.3.3. Mounting Direction







Figure 46: Mounting Direction

### 8.3.4. Packaging Process



Place the modules onto the carrier tape cavity and cover them securely with cover tape. Wind the heat-sealed carrier tape onto a plastic reel and apply a protective tape for additional protection. 1 plastic reel can pack 250 modules.

Place the packaged plastic reel, humidity indicator card and desiccant bag into a vacuum bag, and vacuumize it.



Place the vacuum-packed plastic reel into a pizza box.

Place the 4 packaged pizza boxes into 1 carton and seal it. 1 carton can pack 1000 modules.




Figure 47: Packaging Process

# 9 Appendix References

**Table 43: Related Documents**

| Document Name   |
|---|
| [1] Quectel_UMTS&LTE_EVB_User_Guide                                 |
| [2] Quectel_EC2x&EG2x-G(L)&EG9x&EM05_Series_AT_Commands_Manual      |
| [3] Quectel_EC2x&EG2x&EG9x&EM05_Series_QCFG_AT_Commands_Manual      |
| [4] Quectel_EC2x&EG2x&EG9x_Series_Power_Management_Application_Note |
| [5] Quectel_EG9x_Series_AT+QDSIM_Command_Manual                     |
| [6] Quectel_EC2x&EG2x&EG9x&EM05_Series_GNSS_Application_Note        |
| [7] Quectel_RF_Layout_Application_Note                              |
| [8] Quectel_Module_SMT_Application_Note                             |

**Table 44: Terms and Abbreviations**

| Abbreviation | Description                                 |
|--------------|---|
| ADC          | Analog-to-Digital Converter                 |
| AMR-WB       | Adaptive Multi-Rate Wideband                |
| bps          | Bits Per Second                             |
| CHAP         | Challenge Handshake Authentication Protocol |
| CTS          | Clear To Send                               |
| DDR          | Double Data Rate                            |
| DFOTA        | Delta Firmware Upgrade Over The Air         |
| DL           | Downlink                                    |

|         |   |
|---------|---|
| DRX     | Discontinuous Reception                     |
| DRX     | Diversity Receive                           |
| ESD     | Electrostatic Discharge                     |
| FDD     | Frequency Division Duplex                   |
| GLONASS | Global Navigation Satellite System (Russia) |
| GNSS    | Global Navigation Satellite System          |
| GPS     | Global Positioning System                   |
| GRFC    | General RF Control                          |
| I2C     | Inter-Integrated Circuit                    |
| I/O     | Input/Output                                |
| LB      | Low Band                                    |
| LED     | Light Emitting Diode                        |
| LGA     | Land Grid Array                             |
| LNA     | Low Noise Amplifier                         |
| LTE     | Long Term Evolution                         |
| MB      | Middle Band                                 |
| MCU     | Microcontroller Unit                        |
| MO      | Mobile Originated                           |
| MT      | Mobile Terminated                           |
| PAP     | Password Authentication Protocol            |
| PCB     | Printed Circuit Board                       |
| PCM     | Pulse Code Modulation                       |
| PDU     | Protocol Data Unit                          |
| QAM     | Quadrature Amplitude Modulation             |
| QPSK    | Quadrature Phase Shift Keying               |

|                     |   |
|---------------------|---|
| QZSS                | Quasi-Zenith Satellite System               |
| RI                  | Ring Indicator                              |
| RF                  | Radio Frequency                             |
| RHCP                | Right Hand Circularly Polarized             |
| Rx                  | Receive                                     |
| SIMO                | Single Input Multiple Output                |
| SMD                 | Surface Mount Device                        |
| SMS                 | Short Message Service                       |
| SPI                 | Serial Peripheral Interface                 |
| Tx                  | Transmit                                    |
| UART                | Universal Asynchronous Receiver/Transmitter |
| UL                  | Uplink                                      |
| UMTS                | Universal Mobile Telecommunications System  |
| URC                 | Unsolicited Result Code                     |
| USB                 | Universal Serial Bus                        |
| USIM                | Universal Subscriber Identity Module        |
| VBAT                | Voltage at Battery (Pin)                    |
| Vmax                | Maximum Voltage                             |
| Vnom                | Nominal Voltage                             |
| Vmin                | Minimum Voltage                             |
| V <sub>IH</sub> max | Maximum High-level Input Voltage            |
| V <sub>IH</sub> min | Minimum High-level Input Voltage            |
| V <sub>IL</sub> max | Maximum Low-level Input Voltage             |
| VSWR                | Voltage Standing Wave Ratio                 |

# 10 Waring

The module's FCC certification is only valid when the manufacturer/integrator adheres to the trace reference design guidance as provided in this integration instruction.

Quectel promises that any deviation in the defined parameters of the antenna trace requires the host product manufacturer to notify the module transferee that they wish to change the antenna trace design. In this case, the authorizer needs to submit a Class II license change application, or the host manufacturer can take responsibility by changing the FCC ID: XMR2023EG96NAX (new application) program and then submitting a Class II license change application.

- a. According to FCC KDB 996369 D01, D02, D03, D04, the following content are must meet
  1. The module is limited to OEM installation ONLY
  2. The OEM integrator is responsible for ensuring that the end-user has no manual instructions to remove or install module
  3. The module is limited to installation in mobile or fixed applications, according to Part 2.1091(b)
  4. The separate approval is required for all other operating configurations, including portable configurations with respect to Part 2.1093 and different antenna configurations
  5. Labelling instructions of finished product.

The ISED certification label and FCC certification label of a module shall be clearly visible at all times when installed in the host product, otherwise, the host product must be labelled to display the ISED certification number and FCC certification number for the module, preceded by the word "contains" or similar wording expressing the same meaning, as follows Contains IC:10224A-2023EG96NAX and Contains FCC ID: XMR2023EG96NAX.

In this case. IC:10224A-2023EG96NAX and FCC ID: XMR2023EG96NAX are the module's certification number

## FCC:

Please take attention that changes or modification not expressly approved by the party responsible for

compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and(2)This device must accept any interference received, including interference that may cause undesired operation.

If the distance from the product to the human body is greater than 20cm, the following warning is required (this requirement is not required for micro-power SRD devices)  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

**IC:**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

l'appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux CNR exempts de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage,
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

For licence-exempt equipment with detachable antennas, the user manual shall also contain the following notice in a conspicuous location

*Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.*

*Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.*

If the distance from the product to the human body is greater than 20cm, the following warning is required (this requirement is not required for micro-power SRD devices)

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ce matériel est conforme aux limites de dose d'exposition aux rayonnements, CNR-102 énoncée dans un autre environnement. cette eqipment devrait être installé et exploité avec distance minimale de 20 entre le radiateur et votre corps.