

User Manual



Smart Audio Glasses


Foreword

Thank you for purchasing and using our company's products. In order to allow you to operate the machine easily and freely as soon as possible, please read this manual carefully before you start using it. This unit is a stylishly designed portable wireless Bluetooth glasses. This machine supports the Bluetooth protocol, supports smart phones, tablet computers, notebooks and other devices with Bluetooth audio functions, allowing you to completely get rid of the shackles of wired, unfettered enjoyment of music.

Warning

- Do not hit the main unit hard.
- Do not come into contact with chemicals such as benzene and thinner.
 - Please do not use it near strong magnetic fields and electric fields.
- >Please avoid direct light or heating appliances.
- DO not disassemble, repair or transform by yourself.
 - When riding a bicycle, driving a car or motorcycle, do not use the player to avoid danger.
 - DO not listen at high volume for a long time to avoid adverse effects on hearing.
 - DO not clean the machine with clean water, please use a slightly damp cloth to clean the surface Of the machine. •Low voltage use may cause sound distortion and please charge it in time. Please disconnect the power supply when not in use for a long time.
 - The Bluetooth function is compatible with common smartphones, tablets, etc., but some functions may not be supported depending on the device or application you are using.

Product Appearance



Specification

Input: DC sV
Speaker power: 8 Ω*1W*2
Battery capacity: 140mAh*1 , rechargeable
Standby time: around 10 hours
Charging time: 2 hours
Working time: 5-8 hours, depends on the volume
Frame material: ABS
Glasses leg material: ABS
Connectivity method: bluetooth 5.0

Operation

Power on: Press and hold the function button at the bottom of the right temple for 5 seconds to give a voice prompt to power on. Power off: When the device is working, long press the function key for 5 seconds.
When the product is in standby state, it will automatically shut down after 5 minutes.
Play/pause : Short press the function key.
Answer/hang up a call: Press the function key twice continuously.
Previous: Press the function key 3 times in a row.
Next: Press the function key twice continuously.
Voice Assistant: Press and hold the function key for 4 seconds.
Take a photo: When the phone camera is turned on, press and hold the function key for 2 seconds.
Prompt tone switching: Press the function key 2 times to switch the prompt tone without connecting to any bluetooth device after power on

Indicator light status

White:
Flashes quickly to indicate charging
Steady light means fully charged
Blue:
Blinking means power on and waiting for pairing, when the phone is paired and connected, the light turns off.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction