

8. SETUP PHOTO

15 cm from the center of the probe




20 cm from the center of the probe




CONFIGURATION 1 STANDBY MODE - 0.3m CABLE

S1, RF EXPOSURE SETUP PHOTO 15cm




S2, RF EXPOSURE SETUP PHOTO 15cm




S3, RF EXPOSURE SETUP PHOTO 15cm



S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm




CONFIGURATION 2 WITH WATCH - 0.3m CABLE


S1, RF EXPOSURE SETUP PHOTO 15 cm




S2, RF EXPOSURE SETUP PHOTO 15 cm




S3, RF EXPOSURE SETUP PHOTO 15 cm



S4, RF EXPOSURE SETUP PHOTO 15 cm




CENTER, RF EXPOSURE SETUP PHOTO 20 cm




CONFIGURATION 1 STANDBY MODE - 1m CABLE


S1, RF EXPOSURE SETUP PHOTO 15cm




S2, RF EXPOSURE SETUP PHOTO 15cm




S3, RF EXPOSURE SETUP PHOTO 15cm



S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm




CONFIGURATION 2 WITH WATCH - 1m CABLE


S1, RF EXPOSURE SETUP PHOTO 15cm




S2, RF EXPOSURE SETUP PHOTO 15cm




S3, RF EXPOSURE SETUP PHOTO 15cm





S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm




CONFIGURATION 1 STANDBY MODE - 2m CABLE




S3, RF EXPOSURE SETUP PHOTO 15cm



S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm




CONFIGURATION 2 WITH WATCH - 2m CABLE


S1, RF EXPOSURE SETUP PHOTO 15 cm




S2, RF EXPOSURE SETUP PHOTO 15 cm




S3, RF EXPOSURE SETUP PHOTO 15 cm



S4, RF EXPOSURE SETUP PHOTO 15 cm



CENTER, RF EXPOSURE SETUP PHOTO 20 cm



END OF REPORT