



## 8. SETUP PHOTO

### CONFIGURATION 1 STANDBY MODE - 0.3m CABLE

S1, RF EXPOSURE SETUP PHOTO 15cm




S2, RF EXPOSURE SETUP PHOTO 15cm



S3, RF EXPOSURE SETUP PHOTO 15cm



S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm




**CONFIGURATION 2 WITH iWATCH - 0.3m CABLE**


S1, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm




S2, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm



S3, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm




S4, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm




CENTER, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 20cm



S1, RF EXPOSURE SETUP PHOTO 15cm




S2, RF EXPOSURE SETUP PHOTO 15cm







S3, RF EXPOSURE SETUP PHOTO 15cm



S4, RF EXPOSURE SETUP PHOTO 15cm




CENTER, RF EXPOSURE SETUP PHOTO 20cm



**CONFIGURATION 2 WITH iWATCH - 1m CABLE**

S1, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm






S2, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm




S3, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm



S4, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 15cm




CENTER, RF EXPOSURE SETUP PHOTO (HORIZONTAL) 20cm



RF EXPOSURE SETUP PHOTO 15cm



RF EXPOSURE SETUP PHOTO 20cm



**END OF REPORT**