

USER MANUAL

IRF V2 8x9

IMPORTANT: THE ABOVE MODELS ARE TO BE INSTALLED ONLY BY AURMANET AUTHORIZED REPRESENTATIVES

FOR INSTALLATION CONTACT AURMANET AT: 4 Impasse de la croix blanche 95370 CORMEILLE EN PARISIS +33 1 39 97 09 65 attn : Mr Jean-claude Tillet

E-mail: jctillet@aurmanet.com

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and must accept any interference received, including interference that may cause undesired operation.

Warnings:

This equipment has been approved for mobile applications where the equipment should be used at distances greater than 20cm from the human body (with the exception of hands, wrists, feet and ankles). Operation at distances less than 20 cm is strictly prohibited.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Installation:

The IRF has to be connected to a standard USB PC port and the Software DRIVER IRF must be installed on the PC



The device is powered by the USB port.

TECH. PARAMETERS:

Voltage input: 5 VDC

Current power input:: 60mA / 0.7 Watt Radio Frequency Band: 902-927 Mhz

WARRANTY INFORMATION

The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, with a minimum of 1 year (Germany: 2 years), starting from the date on which the appliance is sold to the end user. The warranty only covers defects in material or workmanship.

The repairs under warranty may only be carried out by an authorized service centre. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.

The warranty will not apply in cases of:

- Incorrect use, e.g. overloading of the appliance, use of non-approved accessories
- Use of force, damage caused by external influences
- Damage caused by non-observance of the user manual, e.g. connection to an unsuitable mains supply or non-compliance with the installation instructions
- Partially or completely dismantled appliances





This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection Systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.