


Fixture Sensor Installation Instruction

Model # WPPA102

⚠ WARNING: TURN THE POWER OFF AT THE CIRCUIT BREAKER BEFORE INSTALLING THE SENSOR.


DIMENSION

Unit:inch/mm




INSTALLATION

1. Drill a hole 0.83" (21mm) in diameter through the sheet metal in the bottom of the fixture.
2. Install the sensor socket face down, parallel to the mounting surface. Ensure the rubber gasket touches the outside surface of the fixture.
3. Install the screw nut securely against the fixture to a torque of 25-30 in-lbs to ensure IP rating is maintained.
4. Connect the sensor to the socket via 3.5mm audio jack interface.
5. Connect wires as shown in below WIRING diagram.
6. Restore power from the circuit breaker.



WIRING



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.