


309*136mm

User Manual

BT LED SPHERE SPEAKER



Package Contents:

- 1(One) Bluetooth speaker
- 1(One) Charging cable
- 1(One) Instruction Manual

Button Description:

- “**¶**”: Pause/Play Music
- “+”: Short press to increase volume / long press Next song
- “-”: Short press to reduce volume / long press Previous song

How To Use:

- Power on:** Switch the on/off key to ON to turn on the speaker. The blue LED light will turn on, and a voice will prompt indicating that the speaker is in pairing mode. This indicates the speaker is in pairing mode.
- Pairing:** Activate the bluetooth function on your phone within range and select “BT LED SPHERE SPEAKER” from the list shown. When the blue LED light stops flashing, it has paired successfully and you will hear “connected”. The blue LED will flash slowly when playing music.
- Play/Pause:** When it is playing, press the on/off key “**¶**” to pause, then press the on/off key “**¶**” again to play.
- Volume up:** Press “+” once to increase the volume.
- Volume down:** Press “-” once to decrease the volume.
- Previous song:** Hold down the “-” to play the previous song.
- Next song:** Hold down the “+” to play the next song.
- Power off:** Switch the ON/OFF key to OFF to shut down the speaker

Tips:

- Low Battery:** A prompt sound will be heard.
- To Charge:**
 1. Insert the USB connector end of the included cable (see packing list) into the USB jack on the charger or USB port on the computer.
 2. The indicator light will be red while charging.
 3. When the speaker is fully charged, the indicator light will turn off.
 4. Please use a qualified charger to recharge your speaker , If not, it may result in damage or even explosion.
 5. Repeated charging and discharging of the speaker will lead to decreased battery life over time, which is normal for rechargeable batteries.
 6. You must charge the speaker if it has not been used for more than 6 months.



Technical Specifications:

- Model Number: MU03030
- Range: 33ft / 10 m
- Battery Capacity: 300 mAh
- Voltage: 3.7 V
- Play Time: 2-3 hours
- Charging Time: 2-3 hours
- Charging Input: 5V = 150 mA
- Frequency Response: 20Hz-20kHz
- Operating temperature range: 0-45°C

FAQ:

- 1) Why can't I start my Bluetooth speaker?
Answer: Please ensure that the speaker is fully charged for your first use.
- 2) Why won't sound come out of the speaker?
Answer: Check whether the playback device and the Bluetooth speaker are successfully established. If the audio device is not properly connected, please reconnect. Please also adjust your mobile phone or Bluetooth speaker volume to a suitable volume level.
- 3) Why can't I find this speaker in my bluetooth options?
Answer: Make sure the Bluetooth is in “visible mode”. If no pairing occurs, the Bluetooth function will automatically shut off. Please reopen Bluetooth to “visible mode”. If there is a program error, please reboot your phone, and if program error is caused by your Bluetooth speaker, please restart the speaker.

FCC statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker .
- Do not drop, place heavy weight or allow heavy impact to the Headphone.
- PCB of battery should not be crushed and twisted.
- Battery body should not be Bended.
- Do not disassemble and Do not dispose of in fire.
- Do not use the product while driving or crossing the road.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2A2H6-MU03030

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

CLASS 1 LED PRODUCT

Keep All Relevant Information For Future Reference



WARNING:

This product can expose you to chemicals including Bisphenol A(BPA), which is known to the State of California to cause birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov.