


折后尺寸: 60*90

正面

880 User Manual

True wireless headphones



The light display interactive area, the first light color of charging and opening/closing is battery indicator, red light below 20%, white light between 21%-80%, blue light between 81%-100%.

Product Host and Accessories


- ① touch area (FMB)
- ② secondary microphone sound-receiving hole
- ③ speaker sound hole
- ④ earbuds charging pole
- ⑤ main microphone jack
- ⑥ type-C charging port
- ⑦ hanging chain buckle

Product Structure Description

- ① touch area (FMB)
- ② secondary microphone sound-receiving hole
- ③ speaker sound hole
- ④ earbuds charging pole
- ⑤ main microphone jack
- ⑥ type-C charging port
- ⑦ hanging chain buckle

Packing List

Wireless earbuds × 1	User manual × 1
Charging compartment × 1	Type-C charging cable × 1
Metal hanging chain × 1	



Before using the earbuds, please read this User Guide carefully and keep it for future reference.

Product Specifications

- ① touch area (FMB)
- ② secondary microphone sound-receiving hole
- ③ speaker sound hole
- ④ earbuds charging pole
- ⑤ main microphone jack
- ⑥ type-C charging port
- ⑦ hanging chain buckle

Product Structure Description

- ① touch area (FMB)
- ② secondary microphone sound-receiving hole
- ③ speaker sound hole
- ④ earbuds charging pole
- ⑤ main microphone jack
- ⑥ type-C charging port
- ⑦ hanging chain buckle



Packing List

Wireless earbuds × 1	User manual × 1
Charging compartment × 1	Type-C charging cable × 1
Metal hanging chain × 1	

Instructions

Power ON

It automatically enters the pairing state after taking out from the charging compartment, the white light turns on for one second to complete the boot.

Pairing

Wipe the earbuds from the charging compartment, the white light flashes quickly once paired, entering pairing mode automatically. Use a functional device to search for the name of "880", and click to pair it. If there is no connection within 3 minutes, the earbuds will automatically shut down.

Power OFF

- ① It will automatically shut down while putting the earbuds into charging compartment.
- ② Without a mobile phone or other device connected, press and hold the "FMB" for about 5 seconds, the white light flashes 3 times quickly, accompanied by a shutdown prompt sound to complete Power OFF.

Call function

Answering a call: When there is an incoming call, tap "FMB" once to answer. Hang up the call: In the call state, touch "FMB" once to hang up.

Music function

- ① 880 is successfully connected to your mobile phone, you can open the music app to play music.
- ② music mode:
 - ▶ Pause/Play: Touch the multi-function button once to pause the music-play, touch it again to continue.
 - ▶ Previous song: Tap the left "FMB" twice to the previous song.
 - ▶ Next song: Tap the right "FMB" twice to the next song.

Packing List

Wireless earbuds × 1	User manual × 1
Charging compartment × 1	Type-C charging cable × 1
Metal hanging chain × 1	

Instructions

Power ON

It automatically enters the pairing state after taking out from the charging compartment, the white light turns on for one second to complete the boot.

Pairing

Wipe the earbuds from the charging compartment, the white light flashes quickly once paired, entering pairing mode automatically. Use a functional device to search for the name of "880", and click to pair it. If there is no connection within 3 minutes, the earbuds will automatically shut down.

Power OFF

- ① It will automatically shut down while putting the earbuds into charging compartment.
- ② Without a mobile phone or other device connected, press and hold the "FMB" for about 5 seconds, the white light flashes 3 times quickly, accompanied by a shutdown prompt sound to complete Power OFF.

Call function

Answering a call: When there is an incoming call, tap "FMB" once to answer. Hang up the call: In the call state, touch "FMB" once to hang up.

Music function

- ① 880 is successfully connected to your mobile phone, you can open the music app to play music.
- ② music mode:
 - ▶ Pause/Play: Touch the multi-function button once to pause the music-play, touch it again to continue.
 - ▶ Previous song: Tap the left "FMB" twice to the previous song.
 - ▶ Next song: Tap the right "FMB" twice to the next song.

Packing List

Wireless earbuds × 1	User manual × 1
Charging compartment × 1	Type-C charging cable × 1
Metal hanging chain × 1	

Instructions

Power ON

It automatically enters the pairing state after taking out from the charging compartment, the white light turns on for one second to complete the boot.

Pairing

Wipe the earbuds from the charging compartment, the white light flashes quickly once paired, entering pairing mode automatically. Use a functional device to search for the name of "880", and click to pair it. If there is no connection within 3 minutes, the earbuds will automatically shut down.

Power OFF

- ① It will automatically shut down while putting the earbuds into charging compartment.
- ② Without a mobile phone or other device connected, press and hold the "FMB" for about 5 seconds, the white light flashes 3 times quickly, accompanied by a shutdown prompt sound to complete Power OFF.

Call function

Answering a call: When there is an incoming call, tap "FMB" once to answer. Hang up the call: In the call state, touch "FMB" once to hang up.

Music function

- ① 880 is successfully connected to your mobile phone, you can open the music app to play music.
- ② music mode:
 - ▶ Pause/Play: Touch the multi-function button once to pause the music-play, touch it again to continue.
 - ▶ Previous song: Tap the left "FMB" twice to the previous song.
 - ▶ Next song: Tap the right "FMB" twice to the next song.

Intelligent voice assistant

Activate: Tap the left "FMB" about 4 times to activate "Siri" / voice assistant. Exit: Voice exit "Siri" / voice assistant or be canceled by mobile phone.

Game Mode / Music Mode

A. After the earbuds are successfully connected to the mobile phone, tap the left or right "FMB" for 3 times to enter game mode, accompanied by a prompt sound of "Game Mode" with special sound effects.

B. Touch again the left or right "FMB" 3 times to enter music mode, with the prompt sound of "Music Mode" with special sound effects.

C. In music mode, the earbuds indicator light is off, in game mode, the earbuds indicator light flashes slowly (about 5 seconds per frequency).

Charging and battery precautions

This product has a built-in non-removable rechargeable battery. The charging current and voltage is 5V/500mA, please do not charge the product with a charger exceeding 5V/500mA, otherwise it will easily cause damage to the battery.

Safety Precautions

1. To ensure your personal safety, do not wear or place the earbuds too close to the pacemaker (less than 10cm).
2. Children should use this device under adult supervision, this product is not a toy.
3. Using the earbuds at high volume, especially for a long time, may damage your hearing.
4. For traffic safety, do not use earbuds while driving or riding a bicycle.

Charging the compartment: During charging, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

Opening charging compartment: After opening, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

SAFETY WARNINGS

Name and content of toxic and hazardous substances or elements in the product

This form is prepared according to the provisions of GJB 1136-2014

Part name	Toxic and Hazardous Substances or Elements				
Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBS)	Polybrominated diphenyl ethers (PBDE)
Metal parts	×	○	○	○	○
Gum parts	○	○	○	○	○
Wire	○	○	○	○	○
Circuit board assembly	×	○	○	○	○
Battery	×	○	○	○	○

SAFETY



PLEASE READ THE SAFETY WARNINGS CAREFULLY BEFORE USE

DO NOT USE LIQUID AND BRUSHES FOR CLEANING

CHARGING AND BATTERY



KEEP AWAY FROM HIGH TEMPERATURE

KEEP AWAY FROM FIRE

NO RAIN

KEEP AWAY FROM HEAVY SMOKE

SAFETY PRECAUTIONS



BALANCED TRANSPORTATION

DO NOT DROP WITHOUT PROTECTION

DO NOT CHARGE UNATTENDED OR SLEEPING

FAQ

1. What should I do if the left and right ear pairing fails?
If the left and right ears cannot be paired, please turn off the BT function of mobile phone first, put the earbuds back into charging compartment, then take out the earbuds according to above instructions to complete pairing steps. After they are successfully paired, turn on the BT function of mobile phone, and manually click to connect.
2. What to do when the phone is connected to 2 earphones at the same time?
A. Turn off the BT function of the phone, pick up the 2 earphones from the charging compartment at the same time, pair them again, then turn on the BT of phone after the pairing is successful, and manually click to connect again.
B. The earbuds directly disconnects both earphones, and reconnects according to the instructions.
3. Several problems that may occur when pausing playback:
After testing the Apple phone, the automatic reconnection cannot be performed after turning on again. You need to manually click the earbuds name to reconnect, then it can be used normally.
4. Earbuds have noise problems:

SAFETY

Name and content of toxic and hazardous substances or elements in the product

This form is prepared according to the provisions of GJB 1136-2014

Part name	Toxic and Hazardous Substances or Elements				
Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBS)	Polybrominated diphenyl ethers (PBDE)
Metal parts	×	○	○	○	○
Gum parts	○	○	○	○	○
Wire	○	○	○	○	○
Circuit board assembly	×	○	○	○	○
Battery	×	○	○	○	○

SAFETY

Intelligent voice assistant

Activate: Tap the left "FMB" about 4 times to activate "Siri" / voice assistant. Exit: Voice exit "Siri" / voice assistant or be canceled by mobile phone.

Game Mode / Music Mode

A. After the earbuds are successfully connected to the mobile phone, tap the left or right "FMB" for 3 times to enter game mode, accompanied by a prompt sound of "Game Mode" with special sound effects.

B. Touch again the left or right "FMB" 3 times to enter music mode, with the prompt sound of "Music Mode" with special sound effects.

C. In music mode, the earbuds indicator light is off, in game mode, the earbuds indicator light flashes slowly (about 5 seconds per frequency).

Charging and battery precautions

This product has a built-in non-removable rechargeable battery. The charging current and voltage is 5V/500mA, please do not charge the product with a charger exceeding 5V/500mA, otherwise it will easily cause damage to the battery.

Safety Precautions

1. To ensure your personal safety, do not wear or place the earbuds too close to the pacemaker (less than 10cm).
2. Children should use this device under adult supervision, this product is not a toy.
3. Using the earbuds at high volume, especially for a long time, may damage your hearing.
4. For traffic safety, do not use earbuds while driving or riding a bicycle.

Charging the compartment: During charging, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

Opening charging compartment: After opening, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

SAFETY

Name and content of toxic and hazardous substances or elements in the product

This form is prepared according to the provisions of GJB 1136-2014

Part name	Toxic and Hazardous Substances or Elements				
Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBS)	Polybrominated diphenyl ethers (PBDE)
Metal parts	×	○	○	○	○
Gum parts	○	○	○	○	○
Wire	○	○	○	○	○
Circuit board assembly	×	○	○	○	○
Battery	×	○	○	○	○

SAFETY

Intelligent voice assistant

Activate: Tap the left "FMB" about 4 times to activate "Siri" / voice assistant. Exit: Voice exit "Siri" / voice assistant or be canceled by mobile phone.

Game Mode / Music Mode

A. After the earbuds are successfully connected to the mobile phone, tap the left or right "FMB" for 3 times to enter game mode, accompanied by a prompt sound of "Game Mode" with special sound effects.

B. Touch again the left or right "FMB" 3 times to enter music mode, with the prompt sound of "Music Mode" with special sound effects.

C. In music mode, the earbuds indicator light is off, in game mode, the earbuds indicator light flashes slowly (about 5 seconds per frequency).

Charging and battery precautions

This product has a built-in non-removable rechargeable battery. The charging current and voltage is 5V/500mA, please do not charge the product with a charger exceeding 5V/500mA, otherwise it will easily cause damage to the battery.

Safety Precautions

1. To ensure your personal safety, do not wear or place the earbuds too close to the pacemaker (less than 10cm).
2. Children should use this device under adult supervision, this product is not a toy.
3. Using the earbuds at high volume, especially for a long time, may damage your hearing.
4. For traffic safety, do not use earbuds while driving or riding a bicycle.

Charging the compartment: During charging, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

Opening charging compartment: After opening, the RGB lights of charging compartment gradually brighten from the central LOGO position to the outer lights. The initial light color is the current battery indicator color, take a breath and flash slowly, then turn yellow-white-blue colors in sequence, each color light shows a breathing effect and then turns off.

SAFETY

Name and content of toxic and hazardous substances or elements in the product

This form is prepared according to the provisions of GJB 1136-2014

Part name	Toxic and Hazardous Substances or Elements				
Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBS)	Polybrominated diphenyl ethers (PBDE)
Metal parts	×	○	○	○	○
Gum parts	○	○	○	○	○
Wire	○	○	○	○	○
Circuit board assembly	×	○	○	○	○
Battery	×	○	○	○	○

SAFETY

Intelligent voice assistant

Activate: Tap the left "FMB" about 4 times to activate "Siri" / voice assistant. Exit: Voice exit "Siri" / voice assistant or be canceled by mobile phone.

Game Mode / Music Mode

A. After the earbuds are successfully connected to the mobile phone, tap the left or right "FMB" for 3 times to enter game mode, accompanied by a prompt sound of "Game Mode" with special sound effects.

B. Touch again the left or right "FMB" 3 times to enter music mode, with the prompt sound of "Music Mode" with special sound effects.

C. In music mode, the earbuds indicator light is off, in game mode, the earbuds indicator light flashes slowly (about 5 seconds per frequency).

Charging and battery precautions

This product has a built-in non-removable rechargeable battery. The charging current and voltage is 5V/500mA, please do not charge the product with a charger exceeding 5V/500mA, otherwise it will easily cause damage to the battery.

Safety Precautions

1. To ensure your personal safety, do not wear or place the earbuds too close to the pacemaker (less than 10cm).
2. Children should use this device under adult supervision, this product is not a toy.
3. Using the earbuds at high volume, especially for a long time, may damage your hearing.
4. For traffic safety, do not use earbuds while driving or riding a bicycle.