



Diagram of the front panel of the device showing various ports and buttons. The top panel includes a 'DUP LINK' indicator, a USB port, a Type-C port, a MIC input, and a power button. The bottom panel features a LAN port, an HDMI port, an eSATA port, a FIREWIRE port, an AUDIO port, and a DC IN port. Numbered callouts 1 through 7 identify these components.

1. USB port
2. Type-C port
3. MIC headphone jack
4. power button
5. LAN port
6. HDMI port
7. DC in port



The diagram illustrates three mounting options for the power adapter, each within a dashed rectangular frame:

- Wall-Mounted bracket:** Shows the power adapter mounted on a wall using a bracket with two screws.
- fix bracket on MINI PC with screws:** Shows the power adapter mounted on the back of a MINI PC using a bracket and four screws.
- fix bracket on the back of display with screws:** Shows the power adapter mounted on the back of a display using a bracket and four screws.

Below the diagram, a warning icon (a yellow triangle with an exclamation mark) is followed by the text: "Failure to use the included power adapter may violate regulatory compliance requirements and may expose the user to safety hazards." Below this, a note states: "* specifications are subject to the physical product."


DDR Memory Installation. (As shown in the picture)

- 1.Align the memory module key along with the memory socket key and insert the memory at a 30 degree angle,Slide the module into place.



SSD Card Installation. (As shown in the picture)

- 1.Align the notches on the SSD with the tabs in the M.2 slot on the mother board.
- 2.Slide ssd in then secure the SSD with screw.




Note: The HDD installation guide is inscribed on HDD cover.

Connect speakers, headphones, a webcam with a built-in microphone, a Bluetooth headset, or another audio devices to your Windows PC and you'll need to choose which devices Windows actually uses.

1. Just click the sound icon in your notification area (also known as the system tray).
2. Click the "Select playback device" option.
3. Select the playback device you want to use from the menu.

In order to continue to improve the user experience, we may occasionally update app and firmware.

- Do not use harsh of chemical solvent, cleaning products. We recommend using a soft cloth to wipe.
- Do not throw product into fire, avoid having fire accident.
- Do not attempt to open the housing or to repair, if a failure occurs, please contact the customer service.
- Please note seepage while clean electronics, be careful of electric shock.
- Check for any frayed or damaged cords or plugs.
- Don't arbitrarily discard the product, we should protect the environment.
- Operating environment: -10°C~45°C, 30%~85% humidity.
- Storage environment: -20°C~60°C, 10%~90% humidity.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure com

Manufacturer : ShenZhen AZW Technology co.,Ltd
Address : 4th Floor,Building 18,Longjun Industrial Park,
 Bujiuwo,Longhua New District,ShenZhen,China

