15W Alarm clock wireless charger's instruction

Controlling switch display (from left to right):

First turn on the power supply button, (DC5V)) scan display appearance **88:88**, and then display the time.

Press the power button to enable/disable the time

press the power button long time of for more than 3 seconds to reset the clock time

 \rightarrow 00:00 / 06:00,

(I) Set the time

(Operate as below when displaying the time)

- 1.1 Short Press M to switch the hour/minute setting.
- 1.2 When entering the above setting mode:

Short Press ∇: + hour/minute;

Short Press \triangle : - hour/minute;

1.3 Long Press M to save the Settings and exit the time setting.

(II) Set alarm Time

(Operating as below when displaying the time)

2.1 (first) Short Press ∇ to enter ALARM setting, and Short Press \mathbf{M} to switch hour/minute setting;

(Note: this key is only used to set the alarm clock time for the first time, and then adjust the time)

- 2.2 Short Press∆ :decrease hour/minute, Short press ∇: increase hour/minute;
- 2.3 Long Press **M** to save the timing and return to the time display screen;
- 2.4 (It can be be operated after returning back to the time display interface)
 Long press ∇ to switch and confirm the time state **ON/OFF**(only one set of alarm clock time can be set)

(Ⅲ) Setting the Time Format(12H/24H)

(Operating as below when displaying the time)

Short Press △ : Switch to 12/24 hour system

(IV) Snooze function

When the alarm goes off, tap the wireless charging host/press any button to make the alarm stop working. The alarm ringing for 1 minute, after that it will be ringed 1 minute per 3 minutes interval. If don't tap or press any button, it will be stopped after 1

hour.

Note: It will return to the time display state without pressing the button for 30 seconds, when setting the mode.

Wireless Charger Instruction Manual:

Product Specification:

Input Voltage: DC5V/2A 9V/1.67A

Output: 5V/1A 9V/1.1A Size:113*112*32MM Efficiency:≥72%

Transmission distance ≤6MM

Indicator:

Non-wireless charging status:No display lamp Device is on charging: the Blue light is always on Device full charged: the Blue light is always on. Foreign substance detection: Blue lights flashing

Attention:

- 1. Please keep the charger away from water or other liquid.
- 2. If you need to clean the charger, please make sure it is not connected to power supply
- 3. Using Environment temperature remains 0-45°C.
- 4. Please use a 5V /2A adapter or high quality cable to ensure charging effect.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.