

THE **PLATINUM**
K a r a o k e
BRING *Music* TO YOUR *Life*

THE PLATINUM
Karaoke
BRING MUSIC TO YOUR LIFE

B10-PKPWM100U

PORTABLE WIRELESS MICROPHONE



USER MANUAL

Getting Started

Important Safety Instructions

Read these operating instructions carefully before using the unit. Follow all the safety instructions listed below. Keep these operating instructions handy for future reference.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, stoves, refrigerator or other apparatus of this kind.
9. Do not install on top of amplifiers or other apparatus that produce heat.
10. Make sure that you are using the correct electrical socket for your plugs, do not force to insert your plug to a socket if it doesn't fit.
11. Protect the power cord and/or power adapter and power adapter cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
12. Unplug this unit during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Contents

Getting Started

Important Safety Instructions	1
Precaution	2
Accessories	3
Description	
Mic	4
Receiver	5
Replacing Battery	6
Adjust Frequency	7
How to use	8
Specifications	8

Precautions

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER.

NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
The lightning flash and Arrowhead within the triangle is a warning sign alerting you of dangerous voltage inside the product.	Caution: to reduce the risk of electric shock, do not remove cover No user serviceable parts inside. Refer servicing to qualified service personnel.	The explanation point within the triangle is a warning sign alerting you of important instructions accompanying the product.

Do not install this equipment in a confined space such as a bookcase or similar areas.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

Precautions

Warnings

- For the safety of the equipment and adequate ventilation.
- The microphone has a built-in lithium battery. Do not operate in an environment with too high or too low temperature.
- Exposed flame sources should not be placed on the equipment.
- Do not throw battery when it ran out. Please put it in designated recovery box. The Battery contains heavy metals like mercury, cadmium, and lead. If the batteries are mixed into domestic waste. Heavy metals may contaminate groundwater and soil.
- Equipment can be used normally in tropical/temperate climate conditions
- Do not place liquid filled items such as vases on the equipment to prevent being exposed to water droplets or water splashes.


Accessories

Check and Identify accessories


Note: photo may vary from actual units



Wireless Microphone



Receiver



Type-C




Manual




Batteries

Description




Description




Replacing Battery


1. Rotate and remove the microphone net cover



2. Push up the microphone cover and remove it




3. Make sure the battery is placed in the right direction




Adjust Frequency


1. Rotate and remove the microphone net cover



2. Push up the microphone cover and remove it





3. Press the key to adjust the frequency



How to use

Plug the receiver into the device with 6.5mm MIC interface, and turn on the power supply of the receiver and microphone



Plug and play

RECEIVER	
Frequency response	20-20K
Battery voltage	3.7V
Frequency range	570.1-588MHz
Charging voltage	5V

TRANSMITTER	
Frequency range	570.1-588MHz
Frequency response	20-20K
Impedance	50Ω
Battery voltage	3.7V
Working range	15m
Sensitivity	-97dB
Charging voltage	5V

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction

Ant.	Antenna Brand	Antenna Model Name	Antenna Type	Connector	Gain (dBi)	EIRP(dBm)	NOTE
1	N/A	FTGB	Sring Antenna	N/A	-2.32	6.31	Antenna