

USE manual

Working voltage: 5VDC 2.0A

Rated Power:10W

Level of protection :IP20

Working temperature :-35°C ~+55°C

installation requirements and maintenance

- 1, first of all to sort out the lamps and lanterns supporting various parts and accessories.
2. Power supply must be cut off before installation. DC voltage regulator is used for power supply
- 3.the lamp body with the wires on the matching the power cord.
- 4.Ensure that the product is fastened to the surface of the installed object in the following operations, and finally turn on the power. 1. There may be danger if the operation is not in accordance with the instructions. 2. Illegal operation may damage your articles or even endanger your personal safety.

warning:

- 1, not according to the manual operation could be dangerous.
- 2, peccancy operation may damage your items, and even damage to your personal safety.

Please repair, should have professional maintenance or repair center, otherwise easy to produce risk, the consequence is proud. Zhongshan beam Angle lighting technology Co., LTD

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction