
A8 使用说明书



• 蓝牙版本: V5.3+BR+EDR

• 耳机充电时长: 约1小时

电源盒充电:约1.5小时

产品参数

• 支持协议: A2DP\AVCTP\AVDTP\ AVRCP\HFP\HID • 传输距离: > 10m · 音频编码: SBC • 充电接口: Type-C • 输入电压电流: DC5V -- 0.2A • 输出电压电流: DC5V -- 0.2A •播放时长:单次播放70%音量时长约4小时,带充盒使用 约10小时 • 通话时长:约3小时

开/关机

• 打开设备蓝牙,搜索 "A8" ,选择连接 替闪烁,副耳灯灭,连接上设备后所有灯灭

打开充电盒,**取出耳机,耳机自动开机**

耳机在盒外,关机状态,长按功能键3秒开机

蓝牙连接

产品操作说明

放入充电盒,关机

for 3 seconds to turn it on

automatically enter the pairing mode

开机状态,**长按5S关机**

未连接设备5分钟后自动关机

·再次开机,耳机自动回连上次设备,回连失败后耳机自 • 给耳机充电,充电盒对应的L/R长亮,充满电10秒后灭, 导致设备故障、着火或爆炸。 动进入配对模式

触控功能 暂停/播放 单击左/右功能键 下一曲 三击右边功能键

三击左边功能键 上一曲 音量加 双击右耳功能键 音量减 双击左耳功能键 语音助手 长按2秒左/右功能键 接听/挂断 单击任意功能键 拒接电话 长按2S任意功能键 取消拨号 拔号中单击任意功能键

注:单耳使用时,双击为音量加;三击为下一曲 ·首次开机,自动进入蓝牙配对状态,主耳白、冰蓝灯交 - Type-C数据线插入充电端口,数码管末位闪烁,充满电 部加热设备对其进行干燥处理。 耳机充电时耳机白灯常亮,充满电,所有灯灭


注意事项 •耳机和充电仓使用一星期左右,用棉签或碎布清洁耳机和 充电仓的充电触点,防止顶针上有污垢,避免造成充电接

•不使用耳机时,请将耳机放回充电盒中,以防止丢失并及 时为耳机充电。 •清洁和维护前,请停止使用本设备,关闭所有应用,并断

开与其他设备的所有连接或线缆。 •请使用清洁、干燥的软布擦拭设备或其配件。 •带锂电池的产品若长时间不使用,请至少确保每三个月充

•请保持设备及其配件干燥。请勿使用微波炉或吹风机等外 •请勿在温度过高或过低区域放置设备及其配件,否则可能 •请勿使用烈性化学制品、清洗剂或强洗涤剂清洁设备或其

A8 Instruction manual



Product parameter

Bluetooth version: V5.3+BR+EDR Support protocol: A2DP\AVCTP\AVDTP\ AVRCP\HFP\HID • Transmission distance: > 10m Audio coding: SBC Charging port: Type-C • input voltage current: DC5V = 0.2 A

Current, output voltage: DC5V = 0.2 A • Playback time: about 4 hours for a single playback of 70% volume, about 10 hours with a charging case • Call duration: > 3 hours

 Charging time: about 1 hour • Power box charging: about 1.5 hours Product operation instruction Open the charging case and take out the earphones, which will turn on automatically

• The earphone is off outside the box. Long press the function button

Put it in the charging case and turn it offPress and hold for 5S to power off Disconnected devices automatically shut down after 5 minutes Bluetooth connection • Turn on your device's Bluetooth, search for "A8" and select Connect •When the device is turned on for the first time, it will automatically enter the Bluetooth pairing state. The white and ice blue lights on the main ear will flicker alternately, and the secondary ear lights will be off **charge** When the device is turned on again, the headset will automatically onnect back to the last device. If the connection fails, the headset will

Touch function

Next track

Previous piece

Volume down

Volume up

Click the left and right function keys Triple the right function key Triple the left function key Double-click the right function key Double-click the left function key Long press left/right for 2 seconds Voice assistant Click any function

Answer a call Long press left/right for 2 seconds Hang up Long press left/right for 2 seconds Reject a call Click any function key Cancel dialing

 When the Type-C data cable is inserted into the charging port, the digital tube flashes at the end and lights up after full charge • When charging the earphone, the L/R corresponding to the charging case will be long on and off after 10 seconds of full charge. When the earphone is charging, the white light of the earphone will be steady on.

Matters needing attention •The earphone and charging bin are used for about a week. Clean the earphone and charging bin's thimble with cotton swabs or rag to prevent dirt on the thimble and avoid bad charging contact When not in use, please put the earphones back in the charging case to prevent loss and timely charge the earphones. Before cleaning and maintenance, stop using the device, shut down

all applications, and disconnect all connections or cables from other • Use a clean, dry, soft cloth to wipe the device or its accessories. • If the product with lithium battery is not used for a long time, make sure to charge it at least once every three months Note: When using in one ear, double-click to add volume; Three clicks • Keep the device and its accessories dry. Do not use external heating devices such as microwave ovens or hair dryers to dry them.

> temperature is too high or too low. Otherwise, the device may fail, catch fire, or explode. Do not use strong chemicals, cleaning agents, or strong detergents to clean the equipment or its accessories.

• Do not place the device or its accessories in an area where the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of He following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, tollowing two conditions:(1) I his device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.