

# Wireless Controller Descriptions

## Applications:

1. 2.4GHZ wireless technology, effective distance about 30 feet.
2. This wireless controller compatible for XBOX One console, and is compatible for PC(D-INPUT), PC360(X-INPUT) games (PC can only be used under Win10 system), PS3 console.

## How To Connect?

1. Connect With The Xbox One Console, Plug The Receiver Into The Usb Port Of The Host, The Receiver's Light Will Flash, Then Press The Home Button Of The controllers, The controllers Light Will Flash, So That Is In The Connection, When The controllers Light And Receiver After The Light Is Always On, The Connection Is Successful And Can Be Used Normally On The Host.
2. Connect With The Computer. As With The Above Operation, When The Light Of The controllers And The Light Of The Receiver Are Long, The Connection Is Successful. At This Time, It Is Xbox One Mode. Long Press The Home Button For 5 seconds To Switch To "X-INPUT" And "D• INPUT" Mode.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction