

ATLAS CUSTOM VI Gaming Mouse Specification

一: Appearance Specifications

Gaming Mouse		
1	MODEL NO:	ATLAS CUSTOM VI
2	Length:	124.5mm
3	Width:	64mm
4	Height:	42mm
5	Weigh:	71±5g



二: Electrical Parameters

1	Mouse Type:	Gaming Mouse
2	Interface:	USB
3	Image Sensor:	3335IC
4	Acceleration:	50G
5	High Speed Motion Detection:	400IPS
6	Resolution:	800-16000
7	Polling Rate:	1000Hz
8	Keys Function:	Left Button Right Button Wheel Button Forward Button Backward Button DPI Button Light Button Switch Button
9	Left&Right Switch:	Huano 20 Million Switch
10	LED:	RGB LED Effects
11	Cable:	1.6m Paracord Cable
12	System:	Win7 /Win8 /Win10 /Windows VISTA /Windows XP
13	Power Supply:	3.7V-400mA
14	Main Button:	Soild/Honeycomb
15	Foot Pad:	0.8mm PTFE Rounded Edge

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.