# MX-3282 FLOOR LIGHT
Instruction Manual

POWER SATION INSTALL INSTRUCTION

1. SCREW 2. DC HOLE
3. NUT 4. DC WIRE

INSTALL STEP
1.PUT THE POWER SATION ON THE NUT
2.TWIST THE NUT(3) WITH SCREW(1)
3.CONNECT THE DC WIRE(4)WITH DC HOLD

OPERATION BY FLOOR LIGHT

1. ADJUST BRIGHTNESS

- One click the ✹ to increase brightness,it would be have 10 levels brightness.
- Hold press the ✹ to increase brightness continuity. it would have 10 levels brightness.
- One click the ✹ to reduce brightness, it would be have 10 levels brightness.
- Hold press the ✹ to reduce brightness continuity. it would have 10 levels brightness.

2. ADJUST COLOR TEMPERATURE
One click ✹ from 2700K-3500K-5500K-6500K to select the color temperature.

3. POWER OFF MEMORY FUNCTION
The intelligent LED light has a state memery function. When each light is adiusted to the appropriate color temperature and brightness, when the remote control or the ordinary wall switch is turned off and on again, the state of the light is the state before the last time the light was turned off .

POWER STATION INSTRUCTION

1. Build in 5V-1A wireless charging function, put device on the power station plate centre to activate.
2. Build in 5V-2A output charging,connect device to charging.

OPERATIONL BY REMOTE CONTROL

1. PAIR
The remote control needs to be coded before it can be used. The method is as follows :

The floor light connect to power supply, hold press the ⏻ of the remote control at the same time , after the light blink 1 times the setting finish.

2. ADJUST BRIGHTNESS

- One click the ✹ to increase brightness,it would be have 10 levels brightness.
- Hold press the ✹ to increase brightness continuity. it would have 10 levels brightness.
- One click the ✹ to reduce brightness,it would be have 10 levels brightness.
- Hold press the ✹ to reduce brightness continuity ,it would have 10 levels brightness.

3. ADJUST COLOR TEMPERATURE
One click ✹ from 2700K - 3500K - 5500K - 6500K to select color temperature.

4. SETTING TIME TO TRUN OFF LIGHT
⏲ setting after 60 second to turn off floor light ;
setting after 1 hours to turn off floor light.

5. EXPRESS MODE SETTING
there can be setting 3 express mode, the method as follows:

Choose the brightness and color temperature as you want, hold press any express mode button of remote control 2-3 second,after floor blink 1 times finish the setting.

6. POWER OFF MEMORY FUNCTION
The intelligent LED light has a state memery function. When each light is adiusted to the appropriate color temperature and brightness, when the remote control or the ordinary wall switch is turned off and on again, the state of the light is the state before the last time the light was turned off .

SMART HOME OPERATION
Software User Manual for IOS APP installation instructions:
Method 1: Search Magic Home Pro in "APP Store" ,Onclick the bellow link and download the app. http://fir.magichue.net/8d9a

Magic Home pro

Method 2: Download the APP by scanning the bellow QR code for free.

Step 1   Step 2

Software User Manual for Android.
APP installation instructions:
Method 1: Search Magic Home Pro in "Google Play Store" or from browsers,Installation details as follows.

Step 1   Step 2

Installation details as below

Method 2: Download the APP by scanning the bellow QR code for free.

Installation details as below

Step 1   Step 2

Instructions
There are three different ways to connect the controller after it has been connected to the power supply.

a) Wi-Fi mode: This mode needs register and login after complete 1 to 1 Mode.(Please refer to connection mode c) Make sure the controller has been powered and never been set, please operate as bellow steps.

b)1.Click "+" in the upper right corner and click "Connect light to Wi-Fi network"

2.Register and login account

3.Connect the device to the router

works with
Google Assistant

Step 1: Create your Magic Home cloud account
In order to control your smart light with the Google Assistant or control them remotely you need to create a Magic Home dloud account and sign in.

Step 2: Add your light and modify the name
Make sure there is at least one smart light in device list, and enable your lights for remote control. On "Home" page, long press light to rename.

Step 3: Add Home Control Action
Click 'Home controf on'Home'APP. Select "Magic Home WiFi' The account and password must be same as the one you created in Magic Home Pro APP.

amazon alexa

Step 1: Create your Magic Home dloud account
In order to control your smart light with the Amazon Echo or control them remotely, you need to create a Magic Home dloud account and sign in.

Step 2: Add your light and modify the name
Make sure there is at least one smart light in device list, and enable your lights for remote control. On "Home" page, long press light to rename.

Step 4: Login with your account
Enter your app account and password to finish the account linking. (Use the Magic Home dloud account you used on step 1), Your lights will be listed on 'Home ControlInterface...

Step 5: Control your light
Here, you finish all setups. You can now control your lights by issuing voice commands.
Supported Commands:
Say "Ok Google" or "Hey Google", then...
Turn on <light name>
Turn on/off <light name>
Turn on/off all the lights

c) Remote control via Internet
Here you can locate the Wi-Fi controller via the internet from anywhere in the world for Wi-Fi mode (connect mode(a),Keep the Wi-Fi router online, no matter where you are ,you still can control your lights with APP as long as there's Wi-Fi/3G/4G internet for your smartphone.

Step 3: Enable Alexa Skill
The next step is to download the Amazon Alexa app , open the Amazon Alexa app and under the skills section, search for the "Magic Home" skill.The account and password must be same as you created in Magic Home Pro APP.

Step 4: Login and Discover Devices
Use your Magic Home dloud account you created in step 1 to sign in to "Magic Home" Skill. The next step is to discover your smart lights from Alexa app. You can say "Alexa, discover devices".
Once Alexa has completed discovering your smart lights, they will be shown in the Smart Home section in Alexa app.

Step 5: Control your light
Here, you finish all setups. You can now control your lights by issuing voice commands.
Supported Commands:
These are some of the currently supported Alexa voice commands for the smart light.
Alexa, turn [light name] on/off

d) 1 to 1 Mode: Open mobile Wi-Fi network signal, find "LEDnet******"signal and connect, then open Magic Home Pro APP.

If the network connect successfully you can enter the APP for operation.

Reset
If you want to reset the device,should be operation as follow STEP 1.power off the device

STEP 2.connect power and cut off it 3 times(even operation should be more than 2 second)

OFF
X3
Light ON

Share
If you want to share the device to other people,the operation is as follows STEP 1.Open Device Settings in APP, and click the device you are currently using to enable remote Settings.

STEP 2.Go to Device Information and click Share Device.Add a share and enter the email address for the share

Lampara de piso MX-3282
Manual de instrucciones

## INSTRUCCIONES DE INSTALACIÓN DE LA CENTRAL ELÉCTRICA

1. TORNILLO 2. AGUJERO DC
3. TUERCA 4. CABLE DE CC

PASO DE INSTALACIÓN
1.PONER LA CENTRAL ELÉCTRICA EN LA TUERCA
2.GIRRE LA TUERCA (3) CON TORNILLO (1)
3.CONECTE EL CABLE DC (4) CON DC HOLD

USO DE LA LAMPARA DE PISO

1.Ajuste el brillo
- Presione una vez el boton ✹ para incrementarel brillo.Cuenta con 10 niveles de brillo.
- Mantenga presionado el boton ✹ para incrementar el brillo de manera continua. Tendra10 niveles de brillo.
- Presione una vez el bottón ✹ para reducir elbrillo.Tiene 10 niveles de brillo.
- Mantenga presionado el boton ✹ para reducirel brillo de manera continua.Tiene 10 niveles debrillo.

2.Ajuste la Temperatura del Color
Presione el boton ✹ para seleccionar la temperatura del color que son: 2700K-3500K-5500K-6500K

3.Funcion de Memoria al apagarse
La luz LED inteligente tiene una funcion de memoria delestado de iluminacion. si la luz es ajustada al color detemperatura y brillo apropiados; cuando usted apaga desde el control remoto o el interruptor de pared ordinarioy encierde nuevamente esta lo har en el estado de la luzanterior al apagado.

INSTRUCCION DE LA ESTACION DE ENERGIA
1. Funcion de carga inalambrica de 5v-1A incorporada, ponga el dispositivo sobre el centro plateado de la estacion decarga para activar.
2. Carga alambrica con salida de 5V-2A incorporada, conectael dispositivo para cargar.

USO DEL CONTROL REMOTO

1.Empareje
El control remoto necesita emparejase por codigo antesde ser usado.El método es el descrito a continuacion:

Conecte la Impara de piso a la corriente eléctrica,almismo tiempo mantenga presionado al boton delcontrol remo, despues de que la luz parpadea 1 vez elajuste finaliza.

2. Ajuste el Brillo
- Presione el boton ✹ para incrementar el brillo entre los 10 niveles que tiene.
- Mantenga presionando ✹ para incrementar el brillo continuamente.
- Presione ✹ para reducir el brillo entre los 10 niveles ofrecidos.
- Mantenga presionando ✹ para reducir el nivel de brillo continuamente.

3. Ajuste la Temperatura del Color
Presione el botón para seleccionar la temperatura delcolor que son: 2700K-3500K-5500-650ok

4. Ajuste el tiempo para apagar la luz
⏲ Presione para ajustar el apagado despues de 60 segundos.Presione para programar el apagado despuês de 1 hora.

5. Modo de ajuste rapido
Puede ajustar 3 modos rapidamente, elmetodo se detalla a continuacion:

Elija el brillo y temperatura del color que desee, mantengapresionando de 2 a 3 segundos cualquiera de los botonesde"Modo Rapido" en su control remoto, despues de quela Impara parpadee 1 vez, el ajuste finaliza.

6. Funcion de Memoria
La luz LED inteligente tiene una funcion de memoria delestado de iluminacion. si la luz es ajustada al color detemperatura y brillo apropiados; cuando usted apaga desde el control remoto o el interruptor de pared ordinarioy encierde nuevamente esta lo har en el estado de la luzanterior al apagado.

Uso de Hogar Inteligente
Manual de uso para la instalacion de laaplicacion en software ios
Metodo 1: Para descargar la app, busque "Magic Home Pro"en la App Store o vaya a la direccion del enlace a continuacion.http://fir.magichue.net/8d9a

Magic Home pro

Metodo 2: Descargue la app escaneando elcodigo QR

DETALLES DE INSTALACION A CONTINUACION

Paso 1   Paso 2

Manual de uso para la instalacion de la aplicacion ensoftware Android
Metodo 1.Para descargar la app, busque "Magic Home Pro"en laGoogle Play Store o desde navegadores de escritorio

Paso 1   Paso 2

Metodo 2.Descargue la app escaneando el codigo QR

### DETALLES DE INSTALACION A CONTINUACIÓN

Paso 1   Paso 2

Instrucciones
Hay tres diferentes maneras de conectar el controldespués de que ha sido conectada a la corrienteeléctrica.

a) Modo Wi-Fi: Este modo necesita del registro e ingreso después decompleto el modo 1 a 1 (Por favor consulte el modo de conexion C)Asegurese de que el control ha sido encendido y nunca haya sidoemparejado con otra lampara, use como se indica a continuacion.

a) Modo Wi-Fi: Este modo necesita del registro e ingreso después decomplete el modo 1 a 1
(Por favor consulte el modo de conexion C)Asegurese de que el control ha sido encendido y nunca haya sidoemparejado con otra lampara, use como se indica a continuacion.

2.Registre e ingrese una cuenta

3.Conecte el dispositivo al enrutador

c)Control remoto via Internet.
Aqui puede localizar el controlador Wi-Fi via internet desde cualquier lugar en el modo Wi-Fi (Por favor consulte elmodo de conexion a). Mantenga al enrutador wi-fi en linea, sinimportar donde este, usted aun podré controlar sus luces con laApp siempre y cuando haya internet Wi-Fi/3G/4G en su telefoninteligente.

d)Modo 1 a 1:
Abra la red movil y encuentre la senal "LEDnet*******" y conectala despues abra la app Magic Home Pro.

If the network connect successfully you can enter the APP for operation.

works with
Google Assistant

Paso 1: cree su cuenta Magic Home Cloud
Para controlar su luz inteligente con el asistente de Google o remotamente usted necesitar crear e ingresar una cuenta Magic HomeCloud.

Paso 2: Agregue su luz y modifique el nombre
Asegurese que haya al menos una luz inteligente en la lista de dispositivos y activar su luces control remoto.En la section"Home" mantenga presionado la luz en la lista y modifique el nombre.

Paso 3: Agregue la accion de control en el hogar
De clic en "Home Control" la pagina principal de la App, seleccione "Magic Home Wi-Fi"La cuenta y contrasena deben ser las mismas quese crearon en la app "Magic Home Pro".

WORKS WITH
amazon alexa

Paso 1: cree su cuenta Magic Home Cloud
Para controlar su luz inteligente con el asistente Amazon Echo o remotamente usted necesitara crear e ingresar una cuenta Magic HomeCloud.

Paso 2: Agregue su luz modifique el nombre
Asegurese que haya al menos una luz inteligente en la lista de dispositivos yactive su luz para control remoto.En la section "Home" mantenga presionado la luz en la lista y modifique el nombre.

Paso 3: Active la habilidad de Alexa
El siguiente paso es descargar la app "Amazon Alexa" , abra la aplicacion ybelajo en la section de"skills" busque la habilidad Magic Home. La cuenta contrasña deben ser las mismas que se crearon en la aplicacion MagicHome Pro.

Paso 4: Ingrese y descubra dispositivos
Use su cuenta de Magic Home Cloud que creó en el paso 1 para ingresar ala habilidad Magic Home of ingrese enla aplicacion "Alexa descubradispositivos" Una vez que Alexa ha completado el descubrimiento de sus luces inteligentes,sern mostradas en la seccion"Smart Home" en la app Alexa.

Paso 5: Controle su luz
Ya finalizados los ajustes, ya puede controlar sus luces emitiendo comandosde voz.
Comandos Admitidos
Esos son algunos de los comando de voz admitidos actualmente por Alexa.Alexa Encienda -Nombre de la luz-Apague/Encienda

Reiniciar y Compartir
Si este producto està conectado en un lugar, necesitará reiniciar si se cambia de Wi-Fi en otro lugar, El método de reinicio es para mantener el estado abierto y se debe apagar el contacto o desconectarlo del mismo 3 veces seguidas, esto significa que se encuentra en un estado de conexión abierta.
El método es el descrito a continuación
PASO 1. Antes de reiniciar, por favor apague el dispositivo.

OFF

PASO 2. Comience el reinicio. Encienda y después apague (Repita este proceso tres veces)
PASO 3. Comience el reinicio. Encienda y después apague (Repita este proceso tres veces)
(Nota: no realice los cambios demasiado rápido) Si el controlador no cambia con interrupciones, puede conectar y desconectar directamente el cable de tomacorriente del dispositivo 3 veces.

OFF   OFF   X3

Si necesita compartir en el mismo lugar con 2 o 3 teléfonos móviles, se requiere la compartición con otra cuenta de conexión.
El método se describe a continuación:
PASO 1.Abra los ajustes de Dispositivo en la aplicacion y de clic en el dispositivo que está utilizando actualmente para activar los ajustes Remotos.

PASO 2. Dirijase a "Informacion de Dispositivo" y oprima "Añadir Dispositivo" e ingrese la cuenta de correo para compartir.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different
   from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

For BT/WIFI:

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

For WPT:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

FCC ID: 2A6FR-3282