


H18

Fast wireless charging stand with mouse pad



Packing list



Wireless charging mouse pad x 1



User manual x 1



USB charging cable x 1

Details about buttons



Product parameters

Product Mode: H18

Material: ABS + cloth + rubber

Input Voltage: 5V/2A , 9V/2A

Product Interface: USB interface

Output Power: 5W , 7.5W , 10W , 15W

Conversion Rate: > 80%

Charging Frequency: 110.5K-148.5kHz

Compatible devices: all Qi standard wireless charging devices

Product Size: 810 x 310 x 4mm

RGB lighting control

Inductive touch the button to turn on RGB lights.

Long touch the button to turn off the RGB lights.

Touch the button to switch the colors of RGB lights(The RGB lights support 6 lighting modes).

Wireless charging

When you plug in the power supply through a USB cable (5V-2A / 9V-2A), place the wireless charging supported phone in the wireless charging area of the product, and it will automatically charge the phone.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.