


英文

<p>Singal Source Setting</p> <p>Press the “” button above the remote control, enter the [input signal] channel, press “OK” to switch the input source.</p> <p>Note: ① you want to return to the previous layer, please press “”; ② you want to return to the main interface, please press “”.</p> <p>FCC Statement</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference caused by other devices.</p> <p>Causes or modifications to this unit not expressed or approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.</p> <p>Radiation Exposure Statement</p> <p>To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm from your body.</p> <p>  </p> <p>Shenzhen Wanbo Technology Co., Ltd. www.szwanbo.com</p>	<p>U Disk Support Format</p> <table border="1"> <thead> <tr> <th>File Type</th> <th>File format supported</th> </tr> </thead> <tbody> <tr> <td>Picture</td> <td>JPG, BMP, PNG, GIF</td> </tr> <tr> <td>Video</td> <td>H.265, H.264, VP9@60, MPEG1/2/4, VC-1, AVS/AVS+(Above based on 1080P@60fps or 30fps)</td> </tr> <tr> <td>Audio</td> <td>FLAC, APE, MP3, WAV, OGG</td> </tr> </tbody> </table> <p>Note: Specific operation contents are subject to actual situation due to irregular update of the product system.</p> <p>Mobile Phone Projection</p> <p>How to “push” contents to the projector</p> <p>① Note: Advantage of push is it does not affect normal use of the mobile phone, 1. Ensure the Phone and Projector are under the same WiFi. 2. Open video software of the mobile phone and finds the TV push icon in the four corners (it's usually on the top right or on the bottom right) (Each APPs have different push icon design). ② Note: Not all video software have function of push. ③ Click this icon to push videos to the projector. At the same time, we can have other operations on the phone, it will have no conflict.</p> <p>  </p> <p>Schematic diagram of some push icons</p>	File Type	File format supported	Picture	JPG, BMP, PNG, GIF	Video	H.265, H.264, VP9@60, MPEG1/2/4, VC-1, AVS/AVS+(Above based on 1080P@60fps or 30fps)	Audio	FLAC, APE, MP3, WAV, OGG	<p>Projection Distance Reference</p> <table border="1"> <thead> <tr> <th>Projection size (under status of no keystone correction) [inch]</th> <th>Screen length * width [in]</th> <th>Lens - screen [m]</th> </tr> </thead> <tbody> <tr> <td>45</td> <td>0.99 × 0.5</td> <td>1.2</td> </tr> <tr> <td>50</td> <td>1.11 × 0.62</td> <td>1.5</td> </tr> <tr> <td>60</td> <td>1.33 × 0.75</td> <td>1.6</td> </tr> <tr> <td>70</td> <td>1.55 × 0.87</td> <td>1.9</td> </tr> <tr> <td>80</td> <td>1.77 × 0.99</td> <td>2.1</td> </tr> <tr> <td>90</td> <td>1.99 × 1.12</td> <td>2.4</td> </tr> <tr> <td>100</td> <td>2.21 × 1.25</td> <td>3.7</td> </tr> <tr> <td>110</td> <td>2.43 × 1.37</td> <td>3.9</td> </tr> <tr> <td>120</td> <td>2.66 × 1.49</td> <td>3.3</td> </tr> <tr> <td>130</td> <td>2.88 × 1.62</td> <td>3.6</td> </tr> <tr> <td>140</td> <td>3.1 × 1.74</td> <td>3.8</td> </tr> <tr> <td>150</td> <td>3.32 × 1.87</td> <td>4.2</td> </tr> </tbody> </table> <p>Note: Projection size and distance are calculated according to projection ratio, which may have a deviation and subject to actual states.</p>	Projection size (under status of no keystone correction) [inch]	Screen length * width [in]	Lens - screen [m]	45	0.99 × 0.5	1.2	50	1.11 × 0.62	1.5	60	1.33 × 0.75	1.6	70	1.55 × 0.87	1.9	80	1.77 × 0.99	2.1	90	1.99 × 1.12	2.4	100	2.21 × 1.25	3.7	110	2.43 × 1.37	3.9	120	2.66 × 1.49	3.3	130	2.88 × 1.62	3.6	140	3.1 × 1.74	3.8	150	3.32 × 1.87	4.2	<p>Cleaning Method</p> <p>Please make sure the power plug is unplugged before cleaning. Do not use pesticides or other volatile chemicals on the projector or lens. Do not let rubber or vinyl products contacts the projector for a long time, which will damage the coating and make it peeled off.</p> <p>Clean the Projector</p> <p>① Clean with a soft, dry cotton cloth. If it's dirtied seriously, we can wipe with soft cloth that stuck with diluted neutral detergent, then dry with a clean and dry cloth. Please pay more attention if used with chemical fiber cloth. ② Don't use thinner, benzene or any other solvents to avoid quality reduction or coating peeling off etc. ③ Dust can be cleaned into the front of the vacuum cleaner to remove it inside the lens. Please don't use vacuum cleaner with no connector, or clean with vents directly. ④ Please don't scratch the machine with nails or any other hard objects so as to avoid scratches.</p> <p>Lens Cleaning</p> <p>① Clean lens with the same method for camera lens, please use professional blow dryer or cleaning paper for glasses, ensure lens are not scratched.</p> <p>Filter and Outlet Dust Cleaning</p> <p>① Dust in the inlet and outlet will prevent ventilation and increase the internal temperature, which will cause defect. ② Disconnect power line after turn off the projector. ③ Clean the exterior with an electric vacuum cleaner, please install brush head adapter on the vacuum cleaner first. Kindly take note: don't use vacuum cleaner with no connector or brush.</p> <p>Power Supply</p> <p>① Content of the hazardous substance in all homogeneous materials of the component is under the limits of SJ/T11363-2006. ② Content of the hazardous substance exceeds the limit requirements specified by SJ/T11363-2006 in at least one homogeneous material of the component. The components labeled “*” have no substance due to global technology development limits. Circuit board assembly*, including printed circuit board and its components, electronic components, etc.</p> <p> This number in the logo represents the normal environmental service life of the product. (Battery Excluded)</p> <p>FCC ID: 2A7PWP0D24</p>	<p>Poisonous and Harmful Substance, Element Name and Content</p> <table border="1"> <thead> <tr> <th rowspan="2">Part name</th> <th colspan="5">Hazardous substances</th> </tr> <tr> <th>Lead (Pb)</th> <th>Mercury (Hg)</th> <th>Cadmium (Cd)</th> <th>Hexavalent chromium (Cr6+)</th> <th>Polymerized bisphenol (BPA)</th> </tr> </thead> <tbody> <tr> <td>Shell</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Optical Machine</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Circuit Board</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Fan</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Other Wires</td> <td><input checked="" type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Remote Control</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <td>Power Supply</td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </tbody> </table> <p>Warranty Card</p> <ol style="list-style-type: none"> We offer “three guarantees” for this product. One year warranty for non-artificial damage since purchasing (subject to purchase record). We will provide warranty service for any defect caused by product technical reasons during warranty period. Following situations are out of the range of guarantee: ① Accessories out of the mainframe ② Unauthorized disassembly and repair without our consent. ③ Damage that caused by external force and other natural disasters. Please fill the card and contact your distributor when products have quality problem. This warranty is limited to product maintenance during the warranty period, no other liability <p>After-Sale Service Card</p> <p>Customer Name: _____ Purchase of Shop: _____ Customer ID: _____ Customer Tel: _____ Fault Description (Please describe in detail for quick maintenance): _____</p> <p> Certificate CC-05</p>	Part name	Hazardous substances					Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polymerized bisphenol (BPA)	Shell	<input type="checkbox"/>	Optical Machine	<input type="checkbox"/>	Circuit Board	<input type="checkbox"/>	Fan	<input type="checkbox"/>	Other Wires	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Remote Control	<input type="checkbox"/>	Power Supply	<input type="checkbox"/>	<p>wanbo WPD24</p> <p></p> <p>Wanbo Projector Introduction Manual</p> <p>Before using this product, please read this product manual carefully.</p> <p>Thank you for purchasing our products. For your safety and benefit, please read this product manual carefully before using. If you fail to take the product instructions or precautions, and cause any personal injury, property or other losses, the company will not bear any responsibility.</p>																								
File Type	File format supported																																																																																																								
Picture	JPG, BMP, PNG, GIF																																																																																																								
Video	H.265, H.264, VP9@60, MPEG1/2/4, VC-1, AVS/AVS+(Above based on 1080P@60fps or 30fps)																																																																																																								
Audio	FLAC, APE, MP3, WAV, OGG																																																																																																								
Projection size (under status of no keystone correction) [inch]	Screen length * width [in]	Lens - screen [m]																																																																																																							
45	0.99 × 0.5	1.2																																																																																																							
50	1.11 × 0.62	1.5																																																																																																							
60	1.33 × 0.75	1.6																																																																																																							
70	1.55 × 0.87	1.9																																																																																																							
80	1.77 × 0.99	2.1																																																																																																							
90	1.99 × 1.12	2.4																																																																																																							
100	2.21 × 1.25	3.7																																																																																																							
110	2.43 × 1.37	3.9																																																																																																							
120	2.66 × 1.49	3.3																																																																																																							
130	2.88 × 1.62	3.6																																																																																																							
140	3.1 × 1.74	3.8																																																																																																							
150	3.32 × 1.87	4.2																																																																																																							
Part name	Hazardous substances																																																																																																								
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polymerized bisphenol (BPA)																																																																																																				
Shell	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Optical Machine	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Circuit Board	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Fan	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Other Wires	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Remote Control	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				
Power Supply	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																				

Important Safety Precautions You are recommended to use the projector in a dark room to achieve the best effect. - ① Please don't install in places that directly blown by cold and warm air of air-conditioning, water condensation or high temperature may lead to failure of the machine. - ② Ensure adequate ventilation and vent are not blocked to prevent heat accumulation inside the machine. - ③ Please prevent foreign matters such as nails or paper scraps from falling into the machine. Do not insert any metals such as iron wire or screwdriver into the machine. Please turn off the power immediately and turn to professional technician to remove it if any foreign matters fall into the body. - ④ Do not place any liquid on this machine to avoid risk of electric leakage. - ⑤ Please use soft packaging materials to move the projector, keep the projector from violent vibration. - ⑥ Areas near the exhaust will become hot during and after we use the projector, it may lead to scald if we touch with hand. - ⑦ Please don't watch lens directly when it's on so as to protect our eyes from damage. **Note:** - ① Don't open the shell to prevent electric shock. Please turn to qualified professional maintenance personnel for the maintenance as there are no parts in the machine that users can repair themselves. - ② Don't expose the machine to rain or moisture so as to prevent mist or electric shock. - ③ The product is applicable to be used under a temperature of 0-35°C for a safe side.	**Important Safety Precautions** **Projector Part Name and Function** **Installation and Adjustment** 1. Device Power-On and Power-Off **Power-On** Method 1: Press the power button on the projector to start. Method 2: Hold the remote control to the projector and press “” to turn it on. **Power-Off** Short press the power button or the “” key on the remote control, once shutdown prompt box appears, short press the power button or the power key on the remote control again. 2. Adjusts Focal Length Focus Length: When the picture image is blurred (indicated as the right picture), adjust the lens focus through “” “” on the remote control to achieve the best definition.	**Projector hanger installation steps** ① The bracket is aligned with the screw hole ② Adjust hanger angle and then tighten screws ③ Install the lifting bracket **Basic Parameters**	Product Name	Wanbo Projector	Display Principle	LCD		----------------	------------------------	---------------------	----------		Light Source	LED	Horn	5W*2		Operation Mode	Remote Control	Working Environment	0-35°C		Output Port	Headphone/Audio Output	Input Port	HDMI/USB		Net Weight	1.9kg	Machine Size	145*	