

User Guidelines of Bluetooth Wi-Fi Bridge/Gateway

User Instruction

Please refer to the Blusafe Smart Lock user instruction manual for setup, or follow below steps.


1. Plug in the Wi-Fi Bridge/Gateway
2. Press the Setting/Resetting button until the red indication light flashes, then ensure your device is connected to Bluetooth and open the Blusafe Smart App
3. Add your Wi-Fi Gateway in the Blusafe Smart App by pressing the '+' in the top right corner, then input your Wi-Fi password and make sure your Wi-Fi Gateway is connected with the Blusafe Smart App
4. Make sure your Blusafe smart lock connects to your Blusafe App first, then bind your Wi-Fi Gateway with your Blusafe smart lock by clicking on the Gateway and selecting 'Add Device'
5. Once your smart lock is added, you will be able to control the lock outside of Bluetooth range

Package Contents

- Bluetooth Wi-Fi Bridge/Gateway
- Cable
- User Guidelines
- Adaptor

Package Contents

The Bluetooth Wi-Fi Bridge/Gateway allows you to connect your Blusafe smart devices to the Wi-Fi, allowing you to benefit from the smart functionality. When connected via the App, it allows users to add devices, reset devices, manage entry methods, control the device remotely and allows connection to smart home applications such as Amazon Alexa or Google Assistant.



PRODUCT SPECIFICATIONS

Product Name	Bluetooth Wi-Fi Bridge/Gateway
Product Model	01.W01.002.M
Power Input	5V == 1A
Operating Temperature	-10° - 55C
Humidity	10% - 99% RH
Wireless Protocol	2.4G Wi-Fi
	Bluetooth 5.0
Product Size	60 x 60 x 14 mm
Product Weight	30g

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.