


F176

Wireless Speaker


USE Manual



Thank you for buying F176 wireless Bluetooth speaker. F176 has simple design, there is chain-link fence cover on both sides, flannel covering the surface made the design more elegant. Before getting started, please read the user's manual carefully so as to ensure the proper operation and optimized performance of this product.

Safety information:

- Do not use the speakers near water, liquid or wet areas. Clean using a soft paper or towel.
- Do not cover or insert anything into the hole of speaker.
- Cut off the power before cleaning the speaker.
- Do not try to disassemble, repair or remould the product by yourself.
- Unplug this device when unused for long periods of time or during lightning storms.
- Do not turn up the volume to a high level constantly as this could shorten the lifetime of this device or impair your hearing.
- Do not expose your speaker to temperature above 45°C. Keep out of direct sunlight.



Operation:

- ① Short press to last track, long press for volume decrease.
- ② Long press to start Bluetooth, Audio input mode switch.
- ③ Short press to next track, long press for volume increase.
- ④ DC12V 2A Charging port.
- ⑤ AUX-IN jack.
- ⑥ USB audio file input.

Connection:

- 1 Connect adapter to power supply, the speaker power on and defaults Bluetooth mode, go to the Bluetooth Manager of your Bluetooth device, search Bluetooth devices and select "F176" to start connecting, after it goes with voice prompt.
- 2 Stereo audio input interface, easy to connect to computer, digital music player, mobile phone and other sound source equipment.
- 3 This speaker will automatically play the songs inside the U disk after a U disk inserting the USB interface.

Product specification:

- 1 Max power output: 10W*2
- 2 Channel system: 2.0
- 3 Bluetooth version: 4.1
- 4 Frequency response range: 100HZ-20KHZ
- 5 Signal to Noise Ratio(SINR): ≥85dB
- 6 Distortion factor: 5%
- 7 Size: 205mm*150mm*162mm
- 8 Weight: 60g

Accessories list:

- 1 Manual*1
- 2 Aux cable*1

FCC COMPLIANCE STATEMENT: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.