SEUIC Reference Manual

AUTOID Pad Air (WIN) Product Series

User's Manual of Products with Windows 10 System



Copyright Statement

All information contained in this Manual is provided based on "its original status". We may change the information without a prior notice.

Seuic neither makes any guarantee for the contents prescribed in this Manual by any means, including but not limited to implied marketability and application to specific purpose, nor holds liable for any error contained in this Manual or accident or random loss caused by supplying, executing or using this Manual or any example contained herein.

Software copyright © 2019 -2021 SEUIC Company

This Manual contains the ownership information protected by copyright. All rights reserved. It is forbidden to, without our prior written consent, photocopy, republish, recompose or translate any part of this Manual, unless otherwise specified in copyright law.

This Manual and the copyright of relevant application software are owned by Seuic Company and protected by the *Copyright Law of the People's Republic of China* and the *International Copyright Order*.

The brand and product name in this Manual are the name of commodity, service marks, trademark or registered trademark of their owners.

For more information about products and support, please feel free to contact our sales representative or login our website directly for query.

The appearance of products in the illustrations of this Manual may differ from your products.

Your computer may not be fitted with some optional accessories, functional parts and software program based on the specific models.

Some descriptions of user's interface may not apply to your computer depending on the version of operating system.

We may change the contents contained in this Manual at all times without a prior notice. SEUIC will keep improving relevant computer files.

Microsoft® changes the functions of Windows® operating system via Windows Update regularly. Therefore, some information in this Manual may have been no longer applicable. Please read Microsoft resources to know about the latest information.

Seuic Technologies Co., Ltd.

No. 15, Xinghuo Road, Jiangsu High-tech Industry Development Zone

Postal code: 210061

Tel.: 86-25-52261298 Fax: 86-25-52268995

Corporate official website: www.Seuic.com

Official website for products: www.ChinaAUTOID.com

Service hotline: 400-677-0876 Email: AUTOID@seuic.com

• File release record

Ver. No.	Modified contents	Modified	Modified by
		date	
V1.0	Initial version of English manual of Windows10	2020/07/06	Jiang Ming'an
V1.1	Modify upper and lower cases of cover models and	2020/09/25	Zhou Zhen
	enrich accessory information		
V1.2	Modify copyright statement	2022/4/27	
V1.3	Remove NFC	2022/8/2	Eric

Table of Contents

Chapter 1 Instructions for Use	1
1.1 Attentions for laser scanning engine	1
1.2 Safety attentions	1
1.3 Attentions for maintenance	1
Chapter 2 Appearance	3
Chapter 3 Keyboard	5
Chapter 4 Quick Use	6
4.1 First use	6
4.2 Startup	6
4.3 Shutdown	6
4.4 Restart	6
Chapter 5 Recharging	7
5.1 Recharging time	7
5.2 Recharging temperature	7
5.3 Battery power supply	7
5.4 Attentions for battery use	8
5.5 LED indicator lamp	8
Chapter 6 Use of Windows 10	9
6.1 Configuration of operating system prior to first use	9
6.2 Operating system interface	
6.3 Shutdown, restart or sleep mode of tablet	10
6.4 Operation of touch screen	10
6.5 Help and support	11
Chapter 7 System Recovery	12
7.1 Introduction	12
Chapter 8 Troubleshooting	13
Introduction to Optional Accessories	15



Chapter 1 Instructions for Use

1.1 Attentions for laser scanning engine

Caution Laser! LASER 2



Laser has radiation effect so users

cannot see laser beam directly.

1.2 Safety attentions

- ➤ Please ensure to use the battery and recharger designated by the Company only. The use of any unauthorized products may lead to battery fluid leakage, overheating, explosion and fire.
- ➤ It is forbidden to short circuit recharger; otherwise, problems such as electric shock, burning and recharger damage may occur.
- ➤ Please do not use recharger once power line is damaged. Otherwise, fire and electric shock may occur.
- ➤ Please do not dismantle or refit recharger; otherwise, personal injury, electric shock, fire and recharger damage may occur.
- ➤ Hold the recharger while pulling out of plug, as pulling power line directly may lead to line damage and even electric shock and fire.
- Clean the equipment, battery and recharger using a soft dry cloth.
- ➤ Please do not wipe the equipment using such solutions as alcohol, diluents or benzene.


1.3 Attentions for maintenance

Do not operate this product under an environment with extremely high or low temperature or a damp environment, although it is dustproof and waterproof. Please

- refer to the temperature and humidity standard corresponding to product specification.
- Pressing the screen with too much force may lead to screen damage. Please do not click the screen using resistive screen touch screen to avoid bruising or damaging it. Clean the screen using soft cloth applied with a small quantity of LCD cleaning agent. Avoid spraying cleaning agent on the screen directly.
- Please avoid wiping the screen using any chemical cleaning agent.
- **\rightarrow** Keep the scanning window clean and tidy and do not touch it with any sharp object.
- Please remember to download the data to computer for storage, if this product will not be used for a long period of time.
- When using this product for the first time or reusing it after a long time of storage, it may cost a long time to finish recharging the battery.
- ➤ If this product becomes faulty, please write down the problems and then contact with repairman.



Chapter 2 Appearance



1	Recharging indicator lamp
2	Scanning indicator lamp
3	Front-facing camera
4	Light Sensor
5	Main microphone
6	Display screen

Fig. 2-1 Front View

3





Fig. 2-2 Side View



1	Rear camera
2	Secondary microphone
3	Flashlight

Fig. 2-3 Back View



Chapter 3 Keyboard

<u>Pad Air</u> device has two keys in total designated at its sides (power key and volume key).

Key instructions:

Table 3-1 Key Instructions

Keys	Main Functions	Function Details
0	Power supply	Short press the key under standby status to enable sleep/awakening mode of this product. Long press for 3S under "off" status to start this product
	Volume key	Press the upper part of for volume up and the

5

Chapter 4 Quick Use

4.1 First use

➤ Long press the power key for 3S to start up this product. Short press power key under working status and this product will enter sleep mode. Short press power key under sleep mode and this product will be awakened and the screen will be on in a few seconds.

4.2 Startup

Start this product by power key. Short press power key under deep sleep mode to awaken the system. If battery is used for power supply, ensure the battery has been under reliable contact.

4.3 Shutdown

After this product is started up, under non-sleep mode, click the "start" icon at the right lower part->Click "power" icon-> Click "shutdown" icon to shut down this product normally.

4.4 Restart

After this product is started up, under non-sleep mode, click the "start" icon at the right lower part->Click "power" icon-> Click "restart" icon to restart this product normally.

Chapter 5 Recharging

The battery power can support test only prior to delivery so please remember to recharge this product upon receiving it.

5.1 Recharging time

- ➤ Battery: Battery recharging for the first time via adapter and Type-C wire may cost about 3.5 hrs: Connect this product to the power socket via accompanying Type-C data cable and power adapter.
- ➤ When recharging this product after shutdown, the recharging indicator lamp will turn red, indicating this product is being recharged. It means recharging has finished, if the indicator lamp is off.
- When recharging this product after startup, the recharging indicator lamp will turn red, indicating this product is being recharged. It means recharging has finished, if the indicator lamp turns green.

5.2 Recharging temperature

- ➤ Optimal operating temperature: Room temperature 18~25 °C.
- \triangleright Battery recharging will fail, if the temperature is lower than 0°C or higher than 55°C.

5.3 Battery power supply

- ➤ The battery power will be consumed significantly, once enabling wireless network service or data acquisition program. Please disable these functions when they are not necessary in order to save power.
- > Tips: Please recharge this product for every two months at least, if this product is

not used for a long time.

> Tips: Please recharge this product with standard adapter and USB cable.

5.4 Attentions for battery use

- ➤ If the battery power is used up, this product may not be started up immediately when it is just connected with recharger, which is quite normal. Please do not start up this product until it is recharged for a certain period of time.
- The battery, which can be recharged repetitively, belongs to consumables. Please replace the battery whose standby time is reduced significantly with a new one.
- > The battery recharging time may vary along with temperature and battery use conditions so please recharge it within a reasonable scope of temperature.
- ➤ This product will give out low-power prompt when the battery power is low. This product will shut down or enter sleep mode automatically when the battery power is too low.

5.5 LED indicator lamp

- The LED indicator lamp in the middle part at the left upper side of this product shows the status of battery power and recharging status via different colors:
 - ♦ If the indicator lamp is in red after inserting USB, recharging adapter and charge connector, it means the battery is being recharged;
 - ❖ If the indicator lamp is in green under "on" status after inserting USB, recharging adapter and charge connector, it means the battery has been fully recharged. If the indicator lamp is off under "off" status, it means the battery has been fully recharged.

Chapter 6 Use of Windows 10


6.1 Configuration of operating system prior to first use

You need to configure the operating system before using this product for the first time. The following steps may be used for configuration

- Accept final user's license agreement
- Configure network connection
- Register operating system
- > Create user's account

6.2 Operating system interface

Windows 10 supports both desktop mode and tablet mode. Click "unfold" after clicking via "notice" icon at the right lower angle of the screen. Switch mode.



6.3 Shutdown, restart or sleep mode of tablet

You can shut down, restart the tablet or make it enter sleep mode after finishing using it.

- Make it enter sleep mode
- ➤ Click → to choose "sleep" mode
- Press power key to awaken the tablet.

Remarks: Please awaken it in several seconds, if this product just enters sleep mode.

- > Shut down the tablet
- > Click to shut down this product
- > Restart the tablet
- ➤ Click → to restart this product

6.4 Operation of touch screen

- ➤ Short press the screen. (it is equivalent to the left key of mouse)
- ➤ Long press the screen. (it is equivalent to the right key of mouse)

6.5 Help and support

- > For any problems that you encounter while operating this product, please feel free to contact our relevant staff
- For any doubts about this system, please refer to Microsoft's Windows 10 help files.

 Website: https://support.microsoft.com/

11



Chapter 7 System recovery

7.1 Introduction

Resetting and recovery are one set of recovery tool inside the Windows system so that users could retain the original data or important information while recovering the operating system to the initial status. Users could also restore factory settings for the system with the functions above.



➤ Then operate according to the prompt.

Remarks: You're suggested to consult Microsoft's help files prior to operation

Chapter 8 Troubleshooting

Problems	Cause	Solutions	
Pad Air does not start after pressing the power	The battery power is too low or this product is not recharged	Recharge this product	
key	Short press	Long press for 3 S	
Rechargeable battery	Battery becomes faulty	Send the battery back to the plant for repairing or replacement	
cannot be recharged	Battery temperature is too high/low	Bring battery under a room temperature environment	
No sound Volume is set too low or has been off		Adjust volume	
Pad Air shuts down automatically	Pad Air is under inactive status	Setting->system->Power& sleep, you can choosing the times for screen and sleep setting.	
	Battery power is used up	Recharge this product	
	Failure to start scanning tool program	Load scanning application program in Paid Air	
	Under bar code setting or application setting interface	Set scanning program to scanning interface or hide scanning program	
Decoding failure when	Bar code is not readable	Ensure the bar code is free of fault	
Pad Air reads bar code	Failure to enable bar code decoding function	Enable the corresponding encoding under bar code setting	
	Pad Air does not support the decoding of such bar code type		
	The distance between Pad Air and bar code is improper.	Set Pad Air within correct scanning scope.	
Failure to find any Bluetooth device nearby	The distance from other Bluetooth device is too faraway	Move this product closer to other Bluetooth device (within 10 m (32.8 feet).	

Seuic 东集 ——————

	The Bluetooth nearby is not	Start the Bluetooth device	
started		to be searched	
	Bluetooth device is not under	Set Bluetooth device under	
	discoverable mode	discoverable mode	
Esilvas to some set AD	Display "authentication	WLAN password is	
Failure to connect AP	problems"	incorrect	

Introduction to Optional Accessories

Please retain the original packaging box and materials for future product repairing or storage. You can purchase the following optional accessories that could help improve your working efficiency.

- ▶ One set of Pad Air product
- ▶ One PD adapter (used together with USB Type-C interface USB cable to realize PD fast recharging)
- ► One USB Type-C interface USD cable (used together with PD adapter to realize PD fast recharging)
 - ▶ Silicone bracket
 - ▶ Protective sleeve
 - ► Multifunctional base
 - ► Tempered glass screen protector

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

The SAR limit adopted by FCC is 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported to the FCC for this device type complies with this limit. The highest SAR value reported to the FCC for this device type when using in portable exposure conditions is 1.19W/kg.