

ARCCOS

SMART LASER

QUICK START GUIDE

Table of Contents

- 04** Rangefinder Diagram
- 06** OLED Display
- 08** Measurement Modes
- 11** Unit of Measure
- 12** Slope Function
- 13** How to Use/Pairing Smart Laser
- 15** Starting a Round
- 16** During a Round
- 20** After a Round
- 21** Warnings



03

Rangefinder Diagram



- A** Eye Piece
- B** Diopter Adjustment
- C** Power Button
- D** Settings/Mode Button
- E** Slope Switch
- F** Battery Cover



OLED Display



*Device vibrates when locking onto nearer objects, e.g. flag sticks

**Displays only when device is in Slope Mode


- A** Aiming Circle
- B** Laser Indicator Crosshair
- C** Actual Icon
- D** Actual Distance
- E** Unit of Measurement
- F** Flag Lock Mode*
- G** Scan Mode
- H** Bluetooth Icon
- I** Battery Indicator
- J** Plays Icon**
- K** Arccos Plays Like Distance**
- L** Launch Arccos App Icon
- M** Gusts Icon
- N** Gusts Distance

Measurement Modes



NORMAL MODE

Normal Mode is recommended when measuring distances to larger objects



FLAG LOCK MODE (FLM)

Flag Lock Mode is best used when measuring a Flag Stick or smaller objects. The device will provide a short vibration to confirm that the laser has locked onto the pin. To toggle between the different modes, hit the Settings/Mode Button once while the device is powered on. When FLM is activated, the flagstick icon will appear on the left side of the display.




SCANNING MODE

Scanning Mode - To measure distances to multiple targets in succession. When in Normal Mode, Press and Release the Power Button to power on. Then HOLD the Power Button. The Laser Indicating Crosshairs will flash and the laser will continuously fire. Measurements will change as you scan the landscape and change targets. Scan Mode is indicated by the Target Icon on the left side of the device. The Target Icon will only display when the Power button is held down and the laser is continuously firing.


Unit of Measure

To change the unit of measure from Yards to Meters, start with the device powered on. Then HOLD the Settings/Mode button for 3 seconds. The unit of measure is indicated by a “Y” or “M” shown directly to the right of the displayed distance.

Slope Function



When No Color is showing: Slope Function is Off. The laser is tournament legal when the slope is turned off.



When Green is showing: Slope Function is Enabled. Plays Like adjusted yardage will be displayed after every time the laser is fired. The Laser is not tournament legal when the Slope Function is enabled.

How to Use the Arccos Smart Laser

- While looking through the Eye Piece, Press & Release the Power Button. The Rangefinder is now powered on.
- To focus or increase the clarity, use the Diopter Adjustment by turning the Eye Piece.
- Continue looking through the Eye Piece, aim the Aiming Circle at your intended target and Press the Power Button. The laser will fire and the Laser Indicator Crosshair will appear around the Aiming Circle. The measurement will be displayed at the top of the OLED display.

Pairing Your Arccos Smart Laser

- Activate Bluetooth on your phone and open the Arccos app.
- Connect Arccos Smart Laser if prompted in the app.
- If not prompted, on the 'Start Round' screen of the app, tap 'Pair Arccos Smart Laser' under the device section.
- Follow On Screen Next Steps until Successfully connected

Note: Pairing will not happen in the phone's Bluetooth settings

Starting a Round

- On the 'Start Round' screen, select your course, shot detection mode, and ensure under the 'Devices' section, Smart Laser is selected.
- Once you've filled out the appropriate Round Settings, select 'Start Round'
- Wait for your Smart Laser to successfully sync and for the round to begin.

During a Round

- PIN MARKING INFO....
- PLAYS LIKE INFO.....
- GUSTS INFO....
- INFO REGARDING APP CONTROLLED SETTINGS (M/Y, GUSTS, PLD, etc.)

During A Round

- To end your round, end the round in the Arccos app.
- Wait until your Arccos Smart Laser has completed the syncing process.
- Place your Arccos Smart Laser back into its case so it'll be ready for your next round.

Operational Notes

- Maximum measurement range: 999 YDS or 999 M
- Auto Shutoff - To conserve battery life, the device will automatically power off when idle for more than 20 seconds
- Weather Conditions - Heavy Rain and thick fog can potentially limit the maximum range of the device.
Weather Resistant - Protected against light rain
- Storing the Laser - Do not leave the eyepiece in direct sunlight, the condenser effect of the lens may damage the internal display surface.

Operational Notes

- To clean, use only a soft, clean cloth to prevent scratches.
- Do not submerge in liquid or any other cleaning products.
- Do not store the laser rangefinder in extreme cold/hot temperatures (<50°F - >110°F).
- Store in the provided carrying case when not in use.

Troubleshooting

Rangefinder is consistently providing inaccurate measurements.

- Make sure the device is set to the desired unit of measure (Yards or Meters)
- Weak battery signal can affect the accuracy of the device. If the Battery Indictor is displayed on the OLED display, replace the battery.
- Make sure there isn't anything obstructing your view such as your fingers, leaves, branches, etc.

Troubleshooting

When looking through the Eye Piece, the view is blurry.

- Use the Diopter Adjustment by turning the Eye Piece to focus/increase clarity.
- Make sure there isn't anything obstructing your view such as your fingers, leaves, branches, etc. Use a soft, clean cloth to clean lens.

What type of battery does the laser rangefinder use?

- CR2 3-Volt Lithium Battery.

Troubleshooting

When should the battery be replaced?

- If the Battery Indicator is on the OLED display.
- If the rangefinder is consistently providing inaccurate measurements.
- If the OLED display is not present when pressing the Power Button

When should Flag Lock Mode (FLM) be used?

- When measuring the distance to smaller targets such as a flagstick.

Warning

- NEVER look directly into the sun or intense light when using the laser rangefinder.
- DO NOT aim/point laser rangefinder at another person
- DO NOT aim/point laser rangefinder at anyone's eyes or face.
- DO NOT attempt to disassemble the laser rangefinder.
- DO NOT submerge in any liquid
- DO NOT store the laser rangefinder in extreme cold/hot temperatures (<50°F - >110°F).

Need Help?

Contact our Customer Experience team
anytime for assistance.

Phone: 1-844-692-7226

Email: starter@arccosgolf.com

Website: www.arccosgolf.com

Support: support.arccosgolf.com

Address: 700 Canal St, Stamford, CT 06902

FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic

Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This device complies with Canadian ICES-003 and RSS-247.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

IC RADIATION EXPOSURE STATEMENT

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

AVERTISSEMENT IC

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) ce dispositif ne peut pas causer d'interférence.

(2) ce dispositif doit accepter toute interférence, y compris l'interférence qui peut causer un fonctionnement indésirable du dispositif.

Selon la réglementation d'Industrie Canada, cet émetteur radio ne peut fonctionner qu'en utilisant une antenne type et gain maximum (ou inférieur) approuvés pour Industrie Canada par l'émetteur. Réduire brouillage radioélectrique potentiel avec d'autres utilisateurs, le type d'antenne et son gain doivent être choisis que la puissance isotrope rayonnée équivalente (e.i.r.p.) n'est pas supérieure à celle nécessaire pour communication réussie. Cet appareil est conforme aux normes canadiennes ICES-003 et RSS-247.

Exposition aux radiations: Cet équipement est conforme à la réglementation canadienne sur les radiations. limites d'exposition établies pour un environnement non contrôlé.

DÉCLARATION D'EXPOSITION AUX RADIATIONS IC

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables..



www.arccosgolf.com

SMART LASER
CLASS 1 LASER PRODUCT

ARCCOS GOLF LLC | arccosgolf.com

FCC ID:2ACQZ-ARCCOS IC ID:12164A-ARCCOS

FC **UK** **CA** **CE**  MADE IN
CHINA