



O' XON BS1 QUICK START GUIDE

PACKAGE CONTENTS




- Speaker
- USB Cable
- 3.5mm Stereo (Wired Audio)
- Quick Start Guide

FUNCTION




3.5mm Audio Input / Power Input (Micro USB Port) / Power Button / LED
Volume Down (Previous) / Volume UP (Next) / NFC / Play/Pause/Talk/Pairing Button

BATTERY CHARGING



- Plug BS1 into your wall charger or computer via micro USB cable.
- Full charge takes 3 hours. The LED will turn off when fully charged.

BLUETOOTH



- When turned on for the first time, BS1 will automatically enter pairing mode.
- Press it to connect your phone with the wireless speaker, you will find the <BS1> character on the menu of your smart phone.
- To enter pairing mode thereafter, press down this button to enable the bluetooth.

*It needs around 20 seconds when connecting the bluetooth in the first time.

SPECIFICATIONS

| | |
|---------------------|------------------------|
| Speaker Power | 2W x 2 |
| Speaker Size | 40mm x 2 |
| Frequency | 160Hz-15kHz |
| SNR | ≥80dB |
| Audio Input | Bluetooth, 3.5mm Audio |
| Power Input | Micro USB |
| Built-in Microphone | Yes |
| Battery Capacity | 1000mAh |
| Working Hours | 10h |
| Dimensions | 177x56x58mm |
| Material | ABS |
| Net Weight | 360g |

SAFETY INFORMATION

© 2018. ALL RIGHTS RESERVED.

REV 1406

CE DECLARATION

We Beijing Natural Smart-Tech Co., Ltd. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EU.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try correct the interference by one or more of the receiving measures:

Reorient or replace relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING:

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless user could lose the authority to operate this equipment if an unauthorized change or modification is made.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.