

PACKAGE CONTAINS:

1 Ecofit Tracker | 1 Equipment ID Decal | 1 User Manual | 1 Tracker Mounting Kit

Notice

No not expose to water or moisture. Do not expose to heat from any source. The Tracker is designed for reliable operation at normal ambient room temperature.

This product contains a Li-metal battery. These batteries should not be put in municipal waste system. Contact your local waste management agency for proper recycling and disposal information in your area.

Optimal Tracker mounting orientation is VERTICAL. This ensures maximum antenna range.

FCC ID: 2ADCN-TRK100

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept ant interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

It is recommended that the unit is positioned so that the typical distance from the antenna to the end user is 20cm or greater.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USERS AUTHORITY TO OPERATE THE EQUIPMENT.



US Pat 9,844,032; 9,147,343 Exercise Usage Monitoring System



Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

General Usage:

The Tracker is intended to be installed on either cardio or strength fitness equipment. The device tracks equipment usage based one either a physical connection to a compatible CSAFE port (additional cable required) or via movement using accelerometer data.

Configuration of this device requires access to an Android or iPhone smart phone and the use of the Ecofit Installation App. The app can be obtained at <https://www.ecofitnetworks.com/getapp>.

A user account is required to perform any installation actions. Once an account has been created contact Ecofit Support to gain access to the location.

Remove battery slip before use.

CSAFE Installation:

Using the CSAFE cable connect the Tracker to the compatible RJ45 CSAFE port on the equipment. This port is usually located on the back console of the equipment.

Movement Mode:

Mount the Tracker on a part of the equipment that experiences uniform movement during general usage. Follow the registration and test processes in the Ecofit Installation App to ensure proper configuration.

NOTE: Exact installation procedures will vary slightly between equipment types. For in depth instructions please visit the Ecofit Help Center at:

<https://myecofit.zendesk.com/hc/en-us>