

70x100mm

80g书纸, 正反面单黑印刷, 2折页



Note: The speaker will remain in pairing mode for 1 minute. To place the unit in pairing mode again, simply turn the speaker off and then on again using the switch on the back of the unit.

Pairing a Bluetooth Device with Your Speaker:
Your wireless speaker can stream audio from any Bluetooth-enabled device within 10m (33 feet).
Simply follow the steps below:
1. Turn the speaker on to place it in Pairing Mode.
2. Set your phone, tablet or other device to search for Bluetooth devices (i.e., the speaker).
3. When the speaker is found (clip tunes speaker), select it from the list.
4. When the pairing process is complete, the LED will light a steady blue.

Taking Calls on Your Speaker When Connected to a Phone:
1. Press **■** to pick up the call.
2. During a call: Press **■** again to hang up the call.
3. You can also answer/end calls by using your phone as you would normally.
Note: If you are listening to music from your phone, the music will automatically pause.

Controlling Music Playback When Connected via Bluetooth:
Once your Bluetooth audio source is successfully paired to your Bluetooth Speaker, any music played will automatically be heard through your speaker.
1. Press **■** to play/pause the audio.
2. Press and hold the **—** button to lower the volume level of the unit.
Tap this button to go to the last track in a playlist.
3. Press and hold the **+** button to raise the volume level of the unit.
Tap this button to go to the next track in a playlist.

Specifications
Speaker: 3W*1
Size: 75*36*118 mm
Sensitivity: 86dB
Frequency: 100-20KHZ
Power input: 5V, 400mA
Bluetooth Range: 10m (33 feet)

Sakar Warranty
This warranty covers for the original consumer purchaser only and is not transferable. Products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship will be repaired at no charge for parts or labor for a period of one year from the time of purchase.

What Is Not Covered By Warranty:
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

If What Do When Service Is Required:
When returning your defective product (postage pre-paid) for service, your package should include:
1. Copy of original bill of sale.
2. A detailed written description of the problem.
3. Your return address and telephone number (Daytime).
MAIL TO ADDRESS BELOW:

Sakar US Sakar International Attention: Service Department 195 Carter Drive Edison, NJ 08817	Sakar UK/Europe Attention: Service Department 2D, Siskin Parkway East 4020 Middlemarch Business Park Coventry, CV3 4SU	Sakar Australia Return faulty device to the Refund Counter at the store where purchased
--	---	---

Technical Support
For technical support issues please visit our website at www.vivitar.com. You can find manuals, software and FAQ's at the website. Can't find what you are looking for? E-mail us at support@vivitar.com and one of our technical support team members will answer your questions. For phone support in the US please call 1-800-592-9541, in the UK call 0800 917 4831, in Australia call 1800-006-614. If you would like to call from anywhere else, please visit www.vivitar.com for your local toll free number.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.