

GPK-200PK

Party Speaker User Manual



Read the user manual carefully before connecting or starting up the equipment.

Security instructions

1. Please read these instructions carefully before turning on this speaker.
2. Only use the electrical transformer that comes with the product, if it is not included, use the electrical transformer indicated in this manual. Using an unspecified power source will invalidate your warranty and may

damage the product reversibly. Unplug your speaker from the electrical source in case of electrical storms. Always verify that the speaker has been turned off before unplugging the wall plug.

3. To avoid acoustic damage, do not listen at very high volumes for long periods of time.

Always keep the volume at moderate levels.

This manual will help you prepare this product so that you can enjoy a unique listening experience.

Features

Wireless Bluetooth-range 10m

Voice prompts announcing functions

1*6.5"+1.5"party speaker

FM radio

LED display

3.5mm Aux input

6.35mm Microphone input

USB port - Supports MP3 format


TF card

Built-in rechargeable 7.4V 5400mAh battery

Includes

- . User Manual
- . Charging cable

Control Panel



1. Mode (Change Bluetooth \FM Radio \SD card \AUX in\USB mode)
2. Play previous song / FM Station
3. LED mode
4. Vol / MENU(adjust the bass, treble level, microphone volume, Echo)
5. Play/Pause function
6. Next song / FM Station
7. Power on \ off

Function Description

1. Speaker Charge

Charge speaker for built in battery. Connect one end of the charging cable to the machine and the other end to the charger (not included), The charging light will be red, and will turn off when fully charged.

2. Bluetooth function

- Power on the product then press MODE button to enter into BT mode.
- Open mobile devices (Cell phones, computers, etc.) in BT mode, search for BT devices, when it appears the item pairing name (LS921).
- After the device has been paired successfully for the first time, it will connect automatically around 10 seconds to the devices which connected before when next time. (Note: Each product could connect to one Bluetooth device only.).

3. TWS Function

Power on two speakers and enter Bluetooth mode.

Turn off the Bluetooth function on your phone or other Bluetooth device. Long press the Play/Pause button of either speaker, A different beep will then be heard to signify that the two speakers have connected via Bluetooth.

Open Bluetooth on the mobile phone and search “LS921” and connect. A beep will then be heard signifying that the mobile has connected to the speakers. You can now enjoy music from the two speakers.

4. USB mode

1. Insert a USB drive, USB mode will start automatically.
2. Song must be in MP3 format for the speaker to recognize the song.
3. Press the PLAY/PAUSE button to play or pause the music.

5. Auxiliary input mode

1. Connect a 3.5 mm audio cable to the unit's auxiliary input.
2. Press MODE to switch to auxiliary input mode.
3. Use the controls of the connected device to select and play the audio.

6. TF card mode

1. Insert an SD card, SD card mode will start automatically.
2. Song must be in MP3 format for the speaker to recognize the song.
3. Press the PLAY/PAUSE button to play or pause the music.

7. FM radio

1. Press Mode on the speaker to switch to FM mode.
2. Short press PLAY/PAUSE to enter automatic search for FM channels .
3. Press the NEXT button to go to the next channel.
4. Press PREVIOUS to return to the previous channel.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including

interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 0cm from nearby persons.