

2 IN 1 2.4G DOUBLE DRIVE STUNT CAR

EN







Car: 4 X 1.5V AA batteries (not included)


Controller: 3 X 1.5V AAA batteries (not included)


How to chance the tires:

Use screwdriver(pls ask adult for help)to unscrew the below position(arrow)for interchange between wheels and crawler track



Figure 1





CONTENTS








How to connect the car and controller?

Switch on the controller, you will see the red light flashing, then turn on the switch on the car, you will see the red light on controller off, which means that the car and the controller are successfully connected, if the red light on the controller still flashes, it means the connection failed, please turn off the switch and try again.





NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.