

420x280mm-正面

420x280mm-背面



Thank you for selecting Globe as your lighting choice for your home. With proper care, this product will provide years of pleasure and enjoyment. Carefully follow the instructions in order to ensure that this product functions safely and properly for years to come.

PORTABLE LED WORK LIGHT



SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS

CAUTION: Read and understand all Safety and Operating instructions in this manual before attempting to use this product.

Since 1932, Globe has taken pride in offering products of the highest quality and a level of service unparalleled in the industry. Should you encounter any difficulties, have any questions or simply wish to offer us your valuable feedback, you may contact us in the following ways:
Toll Free Telephone: 1-800-361-6761 (North America Only) / Toll Free Fax: 1-800-668-6542 (North America Only)
E-Mail: info@globeelectric.com / Mail: Globe Electric Customer Service Department
150 Dorenda, Montreal, Quebec, Canada H3H 1A2
Please visit our website to discover other quality Globe products: <http://www.globeelectric.com>


SAFETY PRECAUTIONS

- Do not use the work light in the immediate vicinity of inflammable materials or gases.
- Only use accessories included with this product.
- Do not point the light directly in your own or any other person's or animal's eyes.
- If the supply cord is damaged, it must be replaced by a cord with identical specifications to avoid a hazard.
- Keep minimum 20 inches(51cm) minimum away from other light fixtures.
- Keep the lamp out of reach of children.



HOW TO USE THE WORK LIGHT

TECHNICAL DATA

- | | | |
|---|--|---|
| 1. Model: 66208 | 5. Durable body: Aluminum + Polycarbonate construction | 9. Operation Time: Worklight only: 2 to 4 hours |
| 2. Integrated Bluetooth Speaker | 6. Weather Resistant - IP54 | Worklight and Speaker: 1.5 to 3 hours |
| 3. Ultra-high powered LED: 1500 lumens / 30W / 6000K / 30,000 hours | 7. 5V 2A USB output port | Speaker only: up to 8 hours |
| 4. 2 Brightness Levels: 1500 lumens (high) / 750 lumens (low) | 8. Battery: 7.4V 4000mAh Li-Ion | 10. Charging Time: Approx 6 hours |
| | | 11. 6' AC adapter / 5.5' car adapter |



- A - 2A USB output socket (to charge mobile device)
- B - DC IN/OUT (to charge the battery)
- C - Battery indicator light
- D - ON/OFF Switch
- E - 50%/100% Brightness Switch
- F - Bluetooth® Pairing Switch
- G - Speaker



PORTABLE LED WORK LIGHT
66208

page 2/4


HOW TO CONNECT AND PAIR THE BLUETOOTH® SPEAKER

1. Turn ON the Bluetooth Switch
2. Set your mobile Bluetooth device to "discovery" mode.
3. From the Bluetooth device list, select the device called "LED Lamp"

NOTE

Pairing occurs when two Bluetooth devices communicate with each other and establish a connection. A record of information about this connection is then stored in the memory of each device. Once you pair a device with the work light's speaker, you should not have to pair it again.

HOW TO CHARGE THE BATTERY



- Plug in the included AC/DC wall adapter or car adapter.
- Indicator light: Flashing green lights - charging; Solid green lights - fully charged.

CARE AND MAINTENANCE

- CLEANING:**
 - Before cleaning the LED work light, disconnect the power cable and allow the work light to cool down sufficiently. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.
- MAINTENANCE:**
 - Check the plug, power cable, and housing of the LED work light for damage before each use. If the lens is damaged it must be replaced immediately.
 - Clean any dirt from the housing or the lens immediately, since it could cause overheating.
 - Charge the battery every 3 months to preserve battery lifetime.

PORTABLE LED WORK LIGHT
66208

page 3/4

This device complies with Part 15 of the FCC Rules / Industry Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'attention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotropique rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication réussie.

WE'RE HERE TO HELP.
FOR ASSISTANCE BEFORE RETURNING TO YOUR RETAILER, CALL 1-800-361-6761.
HOURS: 9 A.M.-5 P.M., EST, MONDAY- FRIDAY.

Printed in China

PORTABLE LED WORK LIGHT
66208

page 4/4