



Product Name:HP Deathly Hallow Speaker

Model Name:4334362,5488310

Brand Name:Pottery Barn Teen



HARRY POTTER characters, names and related indicia are © & ™ Warner Bros. Entertainment Inc. WB SHIELD, © & ™ WBEI. WIZARDING WORLD trademark and logo © & ™ Warner Bros. Entertainment Inc. Publishing Rights © JKR. (s18)


Manufacture :Shen Zhen Hao Jie Xin Plastic Hardware Co Ltd

Harry Potter™ Deathly Hallow Bluetooth® Speaker User Manual


Please read this manual carefully before operating the device and save it for further reference.

Thank you for purchasing the Harry Potter™ Deathly Hallows Bluetooth Speaker. This manual will help you operate the speaker. Please familiarize yourself first with the Bluetooth functionality of the device you wish to connect.

Package Content



Audio Cable



USB Charging Cable

General Functions	
	"OFF/ON": Switch the button to turn the power on and off.
	"DC IN" (charging port): Insert the micro USB end of the charging cable into this port and connect the USB end to power supply to charge the battery.
	"AUX" (audio cable output port): Insert the audio cable into this port to play music through a non-Bluetooth device.
	Indicator light: Blue or red light indicates operation status. (See "SPECIFICATIONS" below for more details.)
	Play/pause: answer call/hang up call button. Press to play or pause music. If there is an incoming call on the connected device, press to answer and press again to hang up.
	Microphone: This is the sound receiver when answering a call.

Charging

- This speaker contains a built-in rechargeable battery. Before the first use, please fully charge the speaker to ensure optimal performance and battery life.
- Connect the charging cable to any powered USB port (output 5V 500mA). Make sure it is fully plugged in.
- Charging time: at least 4 hours. The indicator light will automatically turn red while charging and turn off when fully charged.

Note: Operating the speaker while charging may affect the battery life.

Pairing

- The speaker must be paired with a Bluetooth output device before it can operate.
 - Manual pairing is only necessary once per device. After the first time, the device will connect automatically.
- Turn on the Bluetooth function on the device that you wish to pair (i.e. smartphone or other compatible device). Some devices may require selecting "Search for Devices" or "Add New Device" in order to create a Bluetooth pairing. If so, initiate a manual search.
 - Select "HP Deathly Hallows Speaker" once it appears on your device screen. Once a connection is established and the pairing is complete, the indicator light will turn blue and you will hear an ascending tone.
 - The speaker is now ready to play music. Press the **▶/⏸** button to play or pause music.

* It is advised to turn the volume on your device all the way down before connecting, then gradually increase the volume until a comfortable listening level is reached.

* If the speaker does not pair with any device after 3 minutes, it will turn off automatically to save power.

Status	Light
Device has been turned on and is searching	Quick blue light flashes
Connection Success	Slow blue light flashes
Low voltage	Red light flashes
Charge Mode	Red light turns on while charging, and off when charging is completed

SPECIFICATIONS:

Bluetooth Version	4.1
Bluetooth Profiles Supported	A2DP, AVRCP
Driver	32mm dynamic driver
Frequency Response	20Hz to 20kHz
Operation Range	10M (30ft)

SAFETY AND CARE

- When the speaker is not in use, turn it off and store in a cool and dry place. Battery performance will be severely decreased if stored in extreme temperatures, including in direct sunlight.
- Clean with a soft and dry (or slightly damp) cloth. Avoid any liquid leaking into the seams of the device. Never use any kind of chemical cleaner.
- Do not attempt to repair or disassemble any part to avoid permanent damage.
- Do not place on any wet surface. Do not use near water.
- Do not drop the speaker on any hard surface. This may damage the product.
- Press the function buttons gently. Pressing hard could shorten the lifetime of the buttons.
- Do not place the speaker near a TV, speakers, wireless telephones or other objects that generate strong magnetic fields.
- If the device comes in contact with any liquids, wipe away as quick as possible. If submerged in water, do not turn the device on until 100% dry.
- Do not use around flammable gases, as fire or explosion may occur.

WARNING

- * Using the speaker at high-volume levels for long periods of time may result in permanent hearing damage. Please keep volume levels moderate to low at all times for your health.
- * Do not use while driving a car, cycling, operating machinery or performing other activities that require hearing surrounding sounds.

TROUBLESHOOTING:

Q: *I cannot pair the speaker successfully.*

A: Check that the speaker is on and within 10 meters of the music device, without any obstacles in between.

A: Check if there are other Bluetooth receivers nearby, then turn off unnecessary devices to avoid interference and try pairing again.

Q: *Why does the speaker not work even though the power is on?*

A: Check the indicator light color – if it is flashing red, the speaker needs to be charged before it can be used.

A: Ensure the battery is charged for at least 4 hours before using for the first time. The LED will turn red when the speaker starts charging.

Q: *The sound is too low or distorted.*

A: Check the volume setting on your music device and adjust to a suitable sound level.

A: The battery may be low; please charge the device.

Q: *The speaker cannot play music properly.*

A: Check that the distance between the speaker and music device is under 10 meters and that obstacles are not blocking the communication between them.

FCC STATEMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CAN ICES-3 (B). FCC ID : 2A188PBTHPSPK18

Product Made in China for Pottery Barn Teen



Thank you for your purchase.

www.pbteen.com