


Light Cam

User Guide

Table of Contents

- 01 What's in the box
- 02 Before you get started
- 03 How to set up
- 04 How to install
- 09 Status introduction
- 11 Limited warranty
- 13 Safety

What's in the box



Please check the following conditions for a successful set-up:


- Turn on your phone's Wi-Fi and make sure it's connected to the same Wi-Fi network that you'll connect your Light Cam to.
- Select a **2.4 GHz** Wi-Fi network and write down the correct Wi-Fi password.
- Place Light Cam as close as to your router.
- Place the speaker of your smartphone close to the front side of Light Cam.
- Keep the environment quiet and turn the media volume to max on your smart phone so that Light Cam can hear your phone.

How to set up

First of all, start by powering your camera inside the house to get everything set up before you take it outside.

Step 1: Power the Camera

Plug the cable into the power port and then plug the power adapter into an indoor power outlet. The indicator light will turn on and turns blinking green when it is ready to set up.



Step 2: Connect

Download App from App Store or Google Play.
app now supports iOS 9.0 or later version and
Android 6.0 or later version.

Open App and follow the instructions to set up
your Light Cam in the app.



Step 3: Choose a spot

Tips for choosing a good spot:



■ Avoid direct sunlight

Light Cam is designed operate between
-20°C to 40°C. If it gets hotter or cooler, image
quality may be affected.


■ Keep it in range of your router


Make sure that you choose a place within range of your network. Thick or insulated walls can greatly reduce the strength of your Wi-Fi signal, even if your router is close by, so you should try streaming video before you mount your camera.



■ Consider the surroundings

Is a pole, plant or porch light blocking the view? It might throw off exposure or interfere with night vision and lighting. If you start noticing glare, adjust the camera so that the horizon is out of frame.





■ Place it up high

But not too high. We find that 2 to 3 meters above the ground, tilted downwards, is best—close enough to see someone's face and talk to them through the camera. If the power cable is not long enough to reach the indoor power outlet, you can use the provided extended cable to make it longer.

Once you've added Light Cam to your account, unplug it and take it to the spot you've chosen outdoors. Plug it into the outlet you want to use and wait for the green light to turn on. Light Cam will reconnect to your Wi-Fi network automatically. This may take a minute or two. Keep Light Cam plugged in for the rest of the installation.

Step 4: Wall Mounting

Before you mount the camera, make sure it can get Wi-Fi in the spot you've picked.

Hold your Light Cam where you'd like to mount it and check to make sure it's streaming video to the SENS8 app. If you don't see video, the Wi-Fi may not be strong enough there — you'll need to find a different spot or move your Wi-Fi router.

Tools you may need:



Drill



Drill bits

(3/32" for pilot holes, 7/32" for wall anchors, 1/2" for cable hole)



Screwdriver




Hammer




Ladder

Take the hole drilling template included and then tape it to the location you want to mount your camera.


- If you want to route the cable through a wall, use a 1/2" bit to drill a hole for the cable connector.
- If the wall is made of a material like brick or stone, you may need to use the wall anchors included to hold the screws. Use a 3/32" bit to drill 3 holes through the paper and wall for the plastic anchors. Then gently hammer each anchor into the holes.
- If you are mounting directly to wood or into a stud, use a 1/16" bit to drill 3 pilot holes for the included screws through the paper and wall.



Attach the camera with mounting bracket to the wall and secure the bracket with screws.



Use the live stream in the app to fine-tune your camera's position. Make the camera slightly downwards, so the motion sensor is optimized to detect human-sized objects at up to 30 feet.



Modes Introduction

Arm: Light Cam monitors your home and sends you a notification with or without sounding the alarm when it detects an abnormal activity/motion.

Disarm: The activities/motions are not monitored by Light Cam.

Schedule: You can set schedules for Arm and Disarm.

Auto-Arm: Light Cam automatically arms or disarms itself based on the location services of your smartphone. If SENS8 believes you are away from home, it will arm itself to protect your home.

Light Status:

SETUP OR UPDATE	
Light Status	Indication
Solid Green	Power On
Blinking Green	Ready to Set up
Blinking Blue	Wi-Fi Connecting
Solid Blue	Wi-Fi Connected
Blinking Red	Upgrading

Normal Running	
Light Status	Indication
Solid Blue	Work properly
Blinking Blue	Disconnected from Wi-Fi

Limited warranty

Smart Home, Inc. , 4500 Great America Parkway, Santa Clara, U.S. 95054, provides the following limited warranty. This limited warranty extends only to the original purchaser.

What Does This Warranty Cover; Period of Coverage

The limited warranty only covers product defects caused by workmanship or build materials for a period of one (1) year from the date of delivery following the original retail purchase (the "Warranty Period"). During this period, SENS8 will either (a) repair or replace defective parts with new or reconditioned parts at SENS8's option, without charge to you; or (b) accept the return of the Product and refund the money actually paid by the original purchaser for the Product. If the Product or a component incorporated within it is no longer available, SENS8 may, at SENS8's sole discretion, replace the Product with a similar product of similar function.

A replacement product/part assumes the remaining warranty of the original product or ninety (90) days from the date of replacement or repair, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes SENS8's property. When a refund is given, your product becomes SENS8's property.

What Does This Warranty Not Cover?

This Limited Warranty does not cover the following (collectively "Ineligible Products"):

1. Unauthorized disassembling, modification or installation has been performed upon the product;
2. The product showing signs of tampering or altering Labels, Serial Numbers, waterproof mark, false proof mark, etc.
3. Product is not normally used as not in accordance with the User's Guide,
4. Ordinary wear and tear.
5. Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane.

SENS8 does not bear costs associated with the replacement and/or repair of the unit, including: a) any freight, shipping or delivery charges b) any removal, installation or re-installation charges c) any material, and/or permits required for installation, re-installation or repaired) charges to return the defective product and/or component part to the manufacturer.

How Do You Get Service?

During warranty period, upon discovering a defect or problem, you should:

- a). Contact either the installer or dealer, or contact us :

4500 Great America Parkway,

Santa Clara, U.S. 95054

E-mail: support@mysens8.com

www.mysens8.com

- b). Notify Light Cam of the intention to claim with valid proof-of-purchase, receipt or order number of Light Cam

How Does State Law Relate to This Warranty?

This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages or exclusions or limitations on the duration of implied warranties or conditions, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary by state or province.

THIS WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. SENS8 SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Le rayonnement de la classe b respecte ISED fixaient un environnement non contrôlés. Installation et mise en œuvre de ce matériel devrait avec échangeur distance minimale entre 20 cm ton corps. Lanceurs ou ne peuvent pas coexister cette antenne ou capteurs avec d'autres.

Safety

PLACEMENT GUIDELINES

To avoid risk of overheating and burns:

Only use in temperatures between -20° to 40° °C.

Keep out of direct sunlight.

Do not block air flow to Light Cam.

To avoid risk of fire and shock:

Only use the USB cable and power adaptor provided. Install in accordance with local building and installation regulations. For example, if the power socket that you want to use is exposed to direct rain, the electrical standards may require that the socket have a while-in-use cover.

We recommend only using a power socket equipped with a residual current device (look for “Test” and “Reset” buttons on your socket).

To avoid risk of other serious injury:

Keep the camera and all of its components out of the reach of children and pets.

If your Light Cam is installed more than 2 m above the ground, make sure that you’ve got a cable clip close to the camera head (15 cm from the base).

If you're having issues with your Light Cam and need support, you can always feel free to contact us.

Call us: +1 (800) 215 – 8303
(9am–5pm PST)

Live chat: mysens8.com

Email: support@mysens8.com

Facebook: [@mysens8](https://www.facebook.com/mysens8)

Twitter: [@mysens8](https://twitter.com/mysens8)

©All Rights Reserved