


size:105X145mm

<p>PROSCAN RAINBOW LED LIGHT UP BLUETOOTH SPEAKER-FM RADIO Model : PSP1176-BLACK</p>  <p>Please read these instructions thoroughly before use and retain for future reference</p> <p>PROSCAN™ IS A REGISTERED TRADEMARK OF TECHNICOLOR USA INC. AND USED UNDER LICENSE TO CURTIS INTERNATIONAL LTD.</p>	<p>Description of parts</p> <table border="1"> <tbody> <tr> <td>1</td><td>M</td><td>Press to enter bluetooth mode / FM radio mode. /pair 2 speakers.</td></tr> <tr> <td>2</td><td>-</td><td>Short press for previous song. Long press for volume down.</td></tr> <tr> <td>3</td><td>+</td><td>Short press for next song. Long press for volume up.</td></tr> <tr> <td>4</td><td>II</td><td>Short press to pause / resume music / answer phone call. Long press to change, turn off the LED light / decline phone call.</td></tr> <tr> <td>5</td><td>USB port</td><td></td></tr> <tr> <td>6</td><td>MicroSD card port</td><td></td></tr> <tr> <td>7</td><td>Power switch</td><td></td></tr> <tr> <td>8</td><td>Micro-USB charging port</td><td></td></tr> </tbody> </table>  <p>1</p>	1	M	Press to enter bluetooth mode / FM radio mode. /pair 2 speakers.	2	-	Short press for previous song. Long press for volume down.	3	+	Short press for next song. Long press for volume up.	4	II	Short press to pause / resume music / answer phone call. Long press to change, turn off the LED light / decline phone call.	5	USB port		6	MicroSD card port		7	Power switch		8	Micro-USB charging port		<p>Operation</p> <ol style="list-style-type: none"> 1. Before first use, fully charge the battery (about 4-5 hours) via the provided USB cable. 2. Turn on the speaker by sliding the power switch on the back to the ON position. 3. Long press M to activate Bluetooth. 4. Open the Bluetooth settings on your device and select the speaker (Pro PSP1176) to make a connection. 5. Control your music via the speaker or via your device. <p>* The speaker reconnects automatically to your device after initial pairing.</p> <p>Pairing multiple speakers</p> <ol style="list-style-type: none"> 1. Turn on the speakers you wish to pair. 2. Long press M. You will hear a sound when the speakers are successfully paired. 3. Connect the speakers to a wireless device via Bluetooth. <p>TECHNICAL SPECIFICATIONS</p> <ul style="list-style-type: none"> • Bluetooth Version: 5.0 • Speaker Output: 5W • Battery Capacity: 1200mAh • Frequency Response Range: 80Hz-20Khz <p>FCC STATEMENT : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.</p> <p>2</p>	<p>-Increase the separation between the equipment and receiver.</p> <p>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>Consult the dealer or an experienced radio/TV technician for help.</p> <p>For service assistance and product information, please call: 1-800-968-9853. Curtis International Ltd. 7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3 www.curtisint.com</p> <p>To make a warranty claim, do not return this product to the store. Please email support@curtiscs.com or call 1-800-968-9853</p> <p>90 day Warranty</p> <p>This product is warranted to be free from defects in material and workmanship for a period of ninety (90) days from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be rendered inoperable or returned to us.</p> <p>This warranty does not cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as on the specified rating on the label (e.g., 120V-60Hz).</p> <p>We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty. This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.</p> <p>For faster service, locate the model, type, and serial numbers on your appliance.</p> <p>3</p>	<p>ATTACH YOUR PROOF OF PURCHASE HERE, PROOF OF PURCHASE IS REQUIRED TO OBTAIN WARRANTY SERVICE. Please have the following information available when you contact the Support Team: • Name, address and telephone number. • Model number and serial number. • A clear, detailed description of the problem. • Proof of purchase including dealer or retailer name, address and date of purchase.</p> <p>4</p>
1	M	Press to enter bluetooth mode / FM radio mode. /pair 2 speakers.																										
2	-	Short press for previous song. Long press for volume down.																										
3	+	Short press for next song. Long press for volume up.																										
4	II	Short press to pause / resume music / answer phone call. Long press to change, turn off the LED light / decline phone call.																										
5	USB port																											
6	MicroSD card port																											
7	Power switch																											
8	Micro-USB charging port																											

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.