






VANKYO SUPPORT

support.vankyo.com





Leisure 470Pro

User Manual


Please read the manual thoroughly before using this product and keep it for future reference.

V1.01


CONTENTS


WHAT'S INCLUDED	01
NOTICE	02
PRODUCT OVERVIEW	02
QUICK START	03
PROJECTOR CONNECTION AND INPUT SOURCE	04
1. USB Connection	04
2. TF Card Connection	04
3. HD Connection	04
4. AV Connection	05
SCREEN MIRRORING	05
WIFI CONNECTION	05
Bluetooth Connection	06
Projection Distance & Size	06
SETTINGS	12
Projection Distance & Size	13
SPECIFICATIONS	14
TROUBLESHOOTING GUIDE	15

WHAT'S INCLUDED




NOTICE

Recommended: 

NOT Recommended: 

PRODUCT OVERVIEW



- Lens
- Focus Wheel
- Memory Card Slot
- Audio Out
- USB Type-A
- USB Type-B
- AV Input
- Right Source (MHL/USB)
- Right Source (HDMI)
- Right Source (VGA)
- Power Button
- Right
- Left
- Power On
- Play/Pause
- Power Button
- Fast Forward
- Stop
- Left
- Right
- Down
- Up
- Equal Source
- Volume
- Menu

QUICK START

- Plug the power cord into the projector.
- Take off the lens cover.
- Press the Power Button to turn on the projector.
- Adjust the keyboard accordingly.


- Original USB cable (not included).
- Connect your device to the projector correctly.
- Adjust the system and focus ring to get the best image performance.
- Press the Power Button twice to turn off the projector.

PROJECTOR CONNECTION AND INPUT SOURCE

Connect your device to the projector correctly, then select the right input source on the homepage.

- USB Connection**
- TF Card Connection**
- HD Connection**

4. AV Connection



WIFI CONNECTION

Go to **Homepage** > **Settings** > **Network Settings** to connect the projector to your router's WiFi.

- Go to **Homepage** > **Settings** > **Network Settings** to connect the projector to your router's WiFi.
- Go to **Homepage** > **Settings** > **Network Settings** to connect the projector to your router's WiFi.

SCREEN MIRRORING for iOS System

Screen Mirroring Wirelessly

- Step 1: Activate Screen Mirroring/Playing Mirroring in the Control Center of your iOS device and search for the projector.
- Step 2: Go to **Homepage** and select iOS Cast to enter the interface below.
- Step 3: Select **Screen Mirroring/Playing Mirroring** from the searching list. The contents on your iOS device will be mirrored on the projection screen wall after a successful connection.

Screen Mirroring via Lightning Cable

- Go to **Homepage** and select iOS Cable to enter the interface below.
- Go to **Homepage** and select iOS Cable to enter the interface below.
- Go to **Homepage** and select iOS Cable to enter the interface below.

FOR ANDROID SYSTEM

To activate this function, please make sure your Android device supports Multimedia/SmartView/Miracast/Display Feature may vary on different Android devices.

- Go to the **WiFi** settings of your Android mobile device to switch on the option of **WiFi**.
- Go to **Homepage** and select **Miracast** to enter the interface below.

BLUETOOTH CONNECTION

1. Use as a Bluetooth Speaker

You can connect your mobile device to this projector via a Bluetooth connection and use it as Bluetooth speaker.

- Go to **Homepage** > **Settings** > **BT Amplifier** to make the projector ready for Bluetooth connection.
- Go to the Bluetooth setting of your mobile device to turn on the Bluetooth, then search for **Vankyo** from the searching list and pair the mobile device with the projector.
- Press the back button to exit this mode.

2. Connect to an External Bluetooth Speaker

Except for the wired 3.5mm audio output port connection, you can also connect a Bluetooth speaker or Bluetooth headphones to this projector via the Bluetooth connection.

- Go to your Bluetooth device and make it ready for a Bluetooth connection.

- Go to **Homepage** > **Settings** > **System Setting** > **Bluetooth** and press **OK** to enter the interface below.
- Press the **Right** button to turn on the Bluetooth function of the projector, then select **Search device** and press **OK** to start searching for available Bluetooth devices.
- Press the **Right** button to turn on the Bluetooth function of the projector, then select **Search device** and press **OK** to start searching for available Bluetooth devices.
- Select your BT device and pair it with the projector.

IMPORTANT:

- Compared with the wired connection to a speaker, BT wireless connection spends more time processing digital audio files, causing some delay in an audio signal, and weakening the signal. There may be delay or slight lag on audio for digital connection.
- As a result, the sound on the speaker may not be in sync with the image on the projector, especially when you are using wireless screen mirroring with WiFi and BT wireless connection at the same time.
- If you are experiencing this situation, please check the following options to improve audio quality:
 - Instead of using wireless screen mirroring with WiFi and BT wireless connection at the same time, we recommend using wired screen mirroring and BT connection or using WiFi connection with the provided HDMI cable and BT connection simultaneously. If you still want to use wireless screen mirroring, it is recommended to output the audio via a wired speaker.

SETTINGS

1. Press the **Menu** button on any interface to check **Picture**, **Sound** and **Option** settings.

Picture **Sound** **Option**

Tip:

- After you select **Mode** in the option of **Picture Mode**, you can change the settings of the **Contrast**, **Brightness**, **Color**, **Gamma** and **Dynamic** to adjust the image quality.
- If you select **Auto** in the option of **Sound**, you could change the settings of the **Treble** and **Bass** to adjust the sound effect.
- If you are using the **USB connection** or **HD connection** on the projector, the option of **Aspect Ratio** will be disabled. You can then adjust the aspect ratio of the projection image.

2. Go to Homepage > Settings to connect the projector to a WiFi network, enable BT amplifier mode, change language, rotate the projection to factory settings, change the projection mode and adjust the image size.


USE AS A BLUETOOTH SPEAKER

Go to **Homepage** > **Settings** > **BT Amplifier** to make the projector ready for Bluetooth connection.

CONNECT TO WIFI

Go to **Homepage** > **Settings** > **Network Settings** to connect the projector to your router's WiFi.

PROJECTION DISTANCE & SIZE



The recommended projection distance varies with different projection contents. Please adjust the distance between the wall/screen and the projector properly as needed.

* Ambient darkness will improve the clarity of the projected images.

TROUBLESHOOTING GUIDE

- The content from Hulu, Netflix, and similar services can not be mirrored or cast.
 - Due to the copyright restriction from Hulu, Netflix, and similar services, the content **WMV** NOT be mirrored or cast.
- What should I do to watch the content from Hulu, Netflix, and similar services via the projector?
 - Please prepare a PC to watch the content from Hulu, Netflix, or Chromecast (not included). Then connect it to the projector to watch the content.
3. **Blurry Image**
 - Adjust focusing ring properly.
 - Projector and screen/wall must be in the same plane.
4. **Remote Unresponsive**
 - Make sure remote points at IR receiver directly.
 - Check the IR receiver.
 - Replace the old AA batteries with new ones.
5. **Update Down Brings**
 - Go to **Homepage** > **Settings** > **Projection Setting** > **Projection Mode** to fix the projection image.
6. **Factory Reset**
 - Go to **Homepage** > **Settings** > **System Setting** > **Restore Factory Default** to restore the projector to default settings.
7. **TF Card only support a few video formats.**
 - It can't be limited decoding and play, so it only supports video formats of MP4, WMV and MOV for the format type of audio. It supports H.264 and for the resolution, it supports 1080P/720P. If there is any unpaired video, it is recommended to save it to disk through the USB connection via a computer through the HD connection.

FCC Statement

All digital products are electronically accepted by the FCC, regulated by the FCC under part 15. The user must comply with the following conditions: 1. The device may not cause harmful interference, and 2. If the device does cause interference, the user must stop using the device immediately.

IMPORTANT NOTE:

This projector is a Class B digital device. It may cause radio interference to other electronic devices. The user must be notified of this interference. If you are experiencing interference, please contact your local FCC office for more information. The user must stop using the device immediately if the device causes interference to other electronic devices. The user must stop using the device immediately if the device causes interference to other electronic devices. The user must stop using the device immediately if the device causes interference to other electronic devices.

FCC Radiation Exposure Statement:

This projector complies with FCC radiation exposure limits for unlicensed intentional radiators. The equipment holder should not operate this projector closer than 20cm to the antenna body.