### The Lullabuddy™ Speaker is Bluetooth® enabled. To pair with another Bluetooth® device, follow these steps:

- 1. Turn the Lullabuddy speaker power switch on.
- 2. Press & hold the center Play/Pause button until the blue light flashes.
- On your mobile device, open Bluetooth®. Find & select Lullabuddy on the list of devices available to pair.
- Start music on your mobile device & it will play through the Lullabuddy speaker.
- To stop streaming music, simply press & hold the Play/Pause button to de-activate Bluetooth®.
- If Lullabuddy doesn't appear on your mobile device, try turning Bluetooth® 0ff & back on again. Then turn Lullabuddy off & back on again. Now try the Bluetooth® pairing sequence again.
- Once you have paired a device to the Lullabuddy you should not have to pair it again.
- If Lullabuddy still doesn't show up on your mobile device list, make sure it is not paired with another device that is nearby.

#### Specifications

Output: RMS 3W THD=10%

Frequency Response: 150-18000HZ(+/-3dB)

Signal and Noise Ratio of Power Amplifier > 80dB

Loud Speaker: 1.77 Inches (External Diameter 45mm), Impedance: 4 Ohms Power Supply: 3,7V/800mAh

TF Card: Internal card pre-loaded with music

IF Card: Internal card pre-loaded with music

The lithium battery in this speaker has been tested and passed according to section 38.3 of the UN Manual of Tests and Criteria (UN Transportation Testing) and is safe for general mailing and air transport.

When battery dies, plug the Lullabuddy in to charge it and turn power switch off and back on again to start speaker playing.

This product is not a toy and is not intended for use by child.

This product is not intended for use in crib.

For adult use only.

Visit https://lullabuddy.com for full song and musician credits
Visit https://lyricpartners.com/lullabuddy for user's guide

© Lyric Partners, LLC




User Manual

# 

#### Functions

- 1. Power: On/Off selection
- Shuffle: On: Songs play in shuffle mode
   Off: Songs play in sequence
- Timer: On: Speaker turns off after one hour Off: Speaker plays continuously
- 4. USB Port: Connect USB cable to power speaker or charge battery
- Previous/Rewind: Press once to go to previous track
   Press and hold to rewind
- 6. Volume Down: Press to decrease volume
- 7. Next/Fast Forward: Press once to go to next track
- Press & hold to fast forward
- Play/Pause/Bluetooth® : Press once to start or pause
   Press & hold to activate Bluetooth®
- 9. Volume Up: Press to increase volume
- Indicator Light: Solid blue when power is on
   Flashing red when battery charge is low
   Solid red when charging



## **FCC STATEMENT:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.