

HF2 PRO Wireless+Active Noise Cancelling+Touch Screen Headphone

Owner's Guide

Noise Cancelling Power Switch

When the switch is on (it shows green, otherwise, it's grey), active noise cancelling works, and LED turns blue.



Charge

Open the USB port, insert the charge cable, LED turns red. It will turn blue after a full charge.



Touch screen

Vol Up:Slide from bottom to the top

Vol Down:Slide from top to bottom

Next Track: Slide forward

Prew Track:Slide backward




A convenient multifunction key

Function	Operation
Turn on/off	Long press the for 3 seconds until the LED light starts flashing.
Pairing	Connect for the first time: Long press the MFB until the LED light flash blue and red to let you know it is ready to pair. It will be connected automatically next time when device turn on.
Answer/hang up a call	Short press the MFB once.
Reject a call	Long press the MFB.
Redial your last call	Short press the MFB twice.
Low battery warning	LED light will flash red.

Ergonomic design

Stretched headband is a very comfortable wearing for anyone.

Comfortable memory foam design, soft and comfortable, can be worn for a long time, without any negative feeling.



Headband Adjustment



Earpads replacement

Specs:

- Brand:
- Model:
- Type: Wireless +Noise cancelling +Touch screen
- Speaker Size: $\Phi 40\text{mm}$
- Sound pressure level:98 $\pm 3\text{dB}$ (1KHz/1mW)
- Impedance:32 Ω
- Frequency Response:20Hz-20KHz
- Rated input power: 30mW
- Maximum Input Power:50mW
- Noise Bandwidth:40Hz-1000Hz
- The Depth of Noise Cancelling:18-20dB
- The MIC Frequency Range:10-4000Hz
- MIC Sensitivity:-42dB
- Battery Capacity:540mAh
- Denoise Time:15H
- Charging Time:4.5H

General precaution

1. When you listen to the music, adjust the volume from low to high slowly, please don't turn up the volume suddenly, to avoid damage to the earphone.
2. When you place the earphone, avoid any direct contact with strong magnets, which may make the permanent magnet lose the magnet, and the sensitivity of earphone will be reduced, thus affecting earphones sound.
3. Avoid falling to the ground, or any type of collision, which may cause damage.
4. The earphone plug should be used with the matching size of socket. And the headset should

be inserted in the special jack, to avoid damage to the earphones.

Safe usages

1. When connecting with equipment, just make sure to connect properly, in case the poor contact causing the voice off and on or no sound.
2. Don't listen at high volume levels for long periods of time to prevent hearing damage.
3. Please adjust the volume from low to high, let your ear adapt slowly, but please don't turn up the volume suddenly, it will hurt your ear a lot.
4. When you turn noise reduction on, the volume will turn up, and it's a normal phenomenon.

Environmental instruction

Parts Name (generally classified)	Poisonous and harmful substances or elements					
	Pb	Hg	Cd	CrVI	PBB	PBDE
Body (metal parts)	X	O	O	O	O	O
Install the base version /Electrical components	X	O	O	O	O	O
Cable	X	O	O	O	O	O

Remark: "0" means the content of toxic and harmful substances in all homogeneous materials of this parts is within the limit requirements of SJ/T11363-2006 standard.
"x" because we still haven't found other substances to replace it with modern technology.

Dangerous

- Please don't play headphone when you are driving, riding or walking, if not, it's very easy to cause traffic accident.

Prohibition

Attention

The rated power of MAX is 10mW, please don't overload to avoid broke the earphone.

Prohibition

Warm

- Please don't pull cable hard, in order to avoid broken.

Prohibition

- Please don't remove the earphone or change the internal structure arbitrarily, to avoid the failure.

Prohibition

- Please put the earphone in a safe place where children are not exposed to avoid the danger.

Warranty

1. This is warranty certificate, user need to keep it.
2. The warranty with one year from the date of purchase.
3. Except the event of force majeure, we repair it for free. But if incorrect usage cause the damage, will be charged.
4. If you remove the earphone arbitrarily, not warranty.

Name:

Tele:

Add:

Product:

Model:

Purchase date:

Maintenance record

(Filled in by the maintenance man)

Signature of

Maintenance man

Date

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.