

Bone conduction earphone

Instructions for user

1. Charge

Charge the headphones with the included micro-USB cable. The LED light will turn from red to blue when charging is complete.

2. Pair

Start with your headphones off. Enter pairing mode by pressing and holding volume+ until Audrey says “pairing” and the LED light flashes red and blue.

3. Connect

Open your device’s Bluetooth® menu and select. Audrey says “Connected” and the LED light will flash blue one time.

Multifunction Button

Function	Action	Prompt/ “Audrey Says™”
Play/pause music	Click once	One beep
Skip to next song	Double-click while music is playing	One beep
Answer/end call	Click once	Two/One beep
Reject a call	Press and hold for 2 seconds	Two beeps

Volume Up/Power Button (+) ; Volume Down Button (-)

Function	Action	Prompt/ “Audrey Says™”
Power on	Press and hold volume+ for 3 seconds	“power on
Power off	Press and hold volume+ for 3 seconds	“Power off”
Adjust volume	Click the volume up or down button to adjust volume	One beep

LED Indicator

Charging	Solid red
Charging complete	Solid blue
Pairing mode	Flashes red and blue

Specifications:

Brand	EKEN
Part number	E1
Bluetooth® version	Bluetooth®v5.0

Battery Capacity	200mAh
Compatible profiles	A2DP,AVRCP,HSP,HFP
Continuous play	up to 6 Hours
Charge time	2 Hours
Maximum Charge Voltage	5.25V
Frequency response	20Hz~20KHz
Microphone	-40dB ± 3dB
Wireless range	33 ft (10m)
Weight	0.95oz(25g)
Standby time	Up to 20 days
Warranty	1 year
Speaker Impedance	8ohm

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Multifunction Button
多功能键



